

Motorflug Baden-Baden GmbH

CAPABILITY LIST

No. 7F-08-11-90

referring to

EASA Part-145 Approved Repair Station

EASA No. DE.145.0082

Place of business:

**Flugstraße 12
76532 Baden-Baden
Germany**

Headquarter and delivery address:

**Baden-Airpark
Summersite Ave. C 312
77836 Rheinmünster
Germany**

Tel.: 0 72 29 / 3014-0

Fax: 0 72 29 / 3014-25

info@motorflug.com

EASA Part-145 Approved Maintenance Organization (Line & Base Maintenance)
Approval No. DE.145.0082
FAA approved Repair Station
Approval No. DE5Y802M

Index

- Front Page**
- List of temporary revisions**
- 0. Release endorsement**
- 1. Fixed Wing Capabilities, EASA Part-145 / FAA approved**
- 2. Helicopter Capabilities, EASA Part-145 / FAA approved**
- 3. Engines, EASA Part-145 / FAA approved**
- 4. Components other than complete engines or APUs, EASA Part-145 / FAA approved**
 - 4.1 Mechanical / Hydraulic Components (C8- / C10- / C11- / C12- / C14- / C20-Rating)**
 - 4.2 Electric / Electronic Components (C2- / C5- / C13-Rating)**
 - 4.3 Avionic Systems (C2- / C3- / C13-Rating)**
 - 4.4 Equipment (C6-Rating)**
 - 4.5 Instruments: P/N**
- 5. Non-Destructive Testing, EASA Part-145 / FAA approved**

List of Temporary Revisions:

Revision No.	Date	Subjected Chapters	Manufacturer's P/N
TR1	2021-01-21	4.1	L642A0101053
TR2	2021-02-18	4.1	D671M7018101
TR2	2021-02-18	4.1	D623M4005101
TR3	2021-04-28	4.1	B671M7016101
TR3	2021-04-28	4.1	B671M7016102
TR3	2021-04-28	4.1	B671M7005101
TR4	2021-05-17	4.1	206-706-045-107
TR4	2021-05-17	4.1	D670M5002101
TR5	2021-05-21	4.1	L642A2020202
TR6	2021-06-25	4.1	212-540-002-...

EASA Part-145 Approved Maintenance Organization (Line & Base Maintenance)

Approval No. DE.145.0082

FAA approved Repair Station

Approval No. DE5Y802M

TCCA Approved Maintenance Organization

Approval No. 813-23

Capability List No. 7F-08-11-90

Chapter	Titel	Revision no.	Date
1.	Fixed Wing Capabilities	Revision 8	Aug. 10, 2020
2.	Helicopter Capabilities	Revision 8	Aug. 10, 2020
3.	Engines	Revision 8	Aug. 10, 2020
4.	Components other than complete engines or APUs	Reissue	May 23, 2017
4.1	Mechanical / Hydraulic Components (C8- / C9- / C10- / C11- / C12- / C14- / C20-Rating)	Revision 8	Aug. 10, 2020
4.2	Electric / Electronic Components (C2- / C5- / C13-Rating)	Revision 4	Sept. 24, 2018
4.3	Avionic Systems (C2- / C3- / C13-Rating)	Revision 4	Sept. 24, 2018
4.4	Equipment (C6-Rating)	Revision 5	Feb. 28, 2019
4.5	Instruments: P/N	Revision 4	Sept. 24, 2018
5.	Non-Destructive Testing, EASA Part-145 / FAA approved	Reissue	May 23, 2017

It is confirmed that the required maintenance data, facilities, test equipment and personnel qualifications acc. to EASA Part-145.A.70 are available within the scope of this capability list.

Date: 12.08.2020

SIGNED

Benjamin Razii
Accountable Manager

Date: 12.08.2020

SIGNED

Rober Kowollik
Dep. Quality Manager

Date: 10.09.2020

SIGNED

Kevin Kissling
Luftfahrtbundesamt
(National aviation authority)

EASA Part-145 Approved Maintenance Organization (Line & Base Maintenance)

Approval No. DE.145.0082

FAA approved Repair Station

Approval No. DE5Y802M

TCCA Approved Maintenance Organization

Approval No. 813-23

Fixed Wing Aircraft

Group ratings for

aircraft with piston engines and with a maximum mass of 2000 kg

aircraft with multi piston engines - metal structure, not requiring individual type training

For these aircraft types the issue of an airworthiness certificate is not authorised.

A2 ratings

Aircraft Type	Rating	Limitations
Cessna 182 Series	A2 rating	
Vulcanair P.68 Series (Lycoming)	A2 rating	

EASA Part-145 Approved Maintenance Organization (Line & Base Maintenance)

Approval No. DE.145.0082

FAA approved Repair Station

Approval No. DE5Y802M

TCCA Approved Maintenance Organization

Approval No. 813-23

Helicopter

Group ratings for:

helicopters, Singel Turbine Engine, not requiring individual type training

Aircraft Types	Limitations	Entry Date
Leonardo S.p.A. A109 Series		
Leonardo S.p.A. A119 / AW119 MKII		
Leonardo S.p.A. AB139 / AW139		
Agusta AB204 / AB205		
Leonardo S.p.A. AB206		
Leonardo S.p.A. AB212		
Leonardo S.p.A. AB412		
Bell 204		
Bell 205		
Bell 206		
Bell 505		
Bell 212		
Bell 222		
Bell 230		
Bell 407		
Bell 412		
Bell 427		
Bell 429		
Bell 430		

Aircraft Types	Limitations	Entry Date
Eurocopter BO105 Series		
Eurocopter AS 350		
Eurocopter AS 355		
Eurocopter EC120		
Eurocopter EC130		
Eurocopter EC135		
Eurocopter MBB BK117 A/B		
Eurocopter MBB BK117 C1		
Eurocopter MBB BK117 C2		
Eurocopter MBB BK117 D2		05.08.2019
MD Helicopters 369 Series / SEI NH-500D		
MD Helicopters MD900		
Robinson R66		
Schweizer 269D		

EASA Part-145 Approved Maintenance Organization (Line & Base Maintenance)

Approval No. DE.145.0082

FAA approved Repair Station

Approval No. DE5Y802M

TCCA Approved Maintenance Organization

Approval No. 813-23

Engines

Manufacturer	Engine Type	Limitations
Honeywell	LTS101 Series	No limitations
Pratt & Whitney	PT6A	Except Overhaul
	PT6A-41 Series	Except Overhaul
	PT6A-67 Series	Except Overhaul
	PT6A-100 Series	Except Overhaul
	PT6C-67 Series	Except Overhaul
	PT6T	Except Overhaul
	PW206 Series	Except Overhaul
	PW207 Series	Except Overhaul
Rolls Royce	PW210	Except Overhaul
	250 C28	No limitations
	250 Series II	Except Overhaul
Turbomeca	ARRIEL 1 Series	Except Overhaul
	ARRIEL 2 Series	Except Overhaul
	ARRIUS 2 Series	Except Overhaul

EASA Part-145 Approved Maintenance Organization (Line & Base Maintenance)

Approval No. DE.145.0082

FAA approved Repair Station (excluding Gyro Systems and Encoding Altimeter Systems)

Approval No. DE5Y802M

TCCA Approved Maintenance Organization

Approval No. 813-23

Components other than complete engines or APUs

Rating

C2	Auto flight
C3	Comms & NAV
C5	Electrical Power & Lights
C6	Equipment
C8	Flight Controls
C9	Fuel System
C10	Helicopter - Rotors
C11	Helicopter - Transmission
C12	Hydraulic Power
C13	Indicating / Recording Systems
C14	Landing Gear
C20	Structural

EASA Part-145 Approved Maintenance Organization (Line & Base Maintenance)

Approval No. DE.145.0082

FAA approved Repair Station

Approval No. DE5Y802M

TCCA Approved Maintenance Organization

Approval No. 813-23

Manufacturer	Manufacturer's P/N	Designation	Limitation	Entry date
Leonardo	204-012-101-...	Hub Assy		05.08.2019
Leonardo	204-011-166-...	Bolt		05.08.2019
Leonardo	204-011-151-...	Bolt assy, Blade		05.08.2019
Leonardo	204-011-153-...	Nut		05.08.2019
Leonardo	204-011-152-...	Washer		05.08.2019
Leonardo	204-011-140-...	Brace Assy, Drag		05.08.2019
Leonardo	204-011-141-...	Fitting		05.08.2019
Leonardo	204-011-180-...	Fitting		05.08.2019
Leonardo	204-011-142-...	Clevis		05.08.2019
Leonardo	204-011-179-...	Clevis		05.08.2019
Leonardo	204-011-144-...	Nut		05.08.2019
Leonardo	204-011-143-...	Barrel Assy		05.08.2019
Leonardo	204-011-116-...	Nut		05.08.2019
Leonardo	204-011-120-...	Horn Assy		05.08.2019
Leonardo	204-011-121-...	Gripp Assy		05.08.2019
Leonardo	204-011-125-...	Plate Assy		05.08.2019
Leonardo	204-012-106-...	Nut		05.08.2019
Leonardo	204-012-116-...	Shield Assy		05.08.2019
Leonardo	204-012-104-...	Pin		05.08.2019
Leonardo	204-012-103-...	Fitting		05.08.2019

Capability List

Chapter 4.1: Dynamic + Hydraulic Components



Leonardo	204-012-102-...	Fitting Assy	05.08.2019
Leonardo	204-012-105-...	Stop Assy, Main Rotor	05.08.2019
Leonardo	204-011-135-...	Bushing	05.08.2019
Leonardo	204-011-108-...	Pillow Block	05.08.2019
Leonardo	204-011-105-...	Trunnion Assy	05.08.2019
Leonardo	204-011-148-...	Radius Ring	05.08.2019
Leonardo	204-011-134-...	Bearing Lock	05.08.2019
Leonardo	204-011-122-...	Liner Assy	05.08.2019
Leonardo	204-011-128-...	Universal Bearing	05.08.2019
Leonardo	204-010-481-...	Nut Mast	05.08.2019
Leonardo	204-011-438-...	Lever Assy	05.08.2019
Leonardo	204-011-326-...	Stabilizer Assy	05.08.2019
Leonardo	540-011-319-...	Tube Assy	05.08.2019
Leonardo	204-011-328-...	Tube Assy	05.08.2019
Leonardo	204-011-301-...	Lever Assy	05.08.2019
Leonardo	204-011-304-...	Support Assy	05.08.2019
Leonardo	204-011-307-...	Frame Assy	05.08.2019
Leonardo	204-011-401-...	Scissors and Sleeve Assy	05.08.2019
Leonardo	204-011-408-...	Sleeve, Collective	05.08.2019
Leonardo	204-010-420-...	Nut	05.08.2019
Leonardo	204-010-437-...	Nut Assy	05.08.2019
Leonardo	204-011-410-...	Spacer Set	05.08.2019
Leonardo	540-011-461-...	Spacer Set	05.08.2019
Leonardo	204-010-479-...	Plate Set	05.08.2019
Leonardo	204-011-405-...	Hub Assy	05.08.2019
Leonardo	204-011-406-...	Scissor Assy	05.08.2019
Leonardo	204-011-407-...	Link Assy	05.08.2019
Leonardo	204-011-400-...	Swashplate and Support Assy	05.08.2019
Leonardo	204-011-403-...	Ring Assy Outer	05.08.2019
Leonardo	204-011-402-...	Ring Assy Inner	05.08.2019

Leonardo	204-011-404-...	Support Assy	05.08.2019
Leonardo	204-010-404-...	Ring Assy	05.08.2019
Leonardo	204-040-366-...	Mast Assy	05.08.2019
Leonardo	204-040-309-...	Nut	05.08.2019
Leonardo	204-040-270-...	Race	05.08.2019
Leonardo	204-040-115-...	Nut	05.08.2019
Leonardo	204-040-307-...	Bearing Liner	05.08.2019
Leonardo	204-040-349-...	Plate Assy	05.08.2019
Leonardo	204-040-761-...	Jet Assy	05.08.2019
Leonardo	204-011-450-...	Mast Assy	05.08.2019
Leonardo	204-040-347-...	Plate	05.08.2019
Leonardo	204-040-009-...	Transmission Assy	05.08.2019
Leonardo	204-040-359-...	Case Assy Top	05.08.2019
Leonardo	204-040-117-...	Adapter	05.08.2019
Leonardo	204-040-337-...	Liner	05.08.2019
Leonardo	204-040-330-...	Gear, upper sun	05.08.2019
Leonardo	205-040-230-...	Gear, upper sun	05.08.2019
Leonardo	204-040-338-...	Liner	05.08.2019
Leonardo	204-040-257-...	Liner	05.08.2019
Leonardo	204-040-329-...	Gear	05.08.2019
Leonardo	204-040-331-...	Ring Gear Assy	05.08.2019
Leonardo	205-040-231-...	Ring Gear Assy	05.08.2019
Leonardo	205-040-135-...	Jet	05.08.2019
Leonardo	204-040-353-...	Case Assy Main	05.08.2019
Leonardo	204-040-354-...	Case Assy Support, Main Transmission	05.08.2019
Leonardo	204-040-131-...	Nut	05.08.2019
Leonardo	204-040-130-...	Shaft, Planetary Pinion	05.08.2019
Leonardo	204-040-130-5	SHAFT, SHOULDERED	05.08.2019
Leonardo	204-040-134-...	Washer	05.08.2019
Leonardo	204-040-108-...	Pinion	05.08.2019

Leonardo	204-040-132-...	Bearing Race, Planetary Pinion	05.08.2019
Leonardo	204-040-397-...	Spiser Assy	05.08.2019
Leonardo	204-040-788-...	Nut	05.08.2019
Leonardo	204-040-789-...	Washer	05.08.2019
Leonardo	204-040-787-...	Bolt	05.08.2019
Leonardo	204-040-790-...	Cup	05.08.2019
Leonardo	204-040-786-...	Plate Assy	05.08.2019
Leonardo	204-040-357-...	Plate	05.08.2019
Leonardo	204-040-386-...	Case Assy, Bevel Gear, Transmission	05.08.2019
Leonardo	204-040-122-...	Nut	05.08.2019
Leonardo	204-040-123-...	Lock Ring	05.08.2019
Leonardo	204-040-324-...	Shaft	05.08.2019
Leonardo	204-040-701-...	Gear	05.08.2019
Leonardo	204-040-363-...	Quill Assy, Main Input Transmission	05.08.2019
Leonardo	205-040-263-...	Quill Assy, Main Input Transmission	05.08.2019
Leonardo	204-040-191-...	Race Outer	05.08.2019
Leonardo	204-040-184-...	Nut	05.08.2019
Leonardo	204-040-190-...	Race , Inner	05.08.2019
Leonardo	204-040-148-...	Plate	05.08.2019
Leonardo	204-040-356-...	Sleeve Assy	05.08.2019
Leonardo	204-040-700-...	Pinnion	05.08.2019
Leonardo	205-040-256-...	Sleeve Assy	05.08.2019
Leonardo	205-040-232-...	Race Outer	05.08.2019
Leonardo	204-040-379-...	Quill Assy, Generator Drive Transmission	05.08.2019
Leonardo	204-040-427-...	Nut	05.08.2019
Leonardo	204-040-412-...	Nut	05.08.2019
Leonardo	204-040-189-...	Specer Set	05.08.2019
Leonardo	204-040-102-...	Pinnion Assy	05.08.2019
Leonardo	204-040-399-...	Sleeve Assy	05.08.2019
Leonardo	204-040-213-...	Quill Assy, Offset Accesory and Tail Rotor Drive	05.08.2019

Capability List

Chapter 4.1: Dynamic + Hydraulic Components



Leonardo	204-040-252-...	Nut	05.08.2019
Leonardo	204-040-250-...	Sleeve Assy	05.08.2019
Leonardo	204-040-251-...	Plate	05.08.2019
Leonardo	204-040-763-...	Gear	05.08.2019
Leonardo	204-040-321-...	Support	05.08.2019
Leonardo	204-040-186-...	Nut	05.08.2019
Leonardo	204-040-762-...	Pinnion	05.08.2019
Leonardo	204-040-121-...	Shaft	05.08.2019
Leonardo	204-040-197-...	Shaft	05.08.2019
Leonardo	204-040-298-...	Jet No. 4	05.08.2019
Leonardo	204-040-206-...	Quill Assy, Accesory and Tail Rotor Drive	05.08.2019
Leonardo	204-040-185-...	Nut	05.08.2019
Leonardo	204-040-185-3	RING, EXTERNALLY THREADED	05.08.2019
Leonardo	204-040-230-...	Nut	05.08.2019
Leonardo	204-040-305-...	Sleeve Assy	05.08.2019
Leonardo	204-040-170-...	Spacer	05.08.2019
Leonardo	204-040-103-...	Gear	05.08.2019
Leonardo	204-040-207-...	Quill Assy Tail Rotor Drive	05.08.2019
Leonardo	204-040-610-...	Plate Assy	05.08.2019
Leonardo	204-040-607-...	Retainer	05.08.2019
Leonardo	204-040-612-...	Bolt	05.08.2019
Leonardo	204-040-603-...	Coupling	05.08.2019
Leonardo	204-040-604-...	Coupling	05.08.2019
Leonardo	204-040-104-...	Pinion Assy	05.08.2019
Leonardo	204-040-367-...	Quill Assy , Hydraulic Pump and Tachometer Drive	05.08.2019
Leonardo	204-040-105-...	Pinion Assy	05.08.2019
Leonardo	204-040-112-...	Sprocket Wheel	05.08.2019
Leonardo	204-040-333-...	Sprocket Assy	05.08.2019
Leonardo	204-040-334-...	Cover Assy	05.08.2019
Leonardo	204-040-306-...	Sleeve Assy	05.08.2019

Leonardo	204-040-387-...	Manifold Assy	05.08.2019
Leonardo	204-040-390-...	Body	05.08.2019
Leonardo	204-040-388-...	Jet Assy	05.08.2019
Leonardo	204-040-010-...	Drivshaft Assy	05.08.2019
Leonardo	204-040-686-...	Driveshaft	05.08.2019
Leonardo	205-040-178-...	Coupling	05.08.2019
Leonardo	204-040-687-...	Coupling	05.08.2019
Leonardo	204-040-616-...	Plate	05.08.2019
Leonardo	204-040-614-...	Coupling	05.08.2019
Leonardo	204-040-602-...	Shaft	05.08.2019
Leonardo	204-040-617-...	Hanger Driveshaft	05.08.2019
Leonardo	204-040-003-...	Gearbox Assy, Tail Rotor	05.08.2019
Leonardo	204-040-513-...	Case Assy, Tail Rotor	05.08.2019
Leonardo	204-040-500-...	Gear	05.08.2019
Leonardo	204-040-012-...	Gearbox Assy Tail Rotor Drive 90 Degree	05.08.2019
Leonardo	204-040-418-...	Case	05.08.2019
Leonardo	204-040-425-...	Sleeve assy	05.08.2019
Leonardo	204-040-423-...	Sleeve Assy	05.08.2019
Leonardo	204-040-402-...	Shaft	05.08.2019
Leonardo	204-040-401-...	Gear	05.08.2019
Leonardo	204-040-405-...	Bolt	05.08.2019
Leonardo	204-040-400-...	Pinon	05.08.2019
Leonardo	204-012-101-...	Hub Assy, Main Rotor	05.08.2019
Leonardo	204-012-118-...	Shild	05.08.2019
Leonardo	212-010-416-...	Ring Assy, Gimbal	05.08.2019
Leonardo	212-040-506-...	Case Assy	05.08.2019
Leonardo	212-040-501-...	Nut	05.08.2019
Leonardo	212-010-468-...	Case Assy	05.08.2019
Leonardo	209-011-712-...	Lever Assy	05.08.2019
Leonardo	209-011-711-...	Idler Assy, Control	05.08.2019

Capability List

Chapter 4.1: Dynamic + Hydraulic Components



Leonardo	209-011-713-...	Link Assy	05.08.2019
Leonardo	209-011-720-...	Housing	05.08.2019
Leonardo	212-010-701-...	Hub Assy	05.08.2019
Leonardo	212-011-701-...	Hub Assy	05.08.2019
Leonardo	212-011-704-...	Trunnion Assy, Tail Rotor	05.08.2019
Leonardo	212-011-702-...	Yoke Assy, Tail Rotor	05.08.2019
Leonardo	205-040-001-...	Transmission Assy	05.08.2019
Leonardo	212-040-206-...	Adapter	05.08.2019
Leonardo	205-040-229-...	Gear , Lower	05.08.2019
Leonardo	204-040-378-...	Deflector	05.08.2019
Leonardo	212-010-053-...	Case Assy, Main	05.08.2019
Leonardo	204-030-987-...	Link Assy, Lift	05.08.2019
Leonardo	209-030-987-...	Link Assy, Lift	05.08.2019
Leonardo	205-030-987-...	Link Assy, Lift	05.08.2019
Leonardo	205-040-233-...	Pinion	05.08.2019
Leonardo	204-040-785-...	Spider Assy	05.08.2019
Leonardo	412-040-785-...	Spider Assy	05.08.2019
Leonardo	212-040-786-...	Plate Assy	05.08.2019
Leonardo	214-010-097-...	Sleeve	05.08.2019
Leonardo	214-040-718-...	Cap Assy	05.08.2019
Leonardo	212-040-203-...	Sleeve Assy	05.08.2019
Leonardo	212-040-201-...	Gear	05.08.2019
Leonardo	212-040-207-...	Spacer	05.08.2019
Leonardo	212-040-197-...	Dshaft	05.08.2019
Leonardo	212-040-221-...	Jet Assy	05.08.2019
Leonardo	204-040-355-...	Case Sump	05.08.2019
Leonardo	212-040-154-...	Sleeve Assy	05.08.2019
Leonardo	212-040-153-...	Nut	05.08.2019
Leonardo	212-040-156-...	Spacer	05.08.2019
Leonardo	212-010-149-...	Gear Assy, Spiral Bevel	05.08.2019

Leonardo	204-040-199-...	Retaner	05.08.2019
Leonardo	205-040-236-...	Washer, Lock	05.08.2019
Leonardo	204-040-600-...	Hanger Assy	05.08.2019
Leonardo	212-010-600-...	Hanger Assy	05.08.2019
Leonardo	212-040-602-...	Shaft Coupling	05.08.2019
Leonardo	206-040-270	FREE-WHEELING ASSY	05.08.2019
Leonardo	206-040-230	FREE-WHEELING ASSY	05.08.2019
Leonardo	206-040-203-3	GEARSHAFT, SPUR	05.08.2019
Leonardo	206-040-241-1	HOUSING ASSY	05.08.2019
Leonardo	206-040-236-13	HOUSING ASSY	05.08.2019
Leonardo	206-040-236-17	HOUSING ASSY	05.08.2019
Leonardo	206-040-270	FREE-WHEELING SHAFT ASSY	05.08.2019
Leonardo	206-040-221-3	SHAFT, SHOULDERED	05.08.2019
Leonardo	206-040-379-101	SHAFT, SHOULDERED	05.08.2019
Leonardo	206-040-268-1	CAP ASSY	05.08.2019
Leonardo	206-040-267-1	FLANGE ASSY	05.08.2019
Leonardo	206-040-222-5	SHAFT, STRAIGHT	05.08.2019
Leonardo	206-010-350-3	PYLON INSTALLATION	05.08.2019
Leonardo	206-010-350-5	PYLON INSTALLATION	05.08.2019
Leonardo	206-010-350-7	PYLON INSTALLATION	05.08.2019
Leonardo	206-010-350-17	PYLON INSTALLATION	05.08.2019
Leonardo	206-010-350-19	PYLON INSTALLATION	05.08.2019
Leonardo	206-010-450-1	SWASHPLATE & SUPPORT	05.08.2019
Leonardo	206-010-450-7	SWASHPLATE & SUPPORT	05.08.2019
Leonardo	206-010-330-7	TUBE ASSY	05.08.2019
Leonardo	206-010-355-9	CONNECTING LINK, RIGID	05.08.2019
Leonardo	206-010-355-19	TUBE ASSY	05.08.2019
Leonardo	206-010-355-11	TUBE	05.08.2019
Leonardo	206-010-335-3	LEVER	05.08.2019
Leonardo	206-010-336-3	LINK	05.08.2019

Leonardo	206-010-336-7	LINK	05.08.2019
Leonardo	206-010-333-3	COLLAR SET	05.08.2019
Leonardo	206-010-333-5	COLLAR SET	05.08.2019
Leonardo	206-011-005-3	COLLAR SET	05.08.2019
Leonardo	206-010-456-1	HOUSING, BEARING UNIT	05.08.2019
Leonardo	206-010-444-1	HOUSING, BEARING UNIT	05.08.2019
Leonardo	206-010-457-1	BEARING, SLEEVE	05.08.2019
Leonardo	206-010-440-1	BEARING SET, SLEEVE	05.08.2019
Leonardo	206-010-455-1	PLATE, RETAINING, BEARING	05.08.2019
Leonardo	206-010-455-103	PLATE, RETAINING, BEARING	05.08.2019
Leonardo	206-010-453-3	RING	05.08.2019
Leonardo	206-010-453-7	RING	05.08.2019
Leonardo	206-010-408-1	PIN, GROOVED, HEADED	05.08.2019
Leonardo	206-010-467-3	LEVER, REMOTE CONTROL	05.08.2019
Leonardo	206-010-407-3	CONNECTING LINK, RIGID	05.08.2019
Leonardo	206-010-454-3	SLEEVE (USABLE ON 206-010-454-1)	05.08.2019
Leonardo	206-010-454-7	SLEEVE (USABLE ON 206-010-454-5)	05.08.2019
Leonardo	206-010-454-111	SLEEVE (USABLE ON 206-010-454-109)	05.08.2019
Leonardo	206-010-459-1	BEARING, SLEEVE	05.08.2019
Leonardo	206-010-451-3	RING (USABLE ON 206-010-451-1)	05.08.2019
Leonardo	206-010-452-3	SUPPORT (USABLE ON 206-010-452-1)	05.08.2019
Leonardo	206-010-452-7	SUPPORT (USABLE ON 206-010-452-5)	05.08.2019
Leonardo	206-010-451-7	RING (USABLE ON 206-010-451-5)	05.08.2019
Leonardo	206-040-400	GEAR BOX ASSY, TAIL ROTOR	05.08.2019
Leonardo	206-040-402	GEAR BOX ASSY, TAIL ROTOR	05.08.2019
Leonardo	206-040-414-1	NUT	05.08.2019
Leonardo	206-040-405-3	GEARSHAFT, MULTIPLE GEARS	05.08.2019
Leonardo	206-040-405-101	GEARSHAFT, SPUR	05.08.2019
Leonardo	206-040-415-1	NUT	05.08.2019
Leonardo	206-040-421-1	NUT	05.08.2019

Leonardo	206-040-424-1	CAP ASSEMBLY	05.08.2019
Leonardo	206-040-427-1	CAP ASSEMBLY	05.08.2019
Leonardo	206-040-437-1	CAP ASSY, GEARBOX	05.08.2019
Leonardo	206-040-406-1	GEAR, BEVEL	05.08.2019
Leonardo	206-040-406-101	GEAR, BEVEL	05.08.2019
Leonardo	206-040-407-7	GEARSHAFT, SPUR	05.08.2019
Leonardo	206-040-439-1	SHAFT, STRAIGHT	05.08.2019
Leonardo	206-040-412-15	CASE	05.08.2019
Leonardo	206-040-425-3	CASE	05.08.2019
Leonardo	206-040-425-15	CASE	05.08.2019
Leonardo	206-040-402-3	GEARBOX ASSY, TAIL ROTOR	05.08.2019
Leonardo	206-040-402-105	GEARBOX ASSY, TAIL ROTOR	05.08.2019
Leonardo	206-040-402-107	GEARBOX ASSY, TAIL ROTOR	05.08.2019
Leonardo	206-040-402-111	GEARBOX ASSY, TAIL ROTOR	05.08.2019
Leonardo	206-040-414-1	NUT	05.08.2019
Leonardo	206-040-440-1	GEAR, BEVEL	05.08.2019
Leonardo	206-040-440-103	GEAR, INPUT PINION	05.08.2019
Leonardo	206-040-415-1	NUT	05.08.2019
Leonardo	206-040-421-1	NUT	05.08.2019
Leonardo	206-040-437-1	CAP ASSY, GEARBOX	05.08.2019
Leonardo	206-040-441-1	GEAR, BEVEL	05.08.2019
Leonardo	206-040-441-103	GEAR, BEVEL	05.08.2019
Leonardo	206-040-439-1	SHAFT, STRAIGHT	05.08.2019
Leonardo	206-040-425-19	HOUSING, MECHANICAL DRIVE	05.08.2019
Leonardo	206-040-425-113	HOUSING, MECHANICAL DRIVE	05.08.2019
Leonardo	206-040-425-133	HOUSING, MECHANICAL DRIVE	05.08.2019
Leonardo	206-040-425-137	HOUSING, MECHANICAL DRIVE	05.08.2019
Leonardo	206-040-002-101	TRANSMISSION INSTALLATION	05.08.2019
Leonardo	206-040-002-105	TRANSMISSION INSTALLATION	05.08.2019
Leonardo	206-040-113-3	PLATE LOCKING	05.08.2019

Leonardo	206-040-078-101	NUT, PLAIN, ROUND	05.08.2019
Leonardo	206-040-062-3	PLATE, RETAINING, BEARING	05.08.2019
Leonardo	206-040-061-1	LINER, BEARING HOUSING	05.08.2019
Leonardo	206-040-002-007	Mast Assembly	05.08.2019
Leonardo	206-040-002-109	Mast Assembly	05.08.2019
Leonardo	206-040-002-111	Mast Assembly	05.08.2019
Leonardo	206-010-332-121	MAST ASSY, MAIN ROTOR	05.08.2019
Leonardo	206-040-100-11	DRIVESHAFT ASSEMBLY, TRANSMISSION	05.08.2019
Leonardo	206-040-102-3	PLATE, RETAINER	05.08.2019
Leonardo	206-040-102-101	PLATE, RETAINER	05.08.2019
Leonardo	206-040-102-103	COVER	05.08.2019
Leonardo	206-040-117-1	COUPLING	05.08.2019
Leonardo	206-040-117-3	COUPLING	05.08.2019
Leonardo	206-040-108-5	COUPLING	05.08.2019
Leonardo	206-040-118-1	COUPLING	05.08.2019
Leonardo	206-040-110-101	SHAFT	05.08.2019
Leonardo	206-040-015-101	DRIVESHAFT INSTL, TRANSMISSION	05.08.2019
Leonardo	206-040-117-3	COUPLING	05.08.2019
Leonardo	206-040-118-1	COUPLING	05.08.2019
Leonardo	206-040-110-101	SHAFT	05.08.2019
Leonardo	206-011-801-11	HUB AND BLADE ASSEMBLY	05.08.2019
Leonardo	206-011-810-1	HUB AND BLADE ASSEMBLY	05.08.2019
Leonardo	206-011-810-117	HUB AND BLADE ASSEMBLY	05.08.2019
Leonardo	206-011-814-1	HOUSING ASSY	05.08.2019
Leonardo	206-011-814-9	HOUSING ASSEMBLY	05.08.2019
Leonardo	206-011-814-113	HOUSING ASSY	05.08.2019
Leonardo	206-011-814-3	HOUSING	05.08.2019
Leonardo	206-011-814-11	HOUSING	05.08.2019
Leonardo	206-011-811-1	YOKE ASSY, TAIL ROTOR	05.08.2019
Leonardo	206-011-811-9	YOKE ASSY, TAIL ROTOR	05.08.2019

Leonardo	206-011-819-101	YOKE ASSY, TAIL ROTOR	05.08.2019
Leonardo	206-011-819-105	YOKE ASSY, TAIL ROTOR	05.08.2019
Leonardo	206-011-811-5	YOKE ASSY, TAIL ROTOR	05.08.2019
Leonardo	206-011-811-3	YOKE	05.08.2019
Leonardo	206-011-811-7	YOKE	05.08.2019
Leonardo	206-011-811-11	YOKE	05.08.2019
Leonardo	206-011-819-103	YOKE	05.08.2019
Leonardo	206-011-819-107	YOKE	05.08.2019
Leonardo	206-011-812-3	TRUNNION	05.08.2019
Leonardo	206-011-810-...	HUB AND BLADE ASSY, TAIL ROTOR	05.08.2019
Leonardo	206-011-810-119	HUB, TAIL ROTOR	05.08.2019
Leonardo	206-011-810-125	HUB, TAIL ROTOR	05.08.2019
Leonardo	206-011-812-5	TRUNNION ASSEMBLY	05.08.2019
Leonardo	206-011-811-9	YOKE ASSY, TAIL ROTOR	05.08.2019
Leonardo	206-011-819-101	YOKE ASSY, TAIL ROTOR	05.08.2019
Leonardo	206-011-819-105	YOKE ASSY, TAIL ROTOR	05.08.2019
Leonardo	206-011-819-109	YOKE ASSY, TAIL ROTOR	05.08.2019
Leonardo	206-010-701	TAIL ROTOR HUB	05.08.2019
Leonardo	206-011-810-117	HUB AND BLADE ASSEMBLY	05.08.2019
Leonardo	206-010-776-3	TRUNNION	05.08.2019
Leonardo	206-010-788-1	YOKE ASSY	05.08.2019
Leonardo	206-010-788-3	YOKE	05.08.2019
Leonardo	206-011-801	TAIL ROTOR HUB	05.08.2019
Leonardo	206-011-805-1	HOUSING	05.08.2019
Leonardo	206-011-805-3	LINER, BEARING HOUSING	05.08.2019
Leonardo	206-011-803-3	TRUNNION	05.08.2019
Leonardo	206-011-803-7	TRUNNION	05.08.2019
Leonardo	206-011-802-1	YOKE ASSEMBLY	05.08.2019
Leonardo	206-011-811-9	YOKE ASSY, TAIL ROTOR	05.08.2019
Leonardo	206-011-819-105	YOKE ASSY, TAIL ROTOR	05.08.2019

Leonardo	206-011-802-3	YOKE	05.08.2019
Leonardo	206-011-810-003	TAIL ROTOR HUB	05.08.2019
Leonardo	206-011-810-009	TAIL ROTOR HUB	05.08.2019
Leonardo	206-011-810-015	TAIL ROTOR HUB	05.08.2019
Leonardo	206-011-810-119	TAIL ROTOR HUB	05.08.2019
Leonardo	206-040-010-5	GEAR ASSY, PLANETARY	05.08.2019
Leonardo	206-040-010-101	GEAR ASSY, PLANETARY	05.08.2019
Leonardo	206-040-010-103	GEAR ASSY, PLANETARY	05.08.2019
Leonardo	206-040-146-1	GEAR, SPUR	05.08.2019
Leonardo	206-040-146-103	GEAR, SPUR	05.08.2019
Leonardo	204-040-129-1	RETAINER, ROLLER, BEARING	05.08.2019
Leonardo	206-040-140-9	WEB	05.08.2019
Leonardo	206-040-140-5	WEB	05.08.2019
Leonardo	206-040-002-...	TRANSMISSION , MECHANICAL, HELICOPTER	05.08.2019
Leonardo	206-010-100	HUB ASSEMBLY, MAIN ROTOR	05.08.2019
Leonardo	206-011-119-1	NUT, SELF-LOCKING, HEXAGON	05.08.2019
Leonardo	206-011-119-101	NUT, SELF-LOCKING, HEXAGON	05.08.2019
Leonardo	206-010-154-1	WASHER, FLAT	05.08.2019
Leonardo	206-010-154-3	WASHER	05.08.2019
Leonardo	206-010-152-1	BOLT, INTERNALLY RELIEVED BODY	05.08.2019
Leonardo	206-010-152-3	BOLT, INTERNALLY RELIEVED BODY	05.08.2019
Leonardo	206-011-108-1	RESERVOIR	05.08.2019
Leonardo	206-010-341-1	BEARING ASSY	05.08.2019
Leonardo	206-010-341-3	CARTRIDGE	05.08.2019
Leonardo	206-010-121-5	BLADE LATCH	05.08.2019
Leonardo	206-010-169-1	BOLT	05.08.2019
Leonardo	206-011-260-103	BOLT	05.08.2019
Leonardo	206-010-102-9	GRIP ASSEMBLY	05.08.2019
Leonardo	206-010-102-117	GRIP ASSEMBLY	05.08.2019
Leonardo	206-010-134-1	BUFFER	05.08.2019

Leonardo	206-010-135-1	PITCH HORN	05.08.2019
Leonardo	206-010-105-3	STRAP	05.08.2019
Leonardo	206-011-147-1	STRAP	05.08.2019
Leonardo	206-2120-01-101	STRAP	05.08.2019
Leonardo	206-011-147-5	STRAP	05.08.2019
Leonardo	206-011-154-101	STRAP	05.08.2019
Leonardo	206-011-154-105	STRAP	05.08.2019
Leonardo	206-2120-01-101	STRAP	05.08.2019
Leonardo	206-010-155-7	FITTING ASSY	05.08.2019
Leonardo	206-010-113-5	SPACER, RING	05.08.2019
Leonardo	206-011-109-1	STOP, STATIC	05.08.2019
Leonardo	206-011-160-101	STOP, STATIC	05.08.2019
Leonardo	206-011-102-5	SPACER, PLATE	05.08.2019
Leonardo	206-011-102-121	SPACER, PLATE	05.08.2019
Leonardo	206-011-113-1	TRUNNION	05.08.2019
Leonardo	206-011-113-103	TRUNNION	05.08.2019
Leonardo	206-010-101-5	YOKE ASSY	05.08.2019
Leonardo	206-010-101-13	YOKE ASSY	05.08.2019
Leonardo	206-010-101-21	YOKE ASSY	05.08.2019
Leonardo	206-010-101-125	YOKE ASSY	05.08.2019
Leonardo	206-010-101-129	YOKE ASSY	05.08.2019
Leonardo	206-011-100-5	HUB, ROTOR, HELICOPTER	05.08.2019
Leonardo	206-011-100-7	HUB, ROTOR, HELICOPTER	05.08.2019
Leonardo	206-011-100-11	HUB, ROTOR, HELICOPTER	05.08.2019
Leonardo	206-011-100-17	HUB, ROTOR, HELICOPTER	05.08.2019
Leonardo	206-011-100-133	HUB ASSEMBLY, MAIN ROTOR	05.08.2019
Leonardo	206-011-100-021	HUB ASSEMBLY, MAIN ROTOR	05.08.2019
Leonardo	206-011-100-127	HUB ASSEMBLY, MAIN ROTOR	05.08.2019
Leonardo	206-011-100-133	HUB ASSEMBLY, MAIN ROTOR	05.08.2019
Leonardo	206-011-100-1021	HUB ASSEMBLY, MAIN ROTOR	05.08.2019

Leonardo	206-011-119-1	NUT, SELF-LOCKING, HEXAGON	05.08.2019
Leonardo	206-010-154-101	WASHER	05.08.2019
Leonardo	206-011-136-1	WASHER, FLAT	05.08.2019
Leonardo	206-010-152-3	BOLT, INTERNALLY RELIEVED BODY	05.08.2019
Leonardo	206-011-135-5	BOLT, INTERNALLY RELIEVED BODY	05.08.2019
Leonardo	206-010-121-5	BLADE LATCH	05.08.2019
Leonardo	206-010-169-3	BOLT	05.08.2019
Leonardo	206-011-122-3	BOLT	05.08.2019
Leonardo	206-011-260-103	BOLT	05.08.2019
Leonardo	206-011-260-103	BOLT	05.08.2019
Leonardo	206-011-105-1	TRUNNION ASSY	05.08.2019
Leonardo	206-011-104-9	PITCH HORN ASSEMBLY	05.08.2019
Leonardo	206-010-123-3	PIN, STRAIGHT, HEADLESS	05.08.2019
Leonardo	206-011-125-105	PIN, STRAIGHT, HEADLESS	05.08.2019
Leonardo	206-011-105-5	STRAP ASSY	05.08.2019
Leonardo	206-011-147-101	STRAP ASSY	05.08.2019
Leonardo	206-011-154-101	STRAP	05.08.2019
Leonardo	206-011-154-105	STRAP	05.08.2019
Leonardo	206-2120-01-101	STRAP	05.08.2019
Leonardo	206-011-147-3	STRAP ASSY	05.08.2019
Leonardo	206-011-147-7	STRAP ASSY	05.08.2019
Leonardo	206-011-154-103	STRAP ASSEMBLY	05.08.2019
Leonardo	206-011-154-107	STRAP	05.08.2019
Leonardo	206-2120-01-103	STRAP	05.08.2019
Leonardo	206-2120-01-101	STRAP	05.08.2019
Leonardo	206-011-124-1	FITTING ASSY	05.08.2019
Leonardo	206-010-113-5	SPACER, RING	05.08.2019
Leonardo	206-011-129-1	RING	05.08.2019
Leonardo	206-011-121-1	STATIC STOP	05.08.2019
Leonardo	206-011-121-103	STOP, STATIC	05.08.2019

Leonardo	206-011-160-101	STOP, STATIC	05.08.2019
Leonardo	206-010-101-21	YOKE ASSY	05.08.2019
Leonardo	206-010-101-129	YOKE ASSEMBLY	05.08.2019
Leonardo	206-011-149-105	YOKE ASSY	05.08.2019
Leonardo	206-010-113-1	TRUNNION	05.08.2019
Leonardo	206-011-113-103	TRUNNION	05.08.2019
Leonardo	206-011-102-11	HOUSING, BEARING UNIT	05.08.2019
Leonardo	206-011-102-117	HOUSING BEARING, UNIT	05.08.2019
Leonardo	206-011-102-119	LOCKING SUPPORT ASSY	05.08.2019
Leonardo	206-011-100-145	HUB ASSY, MAIN ROTOR	05.08.2019
Leonardo	206-011-100-1145	HUB ASSY, MAIN ROTOR	05.08.2019
Leonardo	206-011-119-5	NUT, SELF-LOCKING, HEXAGON	05.08.2019
Leonardo	206-011-119-101	NUT, SELF-LOCKING, HEXAGON	05.08.2019
Leonardo	206-011-136-1	WASHER, FLAT	05.08.2019
Leonardo	206-011-135-5	BOLT, INTERNALLY RELIEVED BODY	05.08.2019
Leonardo	206-011-135-105	BOLT ASSY	05.08.2019
Leonardo	206-010-121-5	BLADE LATCH	05.08.2019
Leonardo	206-011-260-103	BOLT	05.08.2019
Leonardo	206-011-132-9	GRIP ASSY	05.08.2019
Leonardo	206-011-132-113	GRIP ASSY	05.08.2019
Leonardo	206-011-105-1	TRUNNION ASSY	05.08.2019
Leonardo	206-011-104-9	PITCH HORN ASSEMBLY	05.08.2019
Leonardo	206-011-125-105	PIN, STRAIGHT, HEADLESS	05.08.2019
Leonardo	206-011-147-3	STRAP ASSY	05.08.2019
Leonardo	206-2120-01-103	STRAP	05.08.2019
Leonardo	206-011-154-107	STRAP	05.08.2019
Leonardo	206-2120-01-103	STRAP	05.08.2019
Leonardo	206-011-150-105	FITTING ASSY	05.08.2019
Leonardo	206-011-126-1	RING	05.08.2019
Leonardo	206-011-160-101	STOP, STATIC	05.08.2019

Leonardo	206-011-102-117	HOUSING BEARING, UNIT	05.08.2019
Leonardo	206-011-102-119	LOCKING SUPPORT ASSY	05.08.2019
Leonardo	206-011-130-3	SEAL RETAINER ASSY	05.08.2019
Leonardo	206-011-113-103	TRUNNION	05.08.2019
Leonardo	206-011-149-105	YOKE ASSY	05.08.2019
Leonardo	212-010-302-...	Lever Assy	05.08.2019
Leonardo	212-010-311-...	Tube Assy	05.08.2019
Leonardo	212-010-300-...	Stabilizer Bar Assy	05.08.2019
Leonardo	204-011-126-001	Ring	05.08.2019
Leonardo	212-010-103-...	Fitting Assy Main Rotor	05.08.2019
Leonardo	212-011-102-...	Yoke Assy Main Rotor	05.08.2019
Leonardo	212-010-403-...	Lever Assy	05.08.2019
Leonardo	212-011-412-101	Sleeve	05.08.2019
Leonardo	212-010-407-...	Scissor Assy	05.08.2019
Leonardo	212-040-005-...	Driveshaft Assy	05.08.2019
Leonardo	212-040-687-...	Coupling	05.08.2019
Leonardo	212-040-688-...	Coupling	05.08.2019
Leonardo	212-040-686-...	Driveshaft Assy	05.08.2019
Leonardo	204-010-115-...	Nut	05.08.2019
Leonardo	212-040-147-...	Slinger	05.08.2019
Leonardo	212-040-001-...	Transmission Assy	05.08.2019
Leonardo	212-040-059-...	Case Assy	05.08.2019
Leonardo	212-040-053-...	Case Assy	05.08.2019
Leonardo	212-040-783-...	Nut	05.08.2019
Leonardo	212-040-789-...	Spacer	05.08.2019
Leonardo	204-040-785-...	Spider Assy	05.08.2019
Leonardo	412-040-785-...	Spider Assy	05.08.2019
Leonardo	212-040-782-...	Bolt	05.08.2019
Leonardo	212-040-054-...	Case Assy Transmission	05.08.2019
Leonardo	212-040-363-...	Quill Assy, Main Input	05.08.2019

Leonardo	212-040-263-...	Quill Assy, Main Input	05.08.2019
Leonardo	212-040-197-...	Shaft	05.08.2019
Leonardo	212-040-364-...	Race	05.08.2019
Leonardo	212-040-367-...	Race	05.08.2019
Leonardo	204-010-700-...	Pinnion	05.08.2019
Leonardo	212-040-365-...	Quill Assy, Hydraulic Drive singel Boost	05.08.2019
Leonardo	214-040-097-...	Sleeve Assy	05.08.2019
Leonardo	209-040-142-...	Cap Assy	05.08.2019
Leonardo	212-040-190-...	Adapter	05.08.2019
Leonardo	212-040-149-...	Gear Assy	05.08.2019
Leonardo	212-040-208-...	Quill Assy, Offset Accessory and Tail Rotor Drive	05.08.2019
Leonardo	212-040-201-...	Gear	05.08.2019
Leonardo	212-040-203-...	Sleeve Assy	05.08.2019
Leonardo	212-040-365-...	Quill Assy, Accesory and Tail Rotor Drive	05.08.2019
Leonardo	212-040-154-...	Sleeve Assy	05.08.2019
Leonardo	212-040-153-...	Nut	05.08.2019
Leonardo	212-040-150-...	Pinion	05.08.2019
Leonardo	212-040-365-...	Quill Assy, Tail Rotor	05.08.2019
Leonardo	212-040-151-...	Gear Assy	05.08.2019
Leonardo	212-030-104-...	Lift Link Assy	05.08.2019
Leonardo	412-040-123-...	Quill Assy Rotor Brake	05.08.2019
Leonardo	205-040-301-...	Pinion	05.08.2019
Leonardo	412-040-121-...	Sleeve Assy	05.08.2019
Leonardo	412-040-122-...	Retainer	05.08.2019
Leonardo	209-040-176-...	Spacer Set	05.08.2019
Leonardo	209-040-177-...	Flange	05.08.2019
Leonardo	412-040-177-...	Flange	05.08.2019
Leonardo	205-040-305-...	Nut	05.08.2019
Leonardo	212-040-261-...	Jet Assy	05.08.2019
Leonardo	214-040-721-...	Jet Assy No.6	05.08.2019

Capability List

Chapter 4.1: Dynamic + Hydraulic Components



Leonardo	212-040-221-...	Jet Assy	05.08.2019
Leonardo	212-010-706-...	Nut	05.08.2019
Leonardo	212-010-775-...	Crosshead	05.08.2019
Leonardo	212-010-709-...	Bellcrank	05.08.2019
Leonardo	212-010-712-...	Link Assy	05.08.2019
Leonardo	212-011-710-...	Link Assy	05.08.2019
Leonardo	212-010-739-...	Support	05.08.2019
Leonardo	209-011-710-...	Tube Assy	05.08.2019
Leonardo	212-010-744-...	Yoke Assy T/R	05.08.2019
Leonardo	212-010-704-...	Yoke Assy T/R	05.08.2019
Leonardo	212-010-738-...	Trunnion Set	05.08.2019
Leonardo	212-040-600-...	Hanger Assy	05.08.2019
Leonardo	212-040-602-...	Shaft Coupling	05.08.2019
Leonardo	212-010-614-...	Coupling	05.08.2019
Leonardo	201-040-616-...	Plate	05.08.2019
Leonardo	212-040-003-...	Gearbox Assy 42 Degree	05.08.2019
Leonardo	212-040-500-...	Bevel Gear	05.08.2019
Leonardo	212-040-502-...	Sleeve Assy	05.08.2019
Leonardo	212-040-004-...	Gear Box Assy Tail Rotor Drive	05.08.2019
Leonardo	212-040-452-...	Sleeve Assy	05.08.2019
Leonardo	212-040-462-...	Shaft	05.08.2019
Leonardo	212-040-451-...	Gear	05.08.2019
Leonardo	212-040-468-...	Case Assy	05.08.2019
Leonardo	212-040-457-...	Spacer Assy	05.08.2019
Leonardo	212-040-458-...	Nut	05.08.2019
Leonardo	212-040-459-...	Sleeve	05.08.2019
Leonardo	212-040-450-...	Pinion	05.08.2019
Leonardo	212-540-002-...	Transmission Assy	25.06.2021
Leonardo	412-010-400-109	ROTATING CONTROLS INST, MAIN ROTOR	05.08.2019
Leonardo	412-010-400-111	ROTARY CONTROLS INSTL, MAIN ROTOR	05.08.2019

Leonardo	412-010-425-113	CONNECTING LINK, RIGID	05.08.2019
Leonardo	412-010-425-129	TUBE ASSY	05.08.2019
Leonardo	412-010-408-101	LEVER ASSY, COLLECTIVE	05.08.2019
Leonardo	412-040-601-101	COUPLING ASSY	05.08.2019
Leonardo	412-040-102-103	COVER	05.08.2019
Leonardo	412-040-626-101	JOINT	05.08.2019
Leonardo	412-040-628-101	SLEEVE	05.08.2019
Leonardo	412-040-627-101	FLANGE	05.08.2019
Leonardo	214-040-604-105	JOINT	05.08.2019
Leonardo	412-040-601-105	COUPLING ASSY	05.08.2019
Leonardo	412-040-601-107	COUPLING ASSY	05.08.2019
Leonardo	412-040-626-101	JOINT	05.08.2019
Leonardo	412-040-628-101	SLEEVE	05.08.2019
Leonardo	412-040-618-101	SUPPORT	05.08.2019
Leonardo	412-040-631-101	FLANGE	05.08.2019
Leonardo	412-040-600-101	T/R Driveshaft Hangers	05.08.2019
Leonardo	412-040-600-103	T/R Driveshaft Hangers	05.08.2019
Leonardo	412-040-634-101	FLANGE	05.08.2019
Leonardo	412-040-617-101	SUPPORT	05.08.2019
Leonardo	412-040-631-101	FLANGE	05.08.2019
Leonardo	412-010-100-175	HUB ASSY, MAIN ROTOR	05.08.2019
Leonardo	412-010-100-181	HUB ASSY, MAIN ROTOR	05.08.2019
Leonardo	412-010-100-195	HUB ASSY, MAIN ROTOR	05.08.2019
Leonardo	412-010-100-209	HUB ASSY, MAIN ROTOR	05.08.2019
Leonardo	412-010-100-217	HUB ASSY, MAIN ROTOR	05.08.2019
Leonardo	412-010-186-101	STOP	05.08.2019
Leonardo	412-010-186-103	STOP	05.08.2019
Leonardo	412-010-177-101	PLATE ASSY	05.08.2019
Leonardo	412-010-167-105	PLATE ASSY	05.08.2019
Leonardo	412-010-177-105	PLATE ASSY	05.08.2019

Leonardo	412-010-177-117	PLATE ASSY	05.08.2019
Leonardo	412-018-056-103	CONE SEAT, LOWER	05.08.2019
Leonardo	412-018-056-105	CONE SEAT, LOWER	05.08.2019
Leonardo	412-010-166-101	BUSHING, SLEEVE	05.08.2019
Leonardo	412-018-059-105	ARM, BALANCING	05.08.2019
Leonardo	412-018-060-111	CAM, CONTROL	05.08.2019
Leonardo	412-010-206-103	CAM, CONTROL	05.08.2019
Leonardo	412-010-124-105	BOLT ASSY, SPECIAL	05.08.2019
Leonardo	412-010-124-109	BOLT ASSY, SPECIAL	05.08.2019
Leonardo	412-010-137-103	BOLT, MACHINE	05.08.2019
Leonardo	SL54020-35	PIN, GROUND SAFETY	05.08.2019
Leonardo	412-010-216-107	ARM ASSY AND BEARING	05.08.2019
Leonardo	412-010-216-105	ARM ASSY AND BEARING	05.08.2019
Leonardo	412-010-218-101	WEIGHT	05.08.2019
Leonardo	412-010-215-101	BRACKET ASSY	05.08.2019
Leonardo	412-010-264-101	BRACKET ASSY	05.08.2019
Leonardo	412-010-214-101	BRACKET ASSY	05.08.2019
Leonardo	412-010-264-105	BRACKET ASSY	05.08.2019
Leonardo	412-010-217-101	ARM ASSY	05.08.2019
Leonardo	412-010-263-101	ARM ASSY	05.08.2019
Leonardo	412-010-100-177	YOKE AND SPINDLE ASSY, MAIN ROTOR	05.08.2019
Leonardo	412-010-100-183	YOKE AND SPINDLE ASSY, MAIN ROTOR	05.08.2019
Leonardo	412-010-100-207	YOKE AND SPINDLE ASSY, MAIN ROTOR	05.08.2019
Leonardo	412-010-100-215	YOKE AND SPINDLE ASSY, MAIN ROTOR	05.08.2019
Leonardo	412-010-149-111	LEVER ASSY, PITCH CONTROL	05.08.2019
Leonardo	412-010-183-105	BRIDGE ASSY	05.08.2019
Leonardo	412-010-185-109	BRIDGE ASSY	05.08.2019
Leonardo	412-010-183-109	BRIDGE ASSY	05.08.2019
Leonardo	412-018-068-101	BRIDGE ASSY	05.08.2019
Leonardo	412-010-170-105	BRIDGE ASSY	05.08.2019

Leonardo	412-018-068-105	BRIDGE ASSY, DAMPER	05.08.2019
Leonardo	412-010-145-103	MOUNT RESILIENT	05.08.2019
Leonardo	412-010-145-105	MOUNT RESILIENT	05.08.2019
Leonardo	412-310-146-101	MOUNT RESILIENT	05.08.2019
Leonardo	412-310-146-103	MOUNT RESILIENT	05.08.2019
Leonardo	412-010-190-103	SPINDLE AND DAMPER BEARING ASSY	05.08.2019
Leonardo	412-010-190-105	SPINDLE AND DAMPER BEARING ASSY	05.08.2019
Leonardo	412-010-106-101	BEARING, CONICAL	05.08.2019
Leonardo	412-010-111-103	BEARING, PIVOT FITTING	05.08.2019
Leonardo	412-010-111-101	BEARING, PIVOT FITTING	05.08.2019
Leonardo	412-010-101-127	YOKE ASSY (PRE MOD B.T. 412-0749	05.08.2019
Leonardo	412-010-101-129	YOKE ASSY	05.08.2019
Leonardo	412-010-100-139	HUB ASSY, MAIN ROTOR	05.08.2019
Leonardo	412-010-100-151	HUB ASSY, MAIN ROTOR	05.08.2019
Leonardo	412-010-186-101	STOP (PRE MOD.B.T. 412-79)	05.08.2019
Leonardo	412-010-186-103	STOP (POST MOD.B.T. 412-79)	05.08.2019
Leonardo	412-010-177-101	PLATE ASSY (PRE MOD.B.T. 412-79)	05.08.2019
Leonardo	412-010-177-105	PLATE ASSY (POST MOD.B.T. 412-79)	05.08.2019
Leonardo	412-010-177-117	PLATE ASSY (POST MOD.B.T. 412-79)	05.08.2019
Leonardo	412-010-166-101	BUSHING, SLEEVE	05.08.2019
Leonardo	412-018-059-105	ARM, BALANCING	05.08.2019
Leonardo	412-018-060-111	CAM, CONTROL	05.08.2019
Leonardo	412-010-206-103	CAM, CONTROL	05.08.2019
Leonardo	412-010-124-105	BOLT ASSY, SPECIAL	05.08.2019
Leonardo	412-010-124-109	BOLT ASSY, SPECIAL	05.08.2019
Leonardo	412-010-137-103	BOLT, MACHINE	05.08.2019
Leonardo	412-010-218-101	WEIGHT	05.08.2019
Leonardo	412-010-215-101	BRACKET ASSY	05.08.2019
Leonardo	412-010-264-101	BRACKET ASSY	05.08.2019
Leonardo	412-010-214-101	BRACKET ASSY	05.08.2019

Leonardo	412-010-264-105	BRACKET ASSY	05.08.2019
Leonardo	412-010-217-101	ARM ASSY	05.08.2019
Leonardo	412-010-263-101	ARM ASSY	05.08.2019
Leonardo	412-010-100-141	YOKE AND SPINDLE ASSY, MAIN ROTOR	05.08.2019
Leonardo	412-010-100-153	YOKE AND SPINDLE ASSY, MAIN ROTOR	05.08.2019
Leonardo	412-010-100-163	YOKE AND SPINDLE ASSY, MAIN ROTOR	05.08.2019
Leonardo	412-010-100-183	YOKE AND SPINDLE ASSY, MAIN ROTOR	05.08.2019
Leonardo	412-010-100-207	YOKE AND SPINDLE ASSY, MAIN ROTOR	05.08.2019
Leonardo	412-010-100-215	YOKE AND SPINDLE ASSY, MAIN ROTOR	05.08.2019
Leonardo	412-010-149-105	LEVER ASSY, PITCH CONTROL	05.08.2019
Leonardo	412-010-149-111	LEVER ASSY, PITCH CONTROL	05.08.2019
Leonardo	412-010-183-105	BRIDGE ASSY	05.08.2019
Leonardo	412-010-185-109	BRIDGE ASSY	05.08.2019
Leonardo	412-010-183-109	BRIDGE ASSY	05.08.2019
Leonardo	412-010-185-101	BRIDGE ASSY	05.08.2019
Leonardo	412-018-068-101	BRIDGE ASSY	05.08.2019
Leonardo	412-010-170-105	BRIDGE ASSY	05.08.2019
Leonardo	412-018-068-105	BRIDGE ASSY, DAMPER	05.08.2019
Leonardo	412-010-156-105	SPINDLE AND DAMPER BEARING ASSY	05.08.2019
Leonardo	412-010-190-101	SPINDLE AND DAMPER BEARING ASSY	05.08.2019
Leonardo	412-010-190-103	SPINDLE AND DAMPER BEARING ASSY	05.08.2019
Leonardo	412-010-190-105	SPINDLE AND DAMPER BEARING ASSY	05.08.2019
Leonardo	412-010-106-101	BEARING, CONICAL	05.08.2019
Leonardo	412-010-111-103	BEARING, PIVOT FITTING	05.08.2019
Leonardo	412-010-111-101	BEARING, PIVOT FITTING	05.08.2019
Leonardo	412-010-101-123	YOKE ASSY	05.08.2019
Leonardo	412-040-005-103	SHAFT ASSY, INPUT	05.08.2019
Leonardo	214-040-677-1	RETAINER	05.08.2019
Leonardo	204-040-685-1	SPRING, HELICAL, COMPRESSION	05.08.2019
Leonardo	214-040-657-3	Coupling	05.08.2019

Leonardo	204-040-690-1	RETAINER	05.08.2019
Leonardo	214-040-659-5	Coupling, FEMALE	05.08.2019
Leonardo	412-340-102-101	PROTECTION	05.08.2019
Leonardo	212-040-169-101	MANIFOLD ASSY	05.08.2019
Leonardo	204-040-360-105	PLANETARY ASSY, UPPER	05.08.2019
Leonardo	412-040-107-101	ADAPTER, TRANSMISSION	05.08.2019
Leonardo	412-040-109-101	EXTENSION, ADAPTER	05.08.2019
Leonardo	412-040-230-...	Gear	05.08.2019
Leonardo	412-040-362-101	DRIVE ASSY	05.08.2019
Leonardo	412-040-362-103	DRIVE ASSY	05.08.2019
Leonardo	204-040-174-1	COVER ASSY	05.08.2019
Leonardo	212-040-106-105	FITTING	05.08.2019
Leonardo	412-040-134-...	Washer	05.08.2019
Leonardo	412-040-133-101	CAGE	05.08.2019
Leonardo	412-040-785-103	PLANETARY, LOWER	05.08.2019
Leonardo	204-040-784-111	PLANETARY ASSY	05.08.2019
Leonardo	412-040-385-...	Case Assy	05.08.2019
Leonardo	412-040-701-101	GEAR ASSY	05.08.2019
Leonardo	212-040-146-1	MANIFOLD ASSY	05.08.2019
Leonardo	412-040-263-101	QUILL ASSY, MAIN INPUT, TRANSMISSION	05.08.2019
Leonardo	412-040-139-101	PLATE, COVERING	05.08.2019
Leonardo	214-040-914-103	NUT	05.08.2019
Leonardo	412-040-700-101	PINION	05.08.2019
Leonardo	412-040-700-103	PINION	05.08.2019
Leonardo	412-040-136-101	ADAPTOR	05.08.2019
Leonardo	412-040-137-101	NUT, SLEEVE	05.08.2019
Leonardo	412-040-123-101	QUILL ASSY Rotor Brake Quill	05.08.2019
Leonardo	412-040-123-103	QUILL ASSY Rotor Brake Quill	05.08.2019
Leonardo	205-040-305-1	FITTING, FLANGE	05.08.2019
Leonardo	412-040-122-101	STOP	05.08.2019

Capability List

Chapter 4.1: Dynamic + Hydraulic Components



Leonardo	412-040-301-101	GEAR, BEVEL	05.08.2019
Leonardo	412-040-121-107	Sleeve ASSY	05.08.2019
Leonardo	412-040-121-111	Sleeve ASSY	05.08.2019
Leonardo	412-040-121-115	SLEEVE, SEAL, COUPLER	05.08.2019
Leonardo	412-040-302-101	PINION ASSY, SPIRAL	05.08.2019
Leonardo	204-040-393-1	MANIFOLD ASSY, TRANSMISSION	05.08.2019
Leonardo	204-040-368-1	FITTING, LUBRICANT PRESSURE RELIEF	05.08.2019
Leonardo	212-040-201-101	CROWN	05.08.2019
Leonardo	212-040-201-1	GEAR, SPUR	05.08.2019
Leonardo	212-040-202-101	PINION	05.08.2019
Leonardo	212-040-202-3	PINION, SPUR	05.08.2019
Leonardo	212-040-207-1	LINER, BEARING HOUSING	05.08.2019
Leonardo	212-040-203-1	SLEEVE ASSY	05.08.2019
Leonardo	204-040-355-17	CARTER ASSY	05.08.2019
Leonardo	212-040-365-103	QUILL ASSY, HYDRAULIC DRIVE, SINGLE BOOST	05.08.2019
Leonardo	212-040-365-113	DRIVE ASSY, TAIL ROTOR	05.08.2019
Leonardo	412-040-637-101	RETAINER, SPRING	05.08.2019
Leonardo	412-040-624-101	ADAPTER, OUTPUT, TAIL ROTOR DRIVE	05.08.2019
Leonardo	212-040-155-3	FUNNEL	05.08.2019
Leonardo	212-040-151-101	GEAR ASSY, SPIRAL-BEVEL	05.08.2019
Leonardo	212-040-365-23	DRIVE QUILL ASSY	05.08.2019
Leonardo	212-040-365-115	DRIVE QUILL ASSY	05.08.2019
Leonardo	212-040-150-5	GEAR, BEVEL	05.08.2019
Leonardo	212-040-150-101	GEAR, BEVEL	05.08.2019
Leonardo	212-040-153-1	NUT, PLAIN, SPLINE	05.08.2019
Leonardo	212-040-154-1	SLEEVE ASSY	05.08.2019
Leonardo	412-040-004-103	TRANSMISSION ASSY	05.08.2019
Leonardo	412-040-002-103	TRANSMISSION ASSY	05.08.2019
Leonardo	204-040-370-1	MANIFOLD, FLUID, AIRCRAFT	05.08.2019
Leonardo	412-040-263-101	QUILL ASSY, MAIN INPUT, TRANSMISSION	05.08.2019

Leonardo	212-040-470-1	RING, EXTERNALLY THREADED	05.08.2019
Leonardo	412-040-637-101	RETAINER, SPRING	05.08.2019
Leonardo	206-340-401-101	SLEEVE, BLADE	05.08.2019
Leonardo	204-040-422-5	SPACER, SLEEVE	05.08.2019
Leonardo	412-040-366-103	MAST ASSY, MAIN TRANSMISSION	05.08.2019
Leonardo	412-040-366-105	MAST ASSY, MAIN TRANSMISSION	05.08.2019
Leonardo	412-040-366-109	MAST ASSY, MAIN TRANSMISSION	05.08.2019
Leonardo	412-040-366-111	MAST ASSY, MAIN TRANSMISSION	05.08.2019
Leonardo	412-040-366-113	MAST ASSY, MAIN TRANSMISSION	05.08.2019
Leonardo	412-040-366-121	MAST ASSY, MAIN TRANSMISSION	05.08.2019
Leonardo	412-040-515-101	NUT RING	05.08.2019
Leonardo	412-040-519-101	ROTARY, LWR	05.08.2019
Leonardo	412-040-525-101	ROTARY, LWR	05.08.2019
Leonardo	412-040-105-101	RING, METAL, OIL SEAL	05.08.2019
Leonardo	412-040-102-101	HOUSING, BEARING UNIT	05.08.2019
Leonardo	412-040-102-103	HOUSING, BEARING UNIT	05.08.2019
Leonardo	412-340-011-101	O-RING	05.08.2019
Leonardo	412-040-104-101	NUT, ROUND, SPECIAL	05.08.2019
Leonardo	412-040-108-101	RING, LOCK, SERRATED	05.08.2019
Leonardo	412-040-103-101	PLATE ASSY, RETAINING	05.08.2019
Leonardo	412-040-101-125	MAST ASSY, MAIN ROTOR	05.08.2019
Leonardo	412-040-101-129	MAST ASSY, MAIN ROTOR	05.08.2019
Leonardo	412-040-006-101	GEARBOX ASSY, 42 DEGREE	05.08.2019
Leonardo	412-040-006-103	Quill Assy 42 Degree	05.08.2019
Leonardo	412-040-006-105	Quill Assy 42 Degree	05.08.2019
Leonardo	412-040-006-105	QUILL ASSY	05.08.2019
Leonardo	412-040-635-101	JOINT, MALE	05.08.2019
Leonardo	214-040-634-1	HOUSING	05.08.2019
Leonardo	214-040-633-1	SEAL CARRIER	05.08.2019
Leonardo	412-040-636-101	BUSHING	05.08.2019

Leonardo	212-040-514-1	SLEEVE	05.08.2019
Leonardo	212-040-515-1	CONE	05.08.2019
Leonardo	412-040-006-103	QUILL ASSY	05.08.2019
Leonardo	412-040-637-101	RETAINER, SPRING	05.08.2019
Leonardo	412-040-625-101	ADAPTER, GEARBOX, TAIL ROTOR DRIVE	05.08.2019
Leonardo	412-040-638-101	BUSHING	05.08.2019
Leonardo	212-011-710-1	PITCH LINK ASSY	05.08.2019
Leonardo	212-310-701-101	PITCH LINK ASSY	05.08.2019
Leonardo	212-010-711-3	CONNECTING LINK, RIGID	05.08.2019
Leonardo	212-011-705-1	LEVER ASSY	05.08.2019
Leonardo	212-011-713-1	STOP, STATIC	05.08.2019
Leonardo	212-011-713-103	STOP, STATIC	05.08.2019
Leonardo	209-011-710-5	TUBE ASSY, CONTROL	05.08.2019
Leonardo	412-010-401-105	HUB AND SLEEVE ASSY	05.08.2019
Leonardo	412-010-401-109	HUB AND SLEEVE ASSY	05.08.2019
Leonardo	412-010-401-111	HUB AND SLEEVE ASSY	05.08.2019
Leonardo	412-010-401-113	HUB AND SLEEVE ASSY	05.08.2019
Leonardo	412-010-406-115	CONNECTING LINK, RIGID	05.08.2019
Leonardo	412-010-406-117	CONNECTING LINK, RIGID	05.08.2019
Leonardo	412-310-401-101	BRACKET, DOUBLE ANGLE	05.08.2019
Leonardo	412-010-405-107	CONNECTING LINK, RIGID	05.08.2019
Leonardo	412-010-405-109	CONNECTING LINK, RIGID	05.08.2019
Leonardo	412-010-405-111	CONNECTING LINK, RIGID	05.08.2019
Leonardo	412-010-403-113	LEVER ASSY, REPHOSING	05.08.2019
Leonardo	412-010-403-117	LEVER ASSY, REPHOSING	05.08.2019
Leonardo	412-010-403-113	LEVER ASSY, REPHOSING	05.08.2019
Leonardo	412-010-403-117	LEVER ASSY, REPHOSING	05.08.2019
Leonardo	412-010-440-103	FLANGE	05.08.2019
Leonardo	412-010-429-119	PLATE SET	05.08.2019
Leonardo	412-010-445-101	HUB ASSY	05.08.2019

Leonardo	412-040-445-105	HUB ASSY	05.08.2019
Leonardo	412-010-402-107	SWASHPLATE AND SUPPORT ASSY	05.08.2019
Leonardo	412-010-402-109	SWASHPLATE AND SUPPORT ASSY	05.08.2019
Leonardo	412-010-402-111	SWASHPLATE AND SUPPORT ASSY	05.08.2019
Leonardo	412-010-402-113	SWASHPLATE AND SUPPORT ASSY	05.08.2019
Leonardo	204-011-428-3	PLATE, RETAINING, BEARING	05.08.2019
Leonardo	204-011-427-1	PLATE, RETAINING, BEARING	05.08.2019
Leonardo	204-011-427-103	PLATE, RETAINING, BEARING	05.08.2019
Leonardo	412-010-407-105	RING ASSY, OUTER, SWASHPLATE	05.08.2019
Leonardo	412-010-407-117	RING ASSY, OUTER, SWASHPLATE	05.08.2019
Leonardo	412-010-453-105	SUPPORT ASSY	05.08.2019
Leonardo	204-010-433-3	LINER	05.08.2019
Leonardo	412-010-453-101	SUPPORT ASSY	05.08.2019
Leonardo	212-011-709-1	HOUSING ASSY	05.08.2019
Leonardo	212-060-724-11	CONNECTING LINK, RIGID	05.08.2019
Leonardo	212-060-724-13	CONNECTING LINK, RIGID	05.08.2019
Leonardo	209-001-053-1	ROD END, BEARING, PLAIN	05.08.2019
Leonardo	204-061-717-3	BEARING, SPHERICAL, ROD END	05.08.2019
Leonardo	212-001-747-1	BELLCRANK ASSY	05.08.2019
Leonardo	205-001-011-5	CONNECTING LINK, RIGID	05.08.2019
Leonardo	212-001-056-1	CONNECTING LINK, RIGID	05.08.2019
Leonardo	212-001-710-1	BELLCRANK	05.08.2019
Leonardo	205-001-733-5	SUPPORT	05.08.2019
Leonardo	212-001-759-101	BELLCRANK ASSY	05.08.2019
Leonardo	204-001-012-1	CONNECTING LINK, RIGID	05.08.2019
Leonardo	204-001-012-21	CONNECTING LINK, RIGID	05.08.2019
Agusta	109-8412-02-...	Drive Shaft Assy	
Agusta	109-8412-02-1	Drive Shaft Assy	
Agusta	109-8412-02-3	Drive Shaft Assy	
Agusta	206-040-110-...	Shaft	

Agusta	206-0901-01-...	Servo Actuator
AH	B290P0001101	Additional Kit for Pump Drive
AH	B621M3001101	Vibration Absorber
AH	B621M3001103	Vibration Absorber
AH	6920	Solenoid Valve
AH	3700320000	Oil cooler Assy
AH	4639305088	Supporting Tube
AH	105-10113V001	Main Transmission
AHD	105-10157	Transmission Stand Assy LH
AHD	105-10158	Transmission Stand Assy LH
AH	105-131...	Control Rod Assy
AH	105-132...	Drive Rod
AH	105-14101...	Main Rotor Head Assy
AH	105-14102...	Main Rotor Head Assy
AH	105-14103	Main Rotor Head Assy
AH	105-14104	Main Rotor Head
AH	105-141041	Main Gearbox
AH	105-141045	Main Rotor Head
AH	105-14106	Main Rotor Head
AH	105-141081	Main Rotor Head Assy
AH	105-141087	Main Rotor Head Assy
AH	105-141091	Main Rotor Head
AH	105-14181.01	Inner Sleeve
AH	105-15853...	Blade Fitting Assy
AH	105-317...	Tail Rotor Head Assy and components of
AH	105-318...	Tail Rotor Driveshaft
AH	105-31822	Pitch Link Assy
AH	105-319...	Tail Rotor Blade
AH	105-414...	Control Rod
AH	105-419...	Swashplate Assy
AH	105-421..	Control Lever Assy

AH	105-430...	Lever Assy	
AH	105-450...	Tandem Hydraulic Unit	
AH	105-453...	Rod End Assy	
AH	105-455...	Lever	
AH	105-456611	Housing Assy	
AH	105-466...	Bolt	
AH	105-603...	Engine Mount Assy	
AH	105-605...	Control Lever	
AHD	105-60931	Fuel Boost Pump	
AH	105-61704	Oil Tank	
AH	105-73516	Lever Assy	
AH	105-81022...	Shaft	
AH	105-81182	Forked Lever Assy	
AH	105-81807	Emerg. Flotat. Syst. Det. Part	22.02.2019
AH	105-819...	Snow Skid Assy	
AH	105-82766	Ground Handling Wheel	
AH	105-830...	Tandem Hydraulic Unit	
AH	105-84601	Retrofit Hydraulic	
AH	105-98043	Control Rod Lateral	
AH	192-83104-1	Cutter Assembly, Lower	22.02.2019
AH	1120-...	Control Rod Assy	
AH	1120-81024	Vibration Absorber	
AH	1121-13126	M/R Pitch Link	
AH	1121-14102....	Quadruple Nut, upper	
AH	1121-14223	Nuß vollständig / Nut Assy	
AH	1121-23115	Rear Door Support RH	
AH	1121-315...	Shaft Assy	
AH	1121-31730....	Control Lever	
AH	1121-45022	Tandemhydraulic Unit	
AH	117-11170-...	Fitting Assy	

AH	117-11181-...	Stay Assy L/H	
AH	117-11203-...	Rod Assy	
AH	117-1200...	Transmission Assy	
AH	117-120061	Main Transmission	
AH	117-132011....	Bearing Block	
AH	117-132021	Drive Link Assy	
AH	117-132021	Drive Rod Assy	
AH	117-132031....	Bearing Block	
AH	117-132041	Drive Rod Assy	21.08.2019
AH	117-132811	Control Rod Assy	
AH	117-132821	Control Rod Assy	
AH	117-1410...	Main Rotor Head Assy	
AH	117-15854.05	Mounting Fitting Upper Part	22.02.2019
AH	117-15854.06	Mounting Fitting Lower Part	22.02.2019
AH	117-16010-...	Input Shaft Assy	
AH	117-16013-01	Adapter Shaft	
AH	117-31521	Shaft Assy	
AH	117-31542	Shaft Assy	
AH	117-315671	Shaft	
AH	117-317...	Tail Rotor Head Assy	
AH	117-318...	Pitch Link Assy	
AH	117-410271	Trimmer	
AH	117-41126-...	Socket Assy	
AH	117-41175-...	Control Rod Assy	
AH	117-41177-...	Bellcrank Assy	
AH	117-41201-...	Torque Tube Assy	
AH	117-41318-...	Control Rod Assy	
AH	117-41580-...	Push Rod Assy	
AH	117-41613	Pedal Bracket LH	
AH	117-41623	Pedal Bracket RH	

AH	117-41631	Rocking Arm forward Assy
AH	117-41636	Rocking Arm aft Assy
AH	117-41655	Control Rod
AH	117-41904	Swashplate Assy
AH	117-42121-...	Bellcrank Assy
AH	117-421221	Control Fork
AH	117-421231	Control Fork
AH	117-421231	Control Fork
AH	117-42140-01	Bellcrank Assy
AH	117-42175-01	Bellcrank Assy
AH	117-42185-...	Control Rod Assy
AH	117-42270-...	Torsion Bar Assy
AH	117-44115...	Bellcrank Assy
AH	117-441161	Bellcrank Assy
AH	117-44120	Control Rod
AH	117-44125	Control Rod
AH	117-45020	Tandemhydraulic Unit
AH	117-45020V001	Tandemhydraulic Unit
AH	117-45020V002	Tandemhydraulic Unit
AH	117-45029	Tandem Hydraulik Aggregat
AH	117-45029V001	Tandemhydraulic Unit
AH	117-46026	Trimmer Lateral
AH	117-46026	Trimmer Lateral
AH	117-46036	Longitudinal Trimmer
AH	117-50002.11	Skid Protective Plate
AH	117-501031 L/H SIDE	Skid Tube Assy
AH	117-501031 R/H SIDE	Skid Tube Assy
AH	117-62859-...	Link
AH	117-63429-09	Schwenkarm Assy
AHD	117-63499-03	Override Spring Assy

Capability List

Chapter 4.1: Dynamic + Hydraulic Components



AHD	117-72590-01	Tube Assy
AH	117-67171-...	Oil Tank Assy
AH	117-68021-...	Cooling Fan Assy
AH	117-68021-03	Cooling Fan Assy RH
AH	117-72590-01	Tube Assy
AH	117-80127	Load Hook Detachable Part
AH	117-80166	Vibration Absorber
AH	117-80166V001	Vibration Absorber
AH	117-80168	Vibration Absorber
AH	117-80170	Vibration Absorber
AH	117-80170V001	Vibration Absorber
AH	117-80180	Vibration Absorber
AH	117-80180V001	Vibration Absorber
AH	117-801841	Vibration Absorber
AH	117-804021	Rescue Hoist, removable Part
AH	117-804031	Rescue hoist arm assy
AH	117-81121-...	Control Rod Assy
AH	117-84109	Settling Protector Detach. Part
AH	117-88659	Bellcrank Assy
AH	117-88810	Transducer
AH	117-89295-07	Washer & Hinge
AH	117-892961.03	Washer & Hinge
AH	117-892971.03	Washer & Hinge
AH	19E143-...	Bendix Coupling
AH	19E144-...	Bendix Driveshaft
AH	19E145-...	Bendix Driveshaft
AH	19E146-...	Bendix Driveshaft
AH	19E293-...	Bendix Driveshaft
AH	419-210	Brake Head Assy
AH	4-301-213-01	Cable

Capability List

Chapter 4.1: Dynamic + Hydraulic Components



AHD	4619-003-	T/R Gearbox		
AHD	4619-003-003	T/R Gearbox		
AH	4619-005-...	Fan Transmission		
AH	4638-001-...	Transmission Assy		
AH	4639 002 ...	Intermediate Gearbox		
AH	4639 003 ...	Tail RotorGearbox		
AH	7051A36420...	Bolt		
AH	7051A3642029	Bolt		
AH	7051A3642030	Bolt		
AH	76378-200	Hoist		
AH	AC67032	Servo Commande		
AH	AC67244	Servo Commande		
AH	AH037866	Bush Friction		
AH	AHA1121	Rotor Brake		
AH	AHA1121MOD-...	Rotor Brake		
AH	B0223-2	Rotor Brake Caliper Assy		
AH	B281M8825103	Fuel Tank	Limited to work i.a.w. AMM	22.02.2019
AH	B304M2009101	Gearbox		
AH	B321M1003201	Skid Tube Assy RH		
AH	B321M4011101	Skid Tube Assy RH		
AH	B321M4011966	EFS Skid Tube RH Pilot Holes		22.02.2019
AH	B521M3834966	Car Upper		
AH	B622M1002101	Main Rotor Head Assy		
AH	B623M2002101	Swashplate		
AH	B623M2002102	Swashplate		
AH	B623M4001104	Drive Rod Assy		
AH	B623M4002101	Driving Link Tube Assy		
AH	B623M4002101	Driving Link Tube		
AH	B633K1181-101	Rod Assy LH		
AH	B633K1182-102	Strebe		

AH	B633K1203-101	Rod Assy	
AH	B635M1804101	Lever complete	
AH	B635M1804102	Lever complete	20.05.2020
AH	B635M1809101	Brake Cylinder Complete	
AH	B621M1001...	Blade Fittings	
AH	B642M1002...	Tail Rotor Head	
AH	B642M1002102	Tail Rotor Head	
AH	B642M1002103	Tail Rotor Head	
AH	B642M1002104	Tail Rotor Head	
AH	B642M1002105	Tail Rotor Head	
AH	B642M1002106	Tail Rotor Head	
AH	B642M1002107	Tail Rotor Head	
AH	B642M1003...	Blade Mounting Fork Assy	
AHD	B651M1001...	Drive Shaft Assy	
AH	B642M1018102	Pitch Link Assy	22.02.2019
AH	B651M1001101	Drive Shaft Assy	
AHD	B651M1002...	Drive Shaft Assy	
AH	B651M1003101	Shaft Assy	
AH	B651M1003101	Shaft Assy	
AH	B651M1005101	Shaft	
AH	B652M2002...	Tail Rotor XMSN Assy	
AH	B670M5001101	Duplex SEMA-Control Rod	
AH	B670M7003101	Bellcrank	
AH	B670M7004101	Bellcrank	
AH	B671M7005101	Bearing Block Assy	28.04.2021
AH	B670M7020101	Bellcrank Assy	
AH	B670M7021101	Bellcrank	
AH	B671M7018102	Fork Lever Assy	21.08.2019
AH	B671M7016101	Bearing Block Assy	28.04.2021
AH	B671M7016102	Bearing Block Assy	28.04.2021

AH	B716M1050101	IBF Filter	
AH	B761K2110-101	Override Spring Assy	
AH	B851M1002051	Cargo Hook	
AH	B851M1002053	Cargo Hook	
AH	B851M2012052	Greifring	
AH	CD00279-2D100	Actuator	
AHD	D105102	Fuel Boost Pump	
AH	D183M20X1102	Landing Gear Damper Assy	
AH	D621M1001102	Blade Fitting, Pair of	
AH	D622M1001103	Main Rotor Head	
AH	D623M2002103	Swash Plate	
AH	D652M2210202	Output Pinion	
AH	D652M2001101	Tail Gearbox	
AH	D652M2001102	Tail Gearbox	
AH	D623M4001101	Drive Rod Assy	21.08.2019
AHD	D623M4005101	Fork Link Assy	18.02.2021
AHD	D670M5002101	Duplex SEMA-Control Rod	17.05.2021
AHD	D671M6001104	Shaft collective	10.08.2020
AHD	D671M7018101	Forked Lever Assy	18.02.2021
AH	HELI1000	High Density Seat	
AHD	L009M6232881	Sliding Sleeve Preassy	10.08.2020
AHD	L009M6233881	Sliding Sleeve Preassy	10.08.2020
AHD	L009M6234881	Sliding Sleeve Preassy	10.08.2020
AH	L023A0642221	Chinese Weight Bushing	
AH	L210M1811101	Verdampfermodul	
AH	L210M1872105	Bearing shaft block	
AH	L210M1872107	Bearing shaft block	20.05.2020
AH	L210M1872886	Bearing shaft block	
AH	L221M0002102	Transducer	
AH	L304M2805101	Gearbox Assy 90°	

AH	L321P1002...	Transportrad	
AH	L321P1003101	Transportrad / Ground Handling Wheel	
AH	L327M4828101	Settling Protector, RH	
AH	L535A20000052	Tailboom	
AH	L623M2004101	Bearing Ring	
AH	L623M2005...	Swashplate Assy	
AH	E623M2005...	Swashplate Assy	
AH	L623M2006101	Sleeve Assy	
AH	L623M2006103	Sleeve Assy	
AH	L623M4001103	Driving Unit	21.08.2019
AH	L623M4002104	Helical Tube	
AH	L623M4002208	Helical Tube	
AH	L623M4003...	Spiralhebel / Helical Lever	
AH	L632M10019...	Main Gearbox Assy	Limited to work i.a.w. AMM
AH	L632M10029...	Main Gearbox Assy	Limited to work i.a.w. AMM
AH	L632M1003...	Rotor Hub-Shaft Assy with SGB	
AH	L632M1006...	Rotor Hub-Shaft Assy with SGB (ZFL)	
AH	L632M10A1...	Main transmission	Limited to work i.a.w. AMM
AH	L632M10A2...	Main transmission	Limited to work i.a.w. AMM
AH	L633M2001105MOD9	Z-Aris	
AH	L633M2001106	Z-Aris	
AH	L633M2001106MOD9	Z-Aris	
AH	L633M2010101	Z-Aris	
AH	L633M2010101MOD8	Z-Aris	
AH	L633M2010101MOD9	Z-Aris	
AH	L633M2010102MOD10	Z-Aris	
AH	L633M2010102MOD9	Z-Aris	
AH	L633M2010103	Z-Aris	
AH	L633M2010103MOD10	Z-Aris	
AH	L633M2010103MOD7	Z-Aris	

AH	L633M2010103MOD9	Z-Aris	
AH	L633M2010104MOD6	Z-Aris	
AH	L633M2010104MOD9	Z-Aris	
AH	L633M2010104MOD9	Z-Aris	
AH	L633M2010105MOD10	Z-Aris	
AH	L633M2010107	Z-Aris	
AH	L633M2010107MOD10	Z-Aris	
AH	L633M2010108	Z-Aris	
AH	L633M2010109	Z-Aris	
AH	L633M2010109	Z-Aris	
AH	L633M2016101	Z-Aris	
AH	L633M2017101	Z-Aris	
AH	L635M1010101	Lever Assy	
AH	L642A0101052	Tail Ro+C2709tor Head Assy	
AH	L642A0101053	Tail Rotor Head Assy	21.01.2021
AH	L642A2001054	Tail Rotor Head Assy	20.05.2020
AH	L642A2002...	Blade Assy	
AH	L642A2003102	Body Hub Assy	
AH	L642A2017603	Bushing	
AH	L642A2018601	Bushing	
AH	L642A2020202	Attach Ring	21.05.2021
AH	L642A2021201	Bushing	
AH	L642A2028102	Fairing Assy	22.02.2019
AH	L642A2035201	Bushing	
AH	L642A2036201	Anti Buckling	22.02.2019
AH	L642A2037201	Anti Buckling	22.02.2019
AH	L651M2008101	Shaft Long Assy	
AH	L662C1021102	Hub Cap Support	
AH	L671M3009102	Control Rod	
AH	L671M3011...	Lever	
AH	L671M3012101	Forked Lever	
AH	L671M3012102	Forked Lever	21.08.2019

AH	L671M3012201	Forked Lever		
AH	L671M3013...	Bearing Block		
AH	L671M7003103	Hinged		
AH	L671M7003210	Hinged Support		
AH	L671M7007102	Mixing Lever Gear Unit		22.02.2019
AH	L673M20A1005	Main rotor actuator	Limited to EASB EC135-67A-039	17.04.2019
AH	L673M30A2011	Main rotor actuator	Limited to EASB EC135-67A-039	17.04.2019
AH	L673M30A2001	Main rotor actuator	Limited to EASB EC135-67A-039	17.04.2019
AH	L673M20A1008	Longitudinal single-axis actuator	Limited to EASB EC135-67A-039	17.04.2019
AH	L673M30A2111	Longitudinal single-axis actuator	Limited to EASB EC135-67A-039	17.04.2019
AH	L673M20A1012	Collective single-axis actuator	Limited to EASB EC135-67A-039	17.04.2019
AH	L673M30A1211	Collective single-axis actuator	Limited to EASB EC135-67A-039	17.04.2019
AH	L673M30A1201	Collective single-axis actuator	Limited to EASB EC135-67A-039	17.04.2019
AH	L673M20A1011	Lateral single-axis actuator	Limited to EASB EC135-67A-039	17.04.2019
AH	L673M30A2111	Lateral single-axis actuator	Limited to EASB EC135-67A-039	17.04.2019
AH	L712M1006102	V-Strut		
AH	L712M1006103	V-Strut		
AH	L712M1008103	Strut Assy		
AH	L792M3004105	Fan L/H		
AH	L792M3005105	Fan L/H		
AH	L792M3004106	Fan R/H		21.05.2019
AH	L792M3005106	Fan L/H		21.05.2019
AH	L792M3032101	Air Albow Assy RH		
BHT	23069751	Rear Mount		
BHT	41000657	Trunnion		
BHT	02W101633	Filter		
BHT	20-057-12-29	Bolt		
BHT	20-065H08-...	Bolt		
BHT	204-001-042-1	Force Gradement		
BHT	204-001-148-001	Bellcrank Assy		
BHT	204-001-855-...	Lever Assy		

BHT	204-001-954-...	Support Assy
BHT	204-001-957-...	Control Tube
BHT	204-010-404-...	Gimbal Ring
BHT	204-010-433-...	Liner
BHT	204-010-481-...	Nut (Mast)
BHT	204-010-925-...	Tube Assy
BHT	204-010-937-...	Damper Assy
BHT	204-011-108-...	Pillow Block
BHT	204-011-121-...	Grip Assy M/R
BHT	204-011-125-...	Plate Assy
BHT	204-011-127-...	Link Assy
BHT	204-011-128-...	Universal
BHT	204-011-140-...	Drag Brace Assy
BHT	204-011-301-...	Lever Assy
BHT	204-011-326-...	Stabilizer Bar Assy
BHT	204-011-400-...	Swashplate and Support Assy
BHT	204-011-401-...	Scissors and Sleeve Assy
BHT	204-011-402-...	Inner Ring
BHT	204-011-403-...	Ring Assy Outer
BHT	204-011-406-...	Scissors Assy
BHT	204-011-407-...	Link Assy
BHT	204-011-408-...	Sleeve
BHT	204-011-426-...	Cap, Outer Race
BHT	204-011-427-...	Cap, Inner Race
BHT	204-011-428-...	Bearing Cover
BHT	204-011-438-...	Lever Assy
BHT	204-011-801-...	Hub Assy, Tail Rotor
BHT	204-012-101-...	Hub Assy, Main Rotor
BHT	204-012-102-...	Fitting Inboard

BHT	204-012-103-:::	Fitting Outboard
BHT	204-012-104-...	Pin Assy
BHT	204-031-244-...	Bolt Assy
BHT	204-031-920-...	Damper Assy
BHT	204-031-927-...	Pylon Mount
BHT	204-040-003-...	Gearbox Assy 42°
BHT	204-040-012-...	Gearbox Assy 90°
BHT	204-040-016-...	Transmission Assy
BHT	204-040-102-...	Pinion
BHT	204-040-108-...	Pinion
BHT	204-040-112-...	Sprocket Wheel
BHT	204-040-117-...	Adapter
BHT	204-040-122-...	Nut
BHT	204-040-148-...	Plate
BHT	204-040-184-...	Nut
BHT	204-040-189-..	Spacer Set
BHT	204-040-199-..	Retainer
BHT	204-040-250-...	Sleever Assy
BHT	204-040-252-...	Nut
BHT	204-040-261-...	Nut
BHT	204-040-262-...	Jet Assy
BHT	204-040-288-...	Jet Assy
BHT	204-040-305-...	Sleeve Assy
BHT	204-040-306-...	Sleeve Assy
BHT	204-040-309-...	Nut
BHT	204-040-321-...	Support
BHT	204-040-324-...	Shaft
BHT	204-040-326-...	Jet
BHT	204-040-327-...	Jet
BHT	204-040-333-...	Sprocket Assy

BHT	204-040-334-...	Cover Assy
BHT	204-040-337-...	Liner
BHT	204-040-338-...	Liner
BHT	204-040-353-...	Case Assy
BHT	204-040-355-...	Case Assy
BHT	204-040-357-...	Plate
BHT	204-040-359-...	Case Assy
BHT	204-040-362-...	Quill Assy
BHT	204-040-366-...	Main Rotor Mast Assy
BHT	204-040-367-...	Quill Assy
BHT	204-040-378-...	Deflector
BHT	204-040-379-...	Quill Assy, Generator Drive
BHT	204-040-386-...	Case Assy
BHT	204-040-387-...	Manifold Assy, Oil
BHT	204-040-388-...	Jet Assy
BHT	204-040-397-...	Spider Assy
BHT	204-040-399-...	Sleeve Assy
BHT	204-040-412-...	Nut
BHT	204-040-433-...	Driveshaft Assy
BHT	204-040-600-...	Hanger Assy
BHT	204-040-603-...	Coupling Inner
BHT	204-040-604-...	Coupling Outer
BHT	204-040-614-...	Coupling Outer
BHT	204-040-617-...	Hanger
BHT	204-040-620-...	Shaft Assy T/R
BHT	204-040-629-...	Retainer
BHT	204-040-700-...	Pinion
BHT	204-040-701-...	Gear
BHT	204-040-716-...	Clamp Set
BHT	204-040-785-...	Spider

Capability List

Chapter 4.1: Dynamic + Hydraulic Components



BHT	204-040-786-...	Plate Assy
BHT	204-040-788-...	Nut
BHT	204-040-789-...	Washer
BHT	204-040-790-...	Cup
BHT	204-040-811-...	Clamp Assy
BHT	204-060-155-...	Bipod
BHT	204-060-762-...	Actuator
BHT	204-072-915-...	Cargo Hook Assy
BHT	204-072-916-...	Housing
BHT	204-072-917-...	Housing
BHT	204-072-918-...	Shaft Assy
BHT	204-072-920-...	Tube
BHT	204-072-921-...	Yoke
BHT	204-076-036-...	Master Brake Cylinder
BHT	204-076-053-...	Directional Actuator
BHT	204-076-055-...	Irreversible Valve
BHT	204-076-201-...	Housing
BHT	205-001-017-...	Tube Assy
BHT	205-001-722-...	Bellcrank Assy
BHT	205-001-734-...	Bellcrank Assy
BHT	205-001-773-...	Walking Beam Assy
BHT	205-001-902-...	Bellcrank Assy
BHT	205-001-908-...	Idler Assy
BHT	205-001-916-...	Bellcrank Assy
BHT	205-001-917-...	Walking Beam Assy
BHT	205-001-921-...	Bellcrank Assy
BHT	205-040-001-...	Transmission Assy
BHT	205-040-004-...	Driveshaft Assy
BHT	205-040-109-...	Retainer
BHT	205-040-125-...	Case Set

Capability List

Chapter 4.1: Dynamic + Hydraulic Components



BHT	205-040-178-...	Outer Coupling
BHT	205-040-229-...	Gear
BHT	205-040-230-...	Gear
BHT	205-040-231-...	Ring Gear Assy
BHT	205-040-233-...	Gear
BHT	205-040-250-...	Clutch Assy
BHT	205-040-256-...	Sleeve Assy
BHT	205-040-263-...	Quill Assy, Main Input
BHT	205-040-300-...	Quill Assy, Rotorbrake
BHT	205-040-301-...	Pinion
BHT	205-050-403-...	Crosstube
BHT	205-060-106-...	Tripod
BHT	205-060-107-...	Tube Assy
BHT	205-076-029-...	Flight Control Cylinder Assembly
BHT	205-076-031-...	Main Rotor Collective Control Hydr. Cylinder Assy
BHT	205-076-038-...	Flight Control Cylinder Assembly
BHT	205-076-056-...	Collective + Cyclic Actuator
BHT	205-076-175-...	Universal Assy
BHT	205-076-381-...	Universal Assy
BHT	205-540-010-...	Transmission Assy
BHT	206-001-099-...	Tube Assy
BHT	206-001-189-...	Tube Assy
BHT	206-001-194-...	Tube Assy
BHT	206-001-538-...	Bellcrank Assy
BHT	206-001-544-...	Support Assy
BHT	206-001-544-101	Support Assy
BHT	206-010-101-...	M/R Yoke Assy
BHT	206-010-191-...	Plate Support
BHT	206-010-332-121	Mast Assy
BHT	206-010-335-...	Lever Assy

Capability List

Chapter 4.1: Dynamic + Hydraulic Components



BHT	206-010-336-005	Link, Idler Assy
BHT	206-010-360-...	Pitch Link Assy
BHT	206-010-360-003	Pitch Link Assy
BHT	206-010-444-001	Cap Assy
BHT	206-010-450-...	Swashplate
BHT	206-011-005-...	Collar Set Assy
BHT	206-011-005-001	Collar Set Assy
BHT	206-011-005-105	Collar Set Assy
BHT	206-011-100-...	Hub Assy, Main Rotor
BHT	206-011-117-...	Flap Restraint Assy
BHT	206-011-117-003	Flap Restraint Assy
BHT	206-011-132-...	Grip Assy
BHT	206-011-810-...	T / R Hub Assy
BHT	206-016-201-...	Tail Rotor Blade
BHT	206-030-539-...	Isolation Mount Assy
BHT	206-031-509-...	Drag Pin Assy
BHT	206-031-589-...	Link Assy
BHT	206-031-592-...	Mount Fitting
BHT	206-031-593-...	Mount Fitting
BHT	206-039-539-...	Isolation Mount
BHT	206-040-002-...	Main Gearbox
BHT	206-040-003-...	Transmission Assy
BHT	206-040-004-...	Transmission Assy
BHT	206-040-014-107	Mast Assy
BHT	206-040-015-...	Driveshaft
BHT	206-040-100-...	Driveshaft
BHT	206-040-184-001	Pump
BHT	206-040-230-...	Freewhell Assy
BHT	206-040-270-...	Freewhell Assy
BHT	206-040-301-...	Drive Shaft

Capability List

Chapter 4.1: Dynamic + Hydraulic Components



BHT	206-040-325-...	Drive Shaft
BHT	206-040-330-...	Drive Shaft
BHT	206-040-400-...	Tail Rotor Gearbox
BHT	206-040-402-...	Tail Rotor Gearbox
BHT	206-040-532-...	Top Case
BHT	206-040-931-...	Drive Shaft
BHT	206-076-031-...	Servo Actuator
BHT	206-076-034-...	Hydraulic Filter
BHT	206-076-047-...	Master Brake Cylinder
BHT	206-076-062-...	Servo Actuator
BHT	206-340-301-...	Rotor Brake
BHT	206-706-045-107	Transmission Assy
BHT	209-011-700-...	Tube
BHT	209-011-710-...	Tube
BHT	209-011-711-...	Idler
BHT	209-011-712-...	Idler
BHT	209-011-713-...	Link Assy
BHT	209-011-714-...	Tube
BHT	209-040-142-...	Cap Assy
BHT	209-040-618-...	Adapter
BHT	209-062-502-...	Blower Oil Cooler
BHT	212-001-051-...	Cyclic Servo Input Control Tube
BHT	212-001-055-...	Tube Assy
BHT	212-001-060-...	Tube Assy
BHT	212-001-188-...	Bellcrank Assy
BHT	212-001-252-...	Tube Assy
BHT	212-001-280-...	Tube Assy
BHT	212-001-312-...	Bellcrank Assy
BHT	212-001-317-...	Bellcrank Assy
BHT	212-001-322-...	Tube Assy

17.05.2021

Capability List

Chapter 4.1: Dynamic + Hydraulic Components



BHT	212-001-705-...	Bellcrank Assy
BHT	212-001-710-...	Bellcrank Assy
BHT	212-001-712-...	Bellcrank Assy
BHT	212-001-759-...	Bellcrank Assy
BHT	212-001-901-...	Walking Beam Assy
BHT	212-010-300-...	Stabilizer Bar Assy
BHT	212-010-302-...	Lever Assy
BHT	212-010-311-...	Tube Assy
BHT	212-010-403-...	Lever Assy
BHT	212-010-407-...	Scissors Assy
BHT	212-010-412-...	Universal
BHT	212-010-701-...	Hub Assy, Tail Rotor
BHT	212-010-704-...	Yoke Assy T/R
BHT	212-010-706-...	Nut
BHT	212-010-709-...	Bellcrank Assy
BHT	212-010-712-...	Rod
BHT	212-010-738-...	Trunnion Set
BHT	212-010-739-...	Support
BHT	212-010-744-...	T/R Yoke
BHT	212-010-750-...	T/R Blade
BHT	212-010-775-...	Crosshead
BHT	212-011-102-...	Yoke Assy M/R
BHT	212-011-701-...	Tail Rotor Hub Assy
BHT	212-011-702-...	Yoke T/R
BHT	212-011-704-...	Trunnion T/R
BHT	212-011-708-...	Pitch Horn Assy
BHT	212-011-710-...	Link Assy
BHT	212-011-713-...	Stop
BHT	212-030-096-...	Bolt
BHT	212-030-104-...	Link Assy

BHT	212-030-155-...	Bolt Assy
BHT	212-040-001-...	Transmission Assy
BHT	212-040-003-...	Gear Box Assy 42°
BHT	212-040-004-...	Gear Box Assy 90°
BHT	212-040-005-...	Main Driveschaft
BHT	212-040-054-...	Case Assy
BHT	212-040-117-...	Bolt Assy
BHT	212-040-136-...	Bearing
BHT	212-040-150-...	Pinion
BHT	212-040-151-...	Pinion
BHT	212-040-154-...	Sleeve Assy
BHT	212-040-184-...	Oil Pump
BHT	212-040-197-...	Shaft
BHT	212-040-201-...	Gear
BHT	212-040-202-...	Pinion
BHT	212-040-203-...	Sleeve Assy
BHT	212-040-207-...	Spacer
BHT	212-040-221-...	Jet Assy
BHT	212-040-263-...	Quill Assy, Main Input
BHT	212-040-363-...	Quill Assy, Main Input
BHT	212-040-365-...	Quill Assy, Hydraulic Drive
BHT	212-040-367-...	Race, (Main Input)
BHT	212-040-368-...	Spacer
BHT	212-040-600-...	Hanger Assy
BHT	212-040-630-...	Adapter
BHT	212-040-686-...	Driveshaft Assy
BHT	212-040-688-...	Coupling
BHT	212-060-745-...	Bellcrank Assy
BHT	212-060-749-...	Jackshaft
BHT	212-061-107-...	Tripod Assy

BHT	212-061-108-...	Bipod Assy
BHT	212-061-117-...	Tube Assy
BHT	212-076-004-...	Servo Actuator
BHT	212-076-005-...	Servo Actuator
BHT	212-076-006-...	Integrated Valve and Filter Assy
BHT	212-076-007-...	Accumulator
BHT	212-076-015-...	Pressure Operated Valve
BHT	212-076-110-...	Body
BHT	212-076-111-...	Piston
BHT	212-076-112-...	Cap
BHT	212-076-148-...	Clevis
BHT	212-076-149-...	Clevis
BHT	212-076-151-...	Tube Assy
BHT	212-310-701-...	Link Assy
BHT	212-510-001-103 FM "G"	Main Rotor Hub Assy
BHT	212-510-001-103 GFM	Main Rotor Hub Assy
BHT	212-540-002-...	Transmission Assy
BHT	214-040-604-...	Coupling Outer
BHT	214-040-657-...	Coupling Inner
BHT	214-040-659-...	Coupling Outer
BHT	222-010-415-...	Walking Beam Assy
BHT	222-010-419-...	Cyclic Link Assy
BHT	222-01-101-...	Hub Assy, Main Rotor
BHT	222-011-416-...	Link
BHT	222-012-701-...	T/R Hub Assy
BHT	222-012-711-...	Link Assy
BHT	222-016-001-...	T/R Blade Assy
BHT	222-031-619-...	Mount Assy
BHT	222-040-002-...	Mast Assy
BHT	222-040-002-113	Mast Assy

BHT	222-044-607-003	Coupling	
BHT	222-042-001-...	90° T/R Gearbox	
BHT	222-044-006-...	Driveshaft	
BHT	222-044-618-...	Coupling	
BHT	222-044-625-...	Shaft Assy	
BHT	222-080-060-...	Rotorbrake Master Cylinder	
BHT	222-112-700-...	Controls Assy	
BHT	222-382-001-...	Hydraulic Servo Actuator	
BHT	230-312-001-101	Pitch Link Assy	
BHT	230-365-001-...	Fan Assy	
BHT	406-010-401-...	Swashplate	
BHT	406-012-102-...	Yoke	
BHT	406-016-100-...	T/R Blade Assy	
BHT	406-040-315-111	Tail Rotor Shaft	13.05.2019
BHT	406-040-400-...	Tail Rotor Gearbox	
BHT	406-040-500-...	Freewhell Assy	
BHT	407-010-100-...	M/R Hub Assy	
BHT	407-010-206-...	Pinion Restraint	
BHT	407-012-101-...	Hub Assy T/R	
BHT	407-040-006-...	Transmission Assy	
BHT	407-040-007-...	Transmission Assy	13.05.2019
BHT	407-040-011-...	M/R Mast Assy	
BHT	407-040-038-101	Mast Assy	
BHT	407-340-302-...	Rotor Brake Assy	
BHT	41001140-...	Zylinder	
BHT	41103650-...	Servo Actuator Tail Rotor	
BHT	41103750-...	Servo Actuator	
BHT	412-010-100-...	Hub Assy Main Rotor	
BHT	412-010-161-...	Cap Assy	
BHT	412-010-162-...	Nut	

BHT	412-010-165-...	Cone Upper
BHT	412-010-167-...	Plate Assy
BHT	412-010-170-...	Bridge Assy
BHT	412-010-171-...	Cap Assy
BHT	412-010-172-...	Nut
BHT	412-010-177-...	Plate Assy
BHT	412-010-182-...	Rod End
BHT	412-010-190-...	Damper and Spindel Assy
BHT	412-010-400-...	Control Installation Pylon
BHT	412-010-401-...	Hub and Sleeve Assy
BHT	412-010-402-...	Swashplate and Support Assy
BHT	412-010-403-...	Driver Assy
BHT	412-010-405-...	Drive Link Assy
BHT	412-010-406-...	Link Assy
BHT	412-010-408-...	Lever Assy
BHT	412-010-422-...	Pin
BHT	412-010-425-...	Pitch Link Assy
BHT	412-010-443-...	Support Assy
BHT	412-010-445-...	Hub Assy
BHT	412-010-453-...	Support Assy
BHT	412-018-056-...	Cone Seat
BHT	412-018-068-...	Bridge Assy
BHT	412-030-224-...	Bolt Assy
BHT	412-040-002-...	Transmission Assy
BHT	412-040-004-...	Transmission and Mast Assy
BHT	412-040-005-...	Main Driveschaft
BHT	412-040-006-...	42° Gearbox
BHT	412-040-101-...	Mast Assy
BHT	412-040-101-127	Mast Assy
BHT	412-040-101-129...	Mast Assy

Capability List

Chapter 4.1: Dynamic + Hydraulic Components



BHT	412-040-102-...	Liner
BHT	412-040-103-...	Plate Assy
BHT	412-040-104-...	Nut
BHT	412-040-105-...	Oil Slinger
BHT	412-040-108-...	Lock Ring
BHT	412-040-111-...	Seal Magnetic
BHT	412-040-121-...	Sleeve Assy
BHT	412-040-123-...	Quill Assy, Rotor Brake
BHT	412-040-136-...	Adapter
BHT	412-040-230-...	Gear
BHT	412-040-263-...	Main Input
BHT	412-040-264-...	Cap Assy
BHT	412-040-302-...	Pinion
BHT	412-040-366-...	Mast Assy, M/R
BHT	412-040-600-...	Driveshaft Hanger, T/ R
BHT	412-040-601-...	Coupling Assy
BHT	412-040-621-...	Driveshaft Assy, T/R
BHT	412-040-624-...	Adapter T/R
BHT	412-040-625-...	Adapter T/R
BHT	412-040-627-...	Flange T/R
BHT	412-040-703-...	Quill Assy, Generator Drive
BHT	412-040-785-...	Spider
BHT	412-076-620-...	Universal Assy
BHT	412-310-400-...	Rod End Assy
BHT	412-330-437-...	Cap Assy
BHT	412-706-029-...	Transmission Assy
BHT	427-010-100-...	Hub Assy, Main Rotor
BHT	427-016-001-...	T/R Blade Assy
BHT	427-040-011-...	M/R Mast Assy
BHT	429-012-112-...	Pitch Link

Capability List

Chapter 4.1: Dynamic + Hydraulic Components



BHT	429-040-011-...	Main Rotor Mast Assy
BHT	429-040-011-101	Main Rotor Mast Assy
BHT	429-040-040-101	Main Rotor Mast Assy
BHT	430-010-201-...	Lift Link Assy
BHT	430-010-212-...	Restraint Assy
BHT	430-010-400-...	Rotating Ring Assy
BHT	430-010-401-105	Rotating Ring Assy
BHT	430-040-003-...	Transmission Assy
BHT	430-044-100-...	Shaft Assy
BHT	430-110-400-...	Mast Assy
BHT	540-011-319-...	Tube Assy
BHT	540-011-319-001	Tube Assy
BHT	9450103-1	Single Disk Rotor Brake Assembly
Dunlop	SGT520-6	Stabilizer damper
Dunlop	AC 64182	Control Servo without lock
Dunlop	AC 66436	Control Servo Tail Rotor
Dunlop	AC 66442	Control Servo with lock
Dunlop	AC 67030	Control Servo without lock
Dunlop	AC 67032	Control Servo Tail Rotor
Dunlop	AC 67234	Control Servo with lock
Dunlop	AC 67244	Control Servo without lock
Enerpac	AC 67246	Control Servo without lock
F.P.T Industries	B281K2753-053	Fuel Cell Assy
Goodrich	B091P0001051	Transportrad / Ground Handling Wheel
Honeywell	2612555-660	Brake Rotor Assembly
Honeywell	2612555-700	Brake Rotor Assembly
Hawker Pacific	900D3403502-101	Caliper Assy
Hawker Pacific	1660-23	Directional Actuator
Hawker Pacific	204-010-937-...	Stabilizer damper
HRT	SGT520-5	Stabilizer damper

22.02.2019

Capability List

Chapter 4.1: Dynamic + Hydraulic Components



HRT	42550	Irreversible Valve
HRT	30006760	Main Rotor Servo
HRT	30006840	Tail Rotor Servo
HRT	41000265	Lever Assy
HRT	41000286	Housing Assy
HRT	41000470	Cylinder Assy
HRT	41000515	Piston Assy upper
HRT	41000643	Piston Assy upper
HRT	41000670	Servo Actuator
HRT	41000720	Check Valve
HRT	41000870	Collective + Cyclic Actuator
HRT	41001140	SCAS Actuator
HRT	41001520	Servo Actuator
HRT	41011400	Servo Actuator
HRT	41103650	Servo Actuator
HRT	41103730	Servo Actuator
HRT	41105920	Servo Actuator
HRT	41105930	Servo Actuator
HRT	41105950	Servo Actuator
HRT	44000360	Accumulator
HRT	48088857	Servoactuator
HRT	41000570-...	Servo Actuator Tail Rotor
HRT	41103750-...	Servo Actuator
HRT	76650-09805-110	Main Rotor Servo
Pall	9450103	Brake Assy
Parker Hannifin	AEA 94452	Integrated Valve and Filter Assy
Rolls Royce	6895171	Fuel Check Valve

EASA Part-145 Approved Maintenance Organization (Line & Base Maintenance)
Approval No. DE.145.0082

FAA approved Repair Station (excluding Gyro Systems and Encoding Altimeter Systems)
Approval No. DE5Y802M

TCCA Approved Maintenance Organization
Approval No. 813-23

All aircraft batteries (NiCad) manufactured by SAFT, GILL, MARATHON, CONCORD, VARTA

Lead-Acid Batteries manufactured by GILL and CONCORD:

Manufacturer	Manufacturer's P/N	Vendor's P/N	Designation
Gill	G-25		Battery (Lead Acid)
Gill	G-35		Battery (Lead Acid)
Gill	G-242		Battery (Lead Acid)
Gill	G-243		Battery (Lead Acid)
Gill	G-244		Battery (Lead Acid)
Gill	600 Series		Battery (Lead Acid)
Gill	7000 Series		Battery (Lead Acid)
Concord	RG-49		Battery (Lead Acid)
Concord	RG-206		Battery (Lead Acid)
Concord	RG-222		Battery (Lead Acid)
Concord	RG-407		Battery (Lead Acid)
Concord	RG-380 Series		Battery (Lead Acid)

Other battery types upon request

Other electric / electronic components:

Manufacturer	Manufacturer's P/N	Vendor's P/N	Designation
Agusta	205-076-041-...		Accumulator
Agusta	206-062-200-...	200SGL132Q-4	Starter Generator

Manufacturer	Manufacturer's P/N	Vendor's P/N	Designation
Agusta	209-060-221-...	23046-...	Starter Generator
Agusta	212-076-007-...		Accumulator
Agusta	23032-...		Starter Generator
AH	033701AA		Spotlight / Lightning Instr. Panel
BHT	205-076-041-...	44000360	Accumulator
BHT	206-062-200-...	23032-...	Starter Generator
BHT	209-060-221-...	23046-...	Starter Generator
BHT	212-076-007-...		Accumulator
BHT	TSP283	31908-001	Battery
BHT		23081-...	Starter generator
AH	D133-1454.01E		Microswitch Guide
AH	D133-1454E		Microswitch Guide
AH	D133-720E		Switch
Flight Components	04-1104-0028		Power Supply, Anti Coll. Light
Flite-Tronics	PC-12		DC-DC Converter
Goodrich	209-060-221-...		Starter Generator
Goodrich	23032-...		Starter Generator
Goodrich	23046-...		Starter Generator
Goodrich	23081-...		Starter Generator
KGS Electronics	UC-28-14	UC28-14	DC Converter
MD	23081-...		Starter Generator
Sikorsky	23081-...		Starter Generator

EASA Part-145 Approved Maintenance Organization (Line & Base Maintenance)
Approval No. DE.145.0082

FAA approved Repair Station (excluding Gyro Systems and Encoding Altimeter Systems)
Approval No. DE5Y802M

TCCA Approved Maintenance Organization
Approval No. 813-23

Manufacturer	Manufacturer's P/N	Designation	Unit Type
ACME ELECTRIC CORP.	171BS101-...	POWER SUPPLY	AMPS500
Agusta	212-001-081-...	SCAS Actuator	41001140
AVTECH	5260-1-1	AUDIO REMOTE ELECTR.	5260-1-1
AVTECH	5261-1	AUDIO CONTROL PANEL	5261-1
AVTECH	5264-1-1	ELECTRONIC UNIT	5264-1-1
AVTECH	5283-1-1	INTERPHONE HANDSET	5283-1-1
AVTECH	5283-1-2	INTERPHONE HANDSET	5283-1-2
AVTECH	5287-1	CONTROL UNIT	5287-1
AVTECH	5289-1	CONTROL UNIT	5289-1
AVTECH	5383-1	INTERPHONE HANDSET	5383-1
BECKER AVIONICS	BXP6403-2-(01)	MODE S TRANSPONDER	BXP6403
BHT	212-077-163-103	COMPASS CONTROL PANEL	
BENDIX/KING	017-01283-...	NAV CONTROL UNIT	KFS564A
BENDIX/KING	050-1167-...	AUDIO MKR PANEL	KMA20TSO
BENDIX/KING	050-1167-00	AUDIO MKR PANEL	KMA20TSO
BENDIX/KING	060-00015-...	DIRECTIONAL GYRO	KG102A
BENDIX/KING	060-0013-...	SLAVED GYRO	KSG105
BENDIX/KING	060-0015-00	DIRECTIONAL GYRO	KG102A
BENDIX/KING	060-0017-00	FLIGHT COMMAND INDICATOR	KI256
BENDIX/KING	064-01084-...	VHF COM TRANSCEIVER	KY196B
BENDIX/KING	064-1019-...	VHF TRANSCEIVER	KY196
BENDIX/KING	064-1021-...	VHF COM TRANSCEIVER	KY197

Manufacturer	Manufacturer's P/N	Designation	Unit Type
BENDIX/KING	064-1023-...	VHF TRANSCEIVER	KTR908
BENDIX/KING	064-1052-...	VHF COM	KY96A
BENDIX/KING	064-1053-...	VHF COM TRANSCEIVER	KY197A
BENDIX/KING	064-1054-...	VHF COM TRANSCEIVER	KY196A
BENDIX/KING	065-00036-...	YAW COMPUTER	KC296
Bendix / King	065-00056-...	Servo Actuator	
Bendix / King	065-00056-0003	Servo Actuator	
BENDIX/KING	065-00089-...	ALTITUDE PRESELECTOR	KAS297C
BENDIX/KING	065-00143-0000	HELICOPTER MONITOR	KA153
BENDIX/KING	065-00144-0000	AP COMPUTER	KC193
BENDIX/KING	065-00179-0300	PRIMARY SERVO	KS271C
BENDIX/KING	065-0027-...	PITCH SERVO	KS270
BENDIX/KING	065-0028-...	PRIM SERVO	KS271
BENDIX/KING	065-0029-...	PITCH SERVO	KS272
BENDIX/KING	065-0034-...	FLIGHT COMPUTER	KC295
BENDIX/KING	065-0042-...	AP COMPUTER W FD	KC192
BENDIX/KING	065-0046-..	ALTITUDE PRESELECT.	KAS297
BENDIX/KING	065-0050-...	PITCH SERVO	KS177
BENDIX/KING	065-0051-...	PRIMARY SERVO	KS178
BENDIX/KING	065-0052-...	TRIM SERVO	KS179
BENDIX/KING	065-0053-00	ALTITUDE PRESELECTOR	KAS297A
BENDIX/KING	065-0054-...	AP COMPUTER WO FD	KC191
BENDIX/KING	065-0055-...	AP COMPUTER WO PITCH	KC190
BENDIX/KING	065-0059-...	PITCH SERVO	KS270A
BENDIX/KING	065-0060-...	PRIMARY SERVO	KS271A
BENDIX/KING	065-0061-...	TRIM SERVO	KS272A
BENDIX/KING	065-0065-...	ALTITUDE VS/SELCECTOR	KAS297B
BENDIX/KING	065-0089-04	ALTITUDE PRESELECTOR	KAS297C
BENDIX/KING	065-0143-...	HELICOPTER MONITOR	KA153
BENDIX/KING	065-0144-00	AP COMPUTER	KC193

Manufacturer	Manufacturer's P/N	Designation	Unit Type
BENDIX/KING	066-01021-0001	MARKER BEACON REC.	KR21
BENDIX/KING	066-01048-...	RDR ALTIMETER	KRA405
BENDIX/KING	066-01055-...	AUDIO PANEL (HELI)	KMA24H-...
BENDIX/KING	066-01069-...	DME INDICATOR	KDI572
BENDIX/KING	066-01078-0010	VOR/LOC,GS,MR,RMI	KNR634/A
BENDIX/KING	066-01088-...	DME	KN64
BENDIX/KING	066-01141-...	ATC TRANSPONDER	KT70
BENDIX/KING	066-01143-2001	TRANSPONDER	MST67A
BENDIX/KING	066-03024-...	PICTORIAL NAV IND	KPI552
BENDIX/KING	066-03034-0012	VOR/LOC/G.S.INDIC.	KI206
BENDIX/KING	066-03044-0004	RADAR ALT. INDICATOR	KNI416
BENDIX/KING	066-03125-...	ELECTRONIC DISPLAY	ED462
BENDIX/KING	066-1021-...	MARKER BEACON REC.	KR21
BENDIX/KING	066-1024-...	AUDIO MKR PANEL	KMA20TSO
BENDIX/KING	066-1047-01	ADF RECEIVER	KDF805
BENDIX/KING	066-1048-...	RDR ALTIMETER	KRA405
BENDIX/KING	066-1055-...	MARKER BEACON REC.	KMA24
BENDIX/KING	066-1055-...	AUDIO PANEL (HELI)	KMA24H-50/54
BENDIX/KING	066-1066-...	DME	KDM706A
BENDIX/KING	066-1067-...	RECEIVER VOR/LOC/GS	KN53
BENDIX/KING	066-1068-...	DME TRANSCEIVER	KN62A
BENDIX/KING	066-1068-04	DME TRANSCEIVER	KN62A
BENDIX/KING	066-1069-...	DME INDICATOR	KDI574
BENDIX/KING	066-1070-...	DME	KN63
BENDIX/KING	066-1072-...	ADF RECEIVER	KR87
BENDIX/KING	066-1077-...	ADF	KDF806
BENDIX/KING	066-1078-...	VOR/LOC/GS/MKR	KNR634
BENDIX/KING	066-1078-...	VOR/LOC,GS,MR,RMI	KNR634/A
BENDIX/KING	066-1088-00	DME	KN64
BENDIX/KING	066-1126-00	NAV RECEIVER	KNR620

Manufacturer	Manufacturer's P/N	Designation	Unit Type
BENDIX/KING	066-3020-...	ADI	KCI310
BENDIX/KING	066-3024-...	PICTORIAL NAV IND	KPI552
BENDIX/KING	066-3027-...	PICTORIAL NAV IND.	KPI553A
BENDIX/KING	066-3034-...	VOR/LOC INDICATOR	KI202
BENDIX/KING	066-3034-...	VOR/LOC/CONVERTER IN	KI203
BENDIX/KING	066-3034-...	VOR/LOC/COM&GS IND.	KI204
BENDIX/KING	066-3034-...	VOR/LOC/G.S.INDIC.	KI206
BENDIX/KING	066-3034-...	VOR/LOC INDICATOR	KI207
BENDIX/KING	066-3038-00	RMI	KI229
BENDIX/KING	066-3044-...	RADAR ALT. INDICATOR	KNI416
BENDIX/KING	066-3045-...	PICTORIAL NAV IND.	KPI553A
BENDIX/KING	066-3046-...	PICTORIAL NAV IND.	KI525A
BENDIX/KING	066-3056-...	VOR/LOC INDICATOR	KI208
BENDIX/KING	066-3056-...	VOR/LOC CONVERTER	KI209
BENDIX/KING	066-3060-...	RMI	KNI582
BENDIX/KING	066-3082-...	ADI	KCI310A
BENDIX/KING	066-3084-...	INDICATOR	IN182A
BENDIX/KING	066-4010-...	VHF NAV	KNS81
BENDIX/KING	066-04031-	GPS NAV SYSTEM	KLN90B
BENDIX/KING	066-04031-1121	GPS RECEIVER	KLN90B
BENDIX/KING	066-04031-1122	GPS NAV SYSTEM	KLN90B
BENDIX/KING	069-01028-...	VHF COM/NAV	KX125
BENDIX/KING	069-01032-...	VHF COM NAV/GS RCVR.	KX155A
BENDIX/KING	069-01033-...	VHF COM NAV/GS RCVR.	KX165/A
BENDIX/KING	069-1024-...	VHF COM NAV/GS RCVR.	KX155
BENDIX/KING	069-1024-...	VHF COM/NAV RCVR.	KX155 W/O GS
BENDIX/KING	069-1025-...	VHF COM/NAV/GS	KX165
BENDIX/KING	069-1025-...	VHF COM/NAV RCVR.	KX165 W/O GS
BENDIX/KING	069-1028-...	VHF COM/NAV	KX125
BENDIX/KING	071-0017-00	AUTOPILOT ADAPTER	KA57

Manufacturer	Manufacturer's P/N	Designation	Unit Type
BENDIX/KING	071-01053-0000	SLAVING ACCESSORY	KA51
BENDIX/KING	071-01210-...	ADF CONTROL UNIT	KFS586
BENDIX/KING	071-01283-...	NAV CONTROL UNIT	KFS564A
BENDIX/KING	071-01284-...	ADF CONTROL UNIT	KFS586A
BENDIX/KING	071-01438-...	RADAR CTRL. PANEL	CP466A
BENDIX/KING	071-01439-...	CONTROL PANEL	CP468
BENDIX/KING	071-01493-...	RADAR CTRL PANEL	CP466B
BENDIX/KING	071-01507-...	CONTROL PANEL	KFS578A
BENDIX/KING	071-01517-00	CONTROL PANEL	CP470
BENDIX/KING	071-1053-...	SLAVING ACCESSORY	KA51A
BENDIX/KING	071-1192-...	ATC XPDR CONTROL	KFS576
BENDIX/KING	071-1210-...	ADF CONTROL UNIT	KFS586
BENDIX/KING	071-1215-...	VHF COMM CONTROL	KFS598
BENDIX/KING	071-1216-...	NAV CONTROL UNIT	KFS564
BENDIX/KING	071-1242-...	SLAVING ACCESSORY	KA51B
BENDIX/KING	071-1276-...	ATC XPDR CONTROL	KFS576A
BENDIX/KING	071-1282-...	VHF COMM CONTROL	KFS598A
BENDIX/KING	071-1283-26	NAV CONTROL UNIT	KFS564A
BENDIX/KING	071-1284-...	ADF CONTROL UNIT	KFS586A
BENDIX/KING	071-1315-...	WX RADAR SENSOR	RS181A
BENDIX/KING	17960-0101-...	FMS	GNS-XLS
BENDIX/KING	17960-0102-...	FMS	GNS-XLS BRNAV
BENDIX/KING	3610477-...	WX RADAR SENSOR	RS181A
BENDIX/KING	3614277-...	EFIS 10 CONTROL PANE	CP103B
BENDIX/KING	3614278-...	RADAR CONTROL UNIT	CP113...
BENDIX/KING	3614522-...	EFIS10 CONTROL PANEL	CP103E
BENDIX/KING	8095296-...	RADAR CONTROL UNIT	CP123...
BENDIX/KING	8095351-...	ELECTRONIC DISPLAY	ED102E
BENDIX/KING	8095477-...	EFIS10 CONTROL PANEL	CP103F
BENDIX/KING	8095686-...	ELECTRONIC DISPLAY	ED102G

Manufacturer	Manufacturer's P/N	Designation	Unit Type
BENDIX-KING	066-03123-...	ELECTRONIC DISPLAY	ED461
COLLINS	622-2012-...	DME INDICATOR	339F-12A
COLLINS	622-2175-...	DME INDICATOR	339F-12B
COLLINS	622-1234-016	DME INDICATOR	339F12
COLLINS	622-1204-003	RDR ALTIM. IND.	339H-4
COLLINS	622-2362-...	RADAR ALTIMETER	ALT55
COLLINS	622-2855-001	RADAR ALTIMETER	ALT55B
COLLINS	622-3201-...	RADAR ALTIMETER	ALT50A
COLLINS	622-6520-...	CONTROL UNIT	CTL22
COLLINS	622-8737-...	CONTROL UNIT	CTL22A
COLLINS	822-1120-...	COM CONTROL UNIT	CTL22C
COLLINS	622-4524-...	CONTROL UNIT	CTL30
COLLINS	622-6521-...	NAV CONTROL UNIT	CTL32
COLLINS	622-8738-...	CONTROL UNIT	CTL32A
COLLINS	622-4526-...	CONTROL UNIT	CTL60
COLLINS	622-6522-...	CONTROL UNIT	CTL62
COLLINS	622-8739-...	CONTROL	CTL62A
COLLINS	622-4527-...	CONTROL UNIT	CTL90
COLLINS	622-6523-...	CONTROL ATC	CTL92
COLLINS	622-08740-011	CONTROL UNIT	CTL92A
COLLINS	622-8740-...	CONTROL UNIT	CTL92A
COLLINS	622-1233-001	TRANSCEIVER DME	DME40
COLLINS	622-6263-...	TRANSCEIVER DME	DME42
COLLINS	622-3915-...	DME INDICATOR	IND-40
COLLINS	622-3916-...	DME INDICATOR	IND40A
COLLINS	622-3917-...	DME INDICATOR	IND40B
COLLINS	622-3881-...	DME INDICATOR	IND40C
COLLINS	622-3918-...	DME INDICATOR	IND41
COLLINS	622-3919-...	DME INDICATOR	IND41A
COLLINS	622-3920-...	DME INDICATOR	IND41B

Manufacturer	Manufacturer's P/N	Designation	Unit Type
COLLINS	622-3921-...	DME INDICATOR	IND41C
COLLINS	622-6524-...	DME INDICATOR	IND42A
COLLINS	622-7318-...	DME INDICATOR	IND42C
COLLINS	622-9976-...	DME INDICATOR	IND42M
COLLINS	622-1270-001	TRANSPONDER	TDR90
COLLINS	622-9352-...	TRANSPONDER MODE-S	TDR94
COLLINS	622-9210-...	TRANSPONDER ATC	TDR94D
COLLINS	622-1879-...	TRANSCEIVER VHF	VHF20A
COLLINS	622-1334-...	TRANSCEIVER VHF	VHF20B
COLLINS	622-6389-011	TRANSCEIVER, VHF COM	VHF21A
COLLINS	822-1111-001	TRANSCEIVER VHF COM	VHF21C
COLLINS	622-6152-...	TRANSCEIVER VHF COMM	VHF22A
COLLINS	622-6153-001	TRANSCEIVER VHF COMM	VHF22B
COLLINS	822-1113-001	VHF COM 8,33KHZ	VHF22C
COLLINS	622-0876-...	RCVR VOR/LOC/GS/MB	VIR30A
COLLINS	622-0877-...	VHF NAV	VIR30M
COLLINS	622-1239-...	RCVR VOR/LOC/GS/MB	VIR31A
COLLINS	622-6137-...	RCVR VHF NAV/GS/MKR	VIR32
COLLINS	822-0400-001	RCVR VHF NAV	VIR33
DUKANE	DK100	UNDER WATER LOCATOR	DK100 (ELP-362D)
DUKANE	DK120	UNDER WATER LOCATOR	DK120
DUKANE	DK130	UNDERWATER BEACON	DK130
DUKANE	DK140	UNDERWATER BEACON	DK140
GARMIN	011-00152-11	AUDIO SELECTOR PANEL	GMA340
GARMIN	011-00401-...	AUDIO SELECTOR PANEL	GMA340
GARMIN	010-00152-...	AUDIO SELECTOR PANEL	GMA340H
GARMIN	010-00275-...	AUDIO SELECTOR PANEL	GMA347
GARMIN	011-00807-...	AUDIO SELECTOR PANEL	GMA347
GARMIN	010-00139-11	COM/NAV/GS/GPS REC.	GNS430
GARMIN	011-00280-...	COM/NAV/GS/GPS REC.	GNS430

Manufacturer	Manufacturer's P/N	Designation	Unit Type
GARMIN	011-00836-00	VHF COM/NAV/GPS/MMAP	GNS430A
GARMIN	011-01060-00	COM/NAV/GS/GPS REC.	GNS430W
GARMIN	011-00550-...	COM/NAV/GS/GPS REC.	GNS530
GARMIN	011-00835-00	VHF COM/NAV/GPS/MMAP	GNS530A
GARMIN	011-01066-00	COM/NAV/GPS/MMAP	GNS530AW
GARMIN	010-00416-01	COM/NAV/GPS	GNS530W
GARMIN	011-01064-40	COM/NAV/GPS	GNS530W
GARMIN	011-00054-00	GPS	GPS150
GARMIN	011-00104-00	GPS RECEIVER	GPS155
GARMIN	011-00490-...	TRANSPONDER	GTX327
GARMIN	011-01684-00	MODE-S TRANSPONDER	GTX328
GARMIN	010-00230-...	TRANSPONDER MODE S	GTX330
GARMIN	011-00455-00	TRANSPONDER MODE S	GTX330
GARMIN	010-00293-...	TXP MODE-S DIVERSITY	GTX330D
GARMIN	011-00455-10	TXP MODE-S DIVERSITY	GTX330D
HONEYWELL	066-1064-00	DME	KN62
HONEYWELL	066-01153-...	RDR ALTIMETER	KRA405B
HONEYWELL	065-00178-...	PITCH SERVO	KS270C
HONEYWELL	065-0040-...	TRIM SERVO	KS273
HONEYWELL	066-01164-0101	TRANSPONDER MODE-S	KT73
HONEYWELL	3614335-...	SYMBOL GENERATOR	SG101B
J.E.T.	501-1075-...	EMERG. POWER SUPPLY	PS823 A/T
J.E.T.	501-1075-02	EMERG. POWER SUPPLY	PS823B
J.E.T.	501-1228-...	EMERG. POWER SUPPLY	PS835A
KOITO	117-92039-03	POWER SUPPLY	117-92039-03
MARATHON	PC-50	STATIC INVERTER	PC-50
MARATHON	PC-50-8B	STATIC INVERTER	PC-50
MARATHON	PC-250-...	STATIC INVERTER	PC250()
MARATHON	PC-350-...	STATIC INVERTER	PC350
MARATHON FLITE-TRONI	PC251-...	STATIC INVERTER	PC251-()

Manufacturer	Manufacturer's P/N	Designation	Unit Type
MID-CONTINENT	4300-...	ELEC. ATTITUDE IND.	4300-XXX
MOTORFLUG	AE516-...	HELLAS CONTROL PANEL	AE516
NAT	AA85-...	INTERVOX II INTERCOM	AA85
NAT	N335-041	AUDIO CONTROL PANEL	N335
NAT	N335-042	AUDIO CONTROL PANEL	N335
NAT	55-10-041	Faceplate, NVG	
SERMAT	EE0033	POWER SUPPLY	EE33
SKYFORCE	SKYMAPIIIC	MOVING MAP E. GPS	SKYMAP IIIC
SKYFORCE	SM4000	MOVING MAP E. GPS	SKYMAP IIIC
WULFSBERG	071-1341-...	CONTROL UNIT VHF-COM	CD402B
WULFSBERG	8095259-...	CONTROL UNIT VHF-COM	CD402B
WULFSBERG	066-01107-...	DME TRANSCEIVER	DM441B
WULFSBERG	066-1107-...	DME TRANSCEIVER	DM441B
WULFSBERG	064-01047-...	VHF TRANSCEIVER	VC401B
WULFSBERG	064-1047-...	VHF TRANSCEIVER	VC401B
WULFSBERG	3614001-...	VHF TRANSCEIVER	VC401B

EASA Part-145 Approved Maintenance Organization (Line & Base Maintenance)

Approval No. DE.145.0082

FAA approved Repair Station

Approval No. DE5Y802M

TCCA Approved Maintenance Organization

Approval No. 813-23

Manufacturer	Manufacturer's P/N	Nomenclature	Limitation	Entry date
Aeronautical Accessories	206-320-...	Low Skid Gear Kit		
Aeronautical Accessories	206-321-...	High Skid Gear Kit		
Aeronautical Accessories	206-322-...	Flite Step Kit		
Aeronautical Accessories	206-329-...	Cross Tubes		
AH	105-81210	Hook Damper		
AH	105-81911	Snow Skid Assy		
AH	117-804021	Rescue Hoist, removable Part		
AH	117-804031	Rescue Hoist, Ausleger		
BHT	212-062-514-101	Oil cooler blower		
Goodrich	44301-10-xx	EXT. Rescue Hoist	Limited to: ASB EC135-85A-073	22.02.2019
Kannad	S1820514-08	ELT Progr. Dongle		
LISI Aerospace	AS22-xx	Cargo Hook Beam		

Please contact us for equipment which is not in the list

EASA Part-145 Approved Maintenance Organization (Line & Base Maintenance)

Approval No. DE.145.0082

FAA approved Repair Station (excluding Gyro Systems and Encoding Altimeter Systems)

Approval No. DE5Y802M

TCCA Approved Maintenance Organization

Approval No. 813-23

Manufacturer	Manufacturer's P/N	Vendor's P/N	Designation
ABG/SECMA-Atelier-SA	42965		Tachometer Indicator
ABG/SEMCA-Atelier-SA	42960-00	704A-47-612-052B	Tachometer Indicator
Aeritalia	8.150.004	109-0729-09-3	Airspeed Indicator
Aeritalia	8.249.006	38200	Attitude Gyro
Aeritalia	8.249.087	38314B	Horizontal Situation Indicator
Aeritalia	8.249.095	38314	Attitude Gyro
Aeritalia	31101C	8.143.014/ C661075-0106	Directional Gyro
Aeritalia	36101C	C661076-0105/8.148.014	Attitude Gyro
Aeronetics	520-4230-146	HSI-423A	Horizontal Situation Indicator
Aerosonic Corporation	10035-...		Altimeter
Aerosonic Corporation	101420-...		Encoding Altimeter
Aerosonic Corporation	101450-11952		Encoding Altimeter
Aerosonic Corporation	101627-01696		Encoding Altimeter
Aerosonic Corporation	101720-01393	369H4505	Altimeter
Aerosonic Corporation	101735-...		Altimeter
Aerosonic Corporation	102200-...		Encoding Altimeter
Aerosonic Corporation	1301-...		Altimeter
Aerosonic Corporation	20015-11187	412-075-009-105	Airspeed Indicator
Aerosonic Corporation	20020-...		Airspeed Indicator
Aerosonic Corporation	20130-...		Airspeed Indicator
Aerosonic Corporation	30260-1166	27-19139-1	Vertical Speed Indicator
Aerosonic Corporation	31230-...		Vertical Speed Indicator
Aerosonic Corporation	35060-...		Vertical Speed Indicator

Manufacturer	Manufacturer's P/N	Vendor's P/N	Designation
Aerosonic Corporation	4000-1002	206-070-275-005	Clock
Aerosonic Corporation	86000-...		Clock
Aerosonic Corporation	86300-...		Clock
Aerosonic Corporation	86400-1163	212-075-514-001	Clock
Aerosonic Corporation	A35-MA		Altimeter
Aerosonic Corporation	MS28045-...		Airspeed Indicator
Aerosonic Corporation	RC-30-...		Vertical Speed Indicator
Aerosonic Corporation	S15KILR		Airspeed Indicator
Aerosonic Corporation	S15KILR-...		Airspeed Indicator
Air Precision	5728 serie		Turn and Slip Indicator
Aircraft Appliances & Equipment/Bramalea Ont. Canada	32005-...		Tachometer Generator
Airpath Instrument Co.	2300		Magnetic Compass
Airpath Instrument Co.	2300 DL1		Magnetic Compass
Airpath Instrument Co.	C23000DL4-B		Magnetic Compass
Airpath Instrument Co.	C2300924B	269A4604T	Magnetic Compass
Airpath Instrument Co.	C2300DL...		Magnetic Compass
Airpath Instrument Co.	C2300L4-...		Magnetic Compass
Airpath Instrument Co.	CB2100T4		Magnetic Compass
Airpath Instrument Co.	CB2100T6D	MS17983-1	Magnetic Compass
Alenia, Lic Kollsmann, Galileo A	18364	8.106.003	Encoding Altimeter
Ametek	10220N01TOO	206-375-005-103	Temp. Indicator
Ametek	10355N02TOO	212-075-067-115	Temp. Indicator
Ametek	10355N04TOO	212-075-067-119	Temp. Indicator
Ametek	10446N02W00	206-075-739-113	Torque Indicator
Ametek	10447N01TOO	206-375-007-103	Temp. Indicator
Ametek	AW1842BA06	206-075-739-105	Torque Indicator
Ametek	SEL-019...		Temp. Indicator

Manufacturer	Manufacturer's P/N	Vendor's P/N	Designation
Ametek	SEL-0C19...	704A47 63 20 51	Temp. Indicator
Apparatebau Gauting GmbH	VM-450-6-L		Vertical Speed Indicator
Apparatebau Gauting GmbH	VM-450-6-L-...		Vertical Speed Indicator
Astronautics Corp.	111303-4		Attitude Director Indicator
Astronautics Corp.	111302-5		Horizontal Situation Indicator
Astrotech Corp.	AT42210H	Model LC-2H	Clock
Astrotech Corp.	AT6621N1	Model LC-6N	Clock
Autoflug	109290		YAW Gyro Unit
Autoflug	105-94563	105-94563	Mast Moment System
Autoflug	105-94564	105-94564	Mastmoment Indicator
Autoflug	105-945646		Mastmoment Indicator
Autoflug	105-94575	105-94575	Mastmoment Transmitter
Autoflug	117-94564		Mastmoment Indicator
Autoflug	117-945641		Mastmoment Indicator
Autoflug	117-945661		Mastmomentanlage
Auxitrol	G55-56-7-4	ZRB0564007	Transmitter Pressure
Avionic Instruments Inc.	1B250-1D-1	Mod-A	Inverter-Static 250VA/400Hz
Badin Crouzet	38210-...		Vertical Speed Indicator
Badin Crouzet	38399-490		Airspeed Indicator
Badin Crouzet	39600-5841		Encoding Altimeter
Badin Crouzet	44090-094	704A37-1130-34	Airspeed Indicator
Badin Crouzet SA	720		Vertical Speed Indicator
Badin Crouzet SA	37500-		Altimeter
Badin Crouzet SA	38210-...		Vertical Speed Indicator
Badin Crouzet SA	38210-480		Vertical Speed Indicator
Badin Crouzet SA	44090-1941-...		Airspeed Indicator
Badin Crouzet SA	44090-2941-...		Airspeed Indicator
Badin Crouzet SA	46700-ABM/-01		Vertical Speed Indicator
Badin Crouzet SA	7132-11	31831-1	Airspeed Indicator

Manufacturer	Manufacturer's P/N	Vendor's P/N	Designation
Barber Colman/Smith Aerospace	SYLC 50114	209-062-214-001	Actuator, Linear
Barber-Colman	SYLC50228-1	212-075-418-003	Actuator Assy
Barber-Colman	SYLC9868	204-060-762-005	Linear Actuator
Bendix	14602-1J	Type-J8	Attitude Gyro
Bendix	3567643-4801	MS28131-17T	Transmitter Pressure
Bendix	3567758-6501		Transmitter Torque
Bendix	3567758-6503		Transmitter Torque
Bendix	3571251-9110	222-375-022-101	Tachometer Indicator N1
Bendix	3571251-9111	222-375-023-101	Temp. Indicator
Bendix	3571251-9119	222-375-023-103	Temp. Indicator
Bendix	3571251-9120	222-375-022-103	Tachometer Indicator N1
Bendix	3571251-9121	222-375-023-105	Temp. Indicator
Bendix	3571251-9131	212-075-067-105	Temp. Indicator
Bendix	3571262-...	212-070-242-003	Tachometer Indicator N1
Bendix	3571281-8102	MU-1	Tachometer Indicator N1
Bendix	3571370-0001	204-070-155-001	Tachometer Indicator Dual
Bendix	3571371-...	212-070-108-003	Tachometer Indicator Triple
Bendix	3911213-...	214-175-248-103	Temp. Indicator
Bendix	3911213-...	222-375-078-101	Temp. Indicator
Bendix	3932241-...	214-175-257-103	Fuel Quantity Indicator
Bendix	3943331-9002	212-070-108-101	Tachometer Indicator Triple
Bendix	3943333-9002	412-075-010-109	Tachometer Indicator Triple
Bendix	99251-3252013-1401		Encoding Altimeter
Bendix King	KEA 346	066-3062-00	Encoding Altimeter
Bendix/Courter	96774-18-1842-7	412-075-205-101	Transmitter Torque
Bendix/King	060-0015-00	KG-102A	Directional Gyro
BHT	214-074-280-107	214-074-280-107	RPM WARNING UNIT
BHT	206-070-265-...		Dual Tacho Indicator

Manufacturer	Manufacturer's P/N	Vendor's P/N	Designation
BHT	206-070-265-7		Dual Tacho Indicator
BHT	AG34		Tacho. Generator
Brion Leroux Aeronautique	2511-1		Voltmeter
Brion Leroux Aeronautique	4619-776-00-10		Indicator Sling Load
Brion Leroux Aeronautique	4619-777-00-10		Weight Indicator
Brion Leroux Aeronautique	5626-522-00	704A47-632-021	Temp. Indicator
Brion Leroux Aeronautique	5813-700-00-10		Tachometer Indicator NTL-NR
Brion Leroux Aeronautique	7813-175-00-13		Tachometer Indicator Triple
Brion Leroux Aeronautique/Thales	4863-230-80-00		Trimm Position Indicator
CCS	209-062-003-001	209-062-003-001	Switch Pressure
CCS	7G1075		Switch Pressure
CCS	7G186	209-062-003-001	Switch Pressure
CCS Custom Component Switches Inc.	8G1229	117-12654-01	Switch Pressure
CEF Industries Inc.	369D27001	8222M7	Actuator Assy
Chicago Flexible Shaft Co.	8DJ19GAE5		Tachometer Indicator Dual
Chloride Pyrotector	30-231-31		Smoke Detector Type II
Computer Instruments Corp.	8700-28-0-200-10-10	Model 8700	Airspeed Sensor
Consolidated	63-...		Tachometer Indicator Dual
Consolidated Airborne	DSA274	DA23-204(AMC)03362(Y)	Attitude Gyro
Consolidated Airborne	DSA274-4	DAAJ01-72-C-0462	Attitude Gyro
Courter Inc.	96774-18-1838-...		Torquemeter Indicator Dual
Courter Inc.	96774-18-2104	205-075-807-1	Fuel Press Indicator
Courter Inc.	96774-18-2105	205-075-170-1	Torque Indicator
Courter Inc.	96774-18-2106	205-075-158-1	Pressure Indicator
Courter/Bendix	18-1838-11	212-070-160-011	Torquemeter Indicator Dual
Data Systems INC.	82-107-...		Fuel Quantity Indicator Dual
Diehl Avionik	DK449		Pressure Indicator

Manufacturer	Manufacturer's P/N	Vendor's P/N	Designation
Diehl Avionik	DL457-...		Tachometer Indicator Triple
Dodane SA	TYPE11A		Clock
E.C.E.	106CP01Y04		Transmitter Torque
E.C.E.	126PN01Y07		Torque Indicator
E.C.E.	216BB01Y05		Torquemeter Processing Unit
ECET/Labem/Meggitt	3080-201-...		Torque Indicator
Edison	217-00141	Type MO-2	Press Indicator XMSN Oil
Edison	217-01161	205-070-033-1	Torque Indicator
Edison	217-02111		Pressure Indicator
Edison	296-01611	209-070-275-1	Fuel Press Indicator
Edison	393004-01884		Fuel Quantity Indicator
Edison	418-01081	209-062-018-1	Transmitter Pressure Oil
Edison / ARMTEC	418-00084	130-020-5	Transmitter Pressure
Edison Thomas	217A100A		Press Indicator XMSN Oil
Edison/Armtec	418-00014	130-020-1	Transmitter Pressure
Edison/Armtec	418-00044	130-020-3	Transmitter Pressure
EDISON/BENDIX	418-00064/3567401-8801	130-020-9	Transmitter Pressure
Edo Aire	22-279-06	206-070-243-3	Tachometer Indicator N1
Edo Aire	22-285-01-1A	206-070-241-1	Tachometer Indicator Dual
Edo Aire	22-285-02	206-070-241-001	Tachometer Indicator Dual
Edo Aire	22-304-04	206-070-242-003	Temp. Indicator
Edo Aire	22-697-06-02	Model 697	Airspeed Indicator
Edo Aire	EA-1403A-2Z		Vertical Speed Indicator
Edo Aire	EA-5174-14-CES	C661065-0107/Model EA-	Airspeed Indicator
Edo Aire	EA-5175-0	Model EA-5175	Airspeed Indicator
Edo Aire	22-280-027-1B		Tachometer Indicator Dual
Electric Gyro Corporation	1234T100-...		Turn and Slip Indicator
Electronique Aero Spatiale	650-1101-232	650-1101-232	Indicator HSI651
Electronique Aero Spatiale	HS1651	650 1101 232	Horizontal Situation Indicator

Manufacturer	Manufacturer's P/N	Vendor's P/N	Designation
Eurocopter	K-DW-02/1		RPM WARNING UNIT
Eurocopter	K-DW-02/1A		RPM WARNING UNIT
Fairchild Swearingen	27-82186-017		Indicator Ldg Position
Farem SRL	01DB01-TYP717	109-0729-39-1	Amperemeter Dual
Farem SRL	04BD04TIP718	109-0729-23-1	Fuel Quantity Indicator
Farem SRL	04DB07-Typ807	109-0708-68-101	Fuel Quantity Indicator Triple
Farem SRL	08DC06TIP1344		Temp. Indicator
Farem SRL	12DB02TIP720	109-0729-38-3	Voltmeter
Farem SRL	13DC02A-Typ.776	109-0729-30-3	Torquemeter Indicator Dual
Farem SRL	13DC02B-TIP1350		Torque Indicator
Farem SRL	14BD01A-TIP746	109-0729-27-3	Temp.-Press.-Indicator
Farem SRL	14BD01-TYP747	109-0729-26-3	Temp.-Press.-Indicator
Farem SRL	14DB011-TYP1359	109-0729-27-3	Temp.-Press.-Indicator
Farem SRL	14DB01A-TYP 746	109-0729-27-3	Temp.-Press.-Indicator
Farem SRL	14DB01G-Typ1360	109-0729-26-3	Temp.-Press.-Indicator
Farem SRL	15 DAO1R-Typ 1557	212-075-037-109	N1 Tachometer Indicator
Farem SRL	15DA01A-Typ1204	212-075-037-101	Tachometer Indicator N1
Farem SRL	15DA01-Typ1201	109-0729-08-5	Tachometer Indicator N1
Farem SRL	15DA03BTYP1270		Tachometer Indicator Triple
Farem SRL	15DA03-Typ1277	412-075-010-109	Tachometer Indicator Triple
Farem SRL	NE149AB4	212-075-037-101	Tachometer Indicator N1
Farem/Officine Galileo SPA	E149AB1	109-0729-08-5	Tachometer Indicator N1
Farem/Officine Galileo SPA	E149AC	109-0730-16-1	Tachometer Indicator Triple
Farem/Officine Galileo SPA	E149AC7	412-075-010-109	Tachometer Indicator Triple
Garwin Inc.	169P-909-1		Loadmeter
Garwin Inc.	169P-910-22LBW		Fuel Quantity Indicator
Garwin Inc.	169P-910-5 LBW		Temp. Indicator Trans.Oil
Garwin Inc.	169P-910-5LBW		Temp. Indicator
Garwin Inc.	169P-914-5L1BW		Press. Indicator Trans.Oil

Manufacturer	Manufacturer's P/N	Vendor's P/N	Designation
Garwin Inc.	169P-914-5LBW		Pressure Indicator
Garwin Inc.	169P-914-6LBW		Fuel Press Indicator
Garwin/Weston Instruments	22-374-B01	Model 374B	Altimeter
General Design/Janitrol Aero	2800(4530N11L)	27-19167-001	Rate Gyro
General Design/Janitrol Aero	2800(4530N11L) / 4000784-8503 4099B	27-19167-001	Turn & Bank Indicator
General Design/Janitrol Aero	2800-...		Turn and Slip Indicator
General Design/Janitrol Aero	3300-11		Directional Gyro
General Design/Janitrol Aero	3935-2	6610-00-169-1489	Turn and Slip Indicator
General Design/Janitrol Aero	4000784-8503	27-19167-001	Turn & Bank Indicator
General Design/Janitrol Aero	4300-...		Attitude Gyro
General Design/Janitrol Aero	4305-...		Directional Gyro
General Design/Janitrol Aero	5560-8165N1L	222-375-028-101	Turn & Bank Indicator
General Design/Janitrol Aero	5560-8825N1L	27-19167-001	Turn and Slip Indicator
General Design/Janitrol Aero	7125-1	214-075-244-001	Rate of Turn Gyro
General Design/Janitrol Aero	7125-2	214-075-244-001(G)	Rate Transmitter
General Design/Janitrol Aero	7185-15	206-062-721-115	Actuator, Linear
General Electric	8DJ120...		Tachometer Indicator Dual
General Electric	8DJ131...		Tachometer Indicator Dual
General Electric	8DJ150...		Tachometer Indicator Dual
General Electric	8DJ19AAW	AF33170SUB 2	Tachometer Indicator Dual
General Electric	8DJ19-GAE-5	660-8314-1	Tachometer Indicator Dual
General Electric	8DJ43-AAM-14	MS28000-1	Tachometer Indicator N1
General Electric	8DJ43AAMSUB13	369A4516-7	Tachometer Indicator N1
General Electric	8DJ43AAMSUB14	MS28000-1	Tachometer Indicator N1
General Electric	8DJ67...		Tachometer Indicator Dual
General Electric	8DJ81...		Tachometer Indicator N1
General-Electric	8DJ150WAE-1	206-075-681-003	Tachometer Indicator Dual
Globe	206-062-627-003		Tachometer Indicator N1

Manufacturer	Manufacturer's P/N	Vendor's P/N	Designation
Globe	22A580		Tachometer Generator
Globe	22A6000	64550-023-1	Tachometer Generator
Globe	22A649	206-062-627-003	Tachometer Generator
Globe	22A667		Tachometer Generator
Globe	22A690		Tachometer Generator
Globe Industries	22A656	206-076-373-001	Tachometer Generator
Globe Motor	206-062-721-113	206-062-721-113	Actuator, Linear
Globe Motor	25140/65A165	206-062-721-105	Actuator, Linear
Globe Motor	25140/65A192	204-060-762-103	Actuator, Linear
Globe Motor	25140/67A281	214-001-347-007	Actuator Rotary (AFCS)
Globe Motor Div.	22A731	369H4551	Tachometer Generator
Globe Motor Div.	22A738	369H4233	Tachometer Generator
Globe Motors	22-A6000		Tachometer Generator
Globe Motors	25140/65A173	206-062-721-113	Linear Actuator
Goodrich/HELLA	2LA004968-60	1072137/ D8095	Flight Crew Reading Light
Grimes Aerospace	41850A14-4580		Search Light
Grimes Aerospace	41850A17-4580		Search Light
Grimes Aerospace	45-0339-11	Model 72914	Search Light
Grimes Aerospace	60-3474-5		Power Supply
Grimes Aerospace	G-5400-6	212-075-139-001	Landing Light
Grimes Aerospace	G-6250-4		Search Light
Grimes Aerospace Company	45-0253-29		Search Light
Grimes/Midland-Ross	60-3269-1FT	214-175-140-101	Power Supply
Grimes/Midland-Ross	60-3269-3	214-175-140-103	Power Supply
Grob	115EG-7780		Clock
Gull Airborn	261-926-001	PS28899-58	Temp Press Indicator
Gull Airborn	267-960-001	PS28899-57	Tachometer Indicator N1
Gull Airborn	371-903-002	PS28899-89	Press Indicator Oil
Gull Airborn/Dornier	208-906-001	PS28899-56	Temp. Indicator

Manufacturer	Manufacturer's P/N	Vendor's P/N	Designation
Gull Airborn/Dornier	267-961-001	PS28899-54	Torque Indicator
Hickok Electrical Instruments	563-01	Model 114B	Fuel Press/Flow Indicator
Hickok Electrical Instruments	563-031	27-19160-1	Temp.-Press.-Indicator
Hickok Electrical Instruments	563-080	27-19116-5	Ampere-Meter
Hickok Electrical Instruments	563-301	855104-1	Fuel Press/Flow Indicator
Hickok Electrical Instruments	720-264	27-19119-003	Flap Position Indicator
HICKOK/SWACO	563-073	27-19145-3	Temp.Indicator Cabin
Hokushin Electric Works, Ltd.	PF240	117-94054-01/2	Fuel Quantity Indicator
Hokushin Electric Works, Ltd.	PF240-N	117-94054-0	Fuel Quantity Indicator
Hokushin Electric Works, Ltd.	PF240-N3	117-94054-01	Fuel Quantity Indicator
Hokushin Electric Works, Ltd.	PF240-N4	117-94054-03	Fuel Quantity Indicator
Honeywell	GG2479-AA03		Transmitter, Rate Gyroscope
Honeywell	GG2479-AB03		Transmitter, Rate Gyroscope
Honeywell/Sperry	7002353-913	AZ-649	Air Data Sensor
InSCO	2502-7001	206-063-656-005	Transmitter Fuel Qty.
INSCO	4012-1003		Voltmeter
INSCO	4106-1020	6625-01-232-0389	Ampere-Meter
INSCO	4308-1007	206-070-989-001	Torque Indicator
INSCO	4308-1014		Torque Indicator
INSCO	4308-1024	369H6418	Press Indicator Oil
INSCO	4308-...		Torque Indicator
INSCO	4310-3005	214-075-239-11	Torque Indicator
INSCO	4320-3001	109-0729-30-1	Torque Indicator
INSCO	4320-3032	109-0729-07-1	Torquemeter Indicator Dual
INSCO	4331-3002	109-0729-06-1	Press Ind. Hydraulik
INSCO	4332-...		Fuel Press Indicator
INSCO	4337-...	260-2353-3	Torquemeter Indicator Dual
INSCO	4344-3021	109-0729-29-1	Press Ind. Hydraulik
INSCO	4351-...		Torquemeter Indicator Dual

Manufacturer	Manufacturer's P/N	Vendor's P/N	Designation
INSCO	4355-3001	109-0729-30-1	Torquemeter Indicator Dual
INSCO	5006-...	369A4521-3	Temp. Indicator
INSCO	5021-...	206-075-190-001	Temp. Indicator
INSCO	5029-...	206-075-190-001	Temp. Indicator
INSCO	5032-...		Temp. Indicator
INSCO	5707-...	206-075-189-001	Fuel Quantity Indicator
INSCO	5802-...	105-90880	Airspeed Indicator
INSCO	6103-...		Altimeter
InSCO	6501-...	206-070-243-1	Tachometer Indicator
INSCO	6502-...	206-070-265-5	Tachometer Indicator Dual
INSCO	6503A-...		Tachometer Indicator N1
INSCO	6505-1008		Tachometer Indicator Triple
INSCO	6505A-...	117-94053-03	Tachometer Indicator Triple
INSCO	6601-...		Vertical Speed Indicator
INSCO	6602-3019	ZG12CD2.341E900/United PN 7030 Code C.27, SN	Vertical Speed Indicator
INSCO	8DJ43-AAM-14	369A4516-7	Tachometer Indicator N1
INSCO	9009-...		Temp. Press Indicator XMSN Oil
INSCO	9016-...		Fuel Pressure & Load Indicator
INSCO	9019-...		Temp.-Pressure Indicator
INSCO	9019-3019	109-0729-03-1	Temp.-Press.-Indicator
INSCO	9020-3003	109-0729-01-1	Voltmeter
INSCO	9020-3004	109-0729-02-1	Ampere-Meter
INSCO	9030-...		Fuel Pressure & Load Indicator
INSCO	9032-...		Fuel Quantity Indicator
INSCO	9034-1003	105-90873	Press Indicator Triple Engine Oil
INSCO	9036-...	109-0729-27-1	Temp.-Press.-Indicator

Manufacturer	Manufacturer's P/N	Vendor's P/N	Designation
INSCO	9819-3016	109-0729-03-1	Temp.-Press.-Indicator
INSCO/Ahlers Aerospace	9030-3053	413-10001	Fuel Press.-Indicator Dual
INSCO / Tridair	6505-3062	260-2350-1	Tachometer Indicator Triple
Instrument Tech	3101-1043	369H4526-19	Torque Indicator
Instrument Tech.Corp	2850-0017	426500025-00	RPM WARNING UNIT
Intercontinental Dynamics Corp.	28702-002		Encoding Altimeter
Intercontinental Dynamics Corp.	29702-901	Typ 523	Encoding Altimeter
Intercontinental Dynamics Corp.	34670-112		Vertical Speed Indicator
Intercontinental Dynamics Corp.	518-16007-		Encoding Altimeter
Intercontinental Dynamics Corp.	571-25005-221		Encoding Altimeter
ITT Aerospace Controls	LA11A2121-1	209-062-780-101	Actuator, Linear
ITT Aerospace Controls	LA11A2129-1	212-075-418-107	Actuator, Linear
J.E.T. /Goodrich	501-1874-06	AI-360	Attitude Gyro
Jaeger	511900	Type 50	Altimeter
Jaeger	511951	3160 7347 903	Altimeter
Jaeger	543941		Torquemeter Indicator Dual
Jaeger	545344		Tachometer Generator
Jaeger	1-1152TC		Temp Press Indicator
Jaeger	1-1223-03	704A47-6500-50	Fuel Quantity Indicator
Jaeger	55-3		Altimeter
Jaeger	601285-03	704A47-270-102	Quadruple Indicators
Jaeger	61015-001-5		Torque Indicator
Jaeger	61533-		Temp. Indicator
Jaeger	64530-068-4	704A47-612-044	Tachometer Indicator N1

Manufacturer	Manufacturer's P/N	Vendor's P/N	Designation
Jaeger	64538-068-1	704A47-612-039	Tachometer Indicator N1
Jaeger	64751-003-3		Transmitter Fuel Contents
Jaeger	64975-003-1		Tachometer Indicator N1
Jaeger	8.383BN		Temp. Indicator
Jaeger	8.588.02		Position Indicator
Jaeger	8.669.02		Transmitter Position
Jaeger	IA9220		Torquemeter Indicator Dual
Jaeger/Sextant	61474-...		Tachometer Indicator Triple
Jaeger/Sextant	61474-104-...		Tachometer Indicator N1
Jaeger/Sextant	61475-100-1		Tachometer Indicator N1
Jaeger/Sextant	61476-402-1	704A47 610 065F1	Tachometer Indicator
Jaeger/Sextant	61476-403-1	704A47 610 069	Tachometer Indicator
Jaeger/Thomson CSF	64050-228-1		Airspeed Indicator
Jaeger/Thomson CSF	64052-200-1		Airspeed Switch
Jaeger/Thomson CSF	64130-102-1		Altimeter
Jaeger/Thomson CSF	64413-102-2		Altimeter
Jaeger/Thomson CSF	64514-203-1	704A37616-003	Tachometer Indicator Triple
Jäger7Sextant/Thomson CSF	5448-709-91-11	117-902101-A	Tachometer Indicator NG
Kannad	406 AF-H		ELT 121,5 / 243 / 406
Karnish Instrument Inc.	AC-102	5860-T2	Airspeed Indicator
Karnish Instrument Inc.	AC-131	MS28045-T1	Airspeed Indicator
Karnish Instrument Inc.	AC131A		Airspeed Indicator
Kearflex Engineering CO	843-67-...	446000458-00	Vertical Speed Indicator
KGS	RG40		Inverter DC
KGS Electronics	LT-50	212-075-962-001	Power Supply
King/United Instruments	066-3062-02	KEA346/5502-S2	Encoding Altimeter
King/United Instruments	KEA129	5035P2-P44/066-3064-01	Encoding Altimeter
King/United Instruments	KEA130A	5035PB-P57/066-3064-05	Encoding Altimeter
KOITO	117-92031-07	83000-00502	Power Supply

Manufacturer	Manufacturer's P/N	Vendor's P/N	Designation
Kollsman	371P1-01		Altimeter
Kollsman	371P-1-01		Altimeter
Kollsman	544KN04		Altimeter
Kollsman	586BK4-0153		Airspeed Indicator
Kollsman	671...		Altimeter
Kollsman	A32992-22-001		Altimeter
Kollsman	A39469-10-035		Airspeed Indicator
Kollsman	A52781-10-302		Tachometer Generator
Kollsman	B45451-10-101/-102		Encoding Altimeter
Kollsman	B4553 110 102		Encoding Altimeter
Kollsman	B45531-10-002/4/102/4		Altimeter
Kollsman	D22061-10-012		Altimeter
Kollsman	MS28044-LIA	671CLU-IU-038D	Altimeter
Kollsman	Typ AN5760-4B	671CPX-4-037D	Altimeter
Kollsman/ IDC Avionics Group	34670-602		Vertical Speed Indicator
Kollsman/Alenia	B45152-10-...		Encoding Altimeter
Kollsman/IDC	28007-...	IDC518	Encoding Altimeter
Kollsman/IDC	28704-D4001	Typ 519	Encoding Altimeter
Kollsman/MFR for Beechcraft	400-16-1	35-380037	Altimeter
Kulite Semiconductor	98505-15082-9	205-076-044-9	Pressure-Switch
Kulite Semiconductor	APT150-1000-125G	222-375-077-117	Transmitter Torque Engine
Kulite Semiconductor	APTE-130-1000-75G	412-375-006-101	Transmitter Engine Torque Pressure
Kulite Semiconductor	APTE-138A-100G		Transmitter Pressure
Kulite Semiconductor	APTE-138A-150G		Transmitter Eng.Oil Press
Kulite Semiconductor	APTE-139-1500SG		Transmitter Hydraulic Pressure
Kulite Semiconductor	IPT-19-1000-2000A	222-375-019-009	Transmitter Pressure
Kulite Semiconductor	IPT-20-1000-...	222-375-019-003	Transmitter Pressure

Manufacturer	Manufacturer's P/N	Vendor's P/N	Designation
Kulite Semiconductor	IPT-20RT1-1000-...	117-12656-01	Transmitter Pressure
L3/AIM/JET Electronics	AI-904		Independant Attitude Reference System
L3/AIM/JET Electronics	300		Horizon Reference Indicator
L3/AIM/JET Electronics	1100-28L...		Attitude Gyro
L3/AIM/JET Electronics	200 ...		Directional Gyro
L3/AIM/JET Electronics	205 ...		Directional Gyro
L3/AIM/JET Electronics	300-...	504-0006-914	Attitude Gyro
L3/AIM/JET Electronics	305-...	5040033943	Attitude Gyro
L3/AIM/JET Electronics	500 ...		Horizon Reference Indicator
L3/AIM/JET Electronics	504-...		Attitude Gyro
L3/AIM/JET Electronics	505-0010-...		Directional Gyro
L3/AIM/JET Electronics	509-0001-904	TS200-3A/329T-1	Turn and Slip Indicator
L3/AIM/JET Electronics	509-0001-910	329T-1	Turn and Slip Indicator
L3/AIM/JET Electronics	510-...		Attitude Gyro
L3/AIM/JET Electronics	540-0010-915	500DCFL(14)	Attitude Gyro
L3/AIM/JET Electronics	AI-360	501-1874-09	Attitude Gyro
L3/AIM/JET Electronics	P-20		Inverter-Static
L3/AIM/JET Electronics	TC100		Turn and Slip Indicator
L3/AIM/JET Electronics	TS200-...		Turn and Slip Indicator
L3/BFGoodrich /AIM/Jet	205-1A	5050031901	Directional Gyro
L3/BFGoodrich /AIM/Jet	305-1A	5040033921	Attitude Gyro
L3/BFGoodrich /AIM/Jet	504-0125-901	Model 1200-5R(15B)	Attitude Gyro
L3/BFGoodrich /AIM/Jet	505-0031-929	205-1BF	Directional Gyro
L3/BFGoodrich /AIM/Jet	PS-835C	501-1228-03	Emergency Power Supply
L3/BFGoodrich /AIM/Jet	PS-835D	501-1228-04	Emergency Power Supply
L3/BFGoodrich /AIM/Jet	PS-855A	501-1712-01	Emergency Power Supply
L3/BFGoodrich /AIM/Jet	PS-855A	501-1712-02	Emergency Power Supply

Manufacturer	Manufacturer's P/N	Vendor's P/N	Designation
L3/BFGoodrich /AIM/Jet	SC-841A	501-1318-01	Power Converter for Emergency Power Supply PS-835D
L3/JET	AI-803()		Attitude Gyro
L3/JET	AI-804()		Attitude Gyro
L3/JET	AI-330()		Attitude Gyro
L3/JET Electronics/AIM	5050031904	206-075-606-107	Directional Gyro
L3/JET Electronics/AIM	505-0031-926		Directional Gyro
Labem	3057-...		Temp. Indicator
Lear Siegler	51522-...		Voltage Regulator
Lear Siegler	51530-...		D.C.Generator Control Unit
Lear Siegler INC.	51522-002	222-375-060-109	Regulator/Controller
Lewis Engineering	147B31...		Temp. Indicator
Lewis Engineering	1528-20026	Type MJ-2	Temp. Indicator
Lewis Engineering	152B...	369A4521-5	Temp. Indicator
Lewis Engineering	152C304	369A4521-7	Temp. Indicator
Lewis Engineering	152C306	369A4521-11	Temp. Indicator
Lewis Engineering	152HL2W...		Temp. Indicator
Lewis Engineering	162B203	MS28009-2	Temp Indicator XMSN Oil
Lewis Engineering	162B3		Temp Indicator XMSN Oil
Lewis/Schwearingen	35981/611111-14	27-19157-3	Tachometer Indicator N1
Lewis/Swaeringen	61111-14	27-19157-3	Tachometer Indicator N1
Lewis/Swearingen	61121-04	27-19158-007	Torque Indicator
Litton Clifton Precision	90090001-...	407-375-001-101	Temp. Indicator
Litton Clifton Precision	90090003-...	407-375-002-105	Tachometer Indicator NG
Litton Clifton Precision	90090005-...	407-375-006-101	Fuel Quantity Indicator
Litton Clifton Precision	90090006-01	407-375-005-101	Temp.Press Indicator XMSN Oil
Litton Clifton Precision	9813-25-..	212-070-160-005	Torquemeter Indicator Dual
Litton Special Devices	1K426-90090007-02	407-375-004-103	Temp.-Press.-Indicator
Litton Special Devices	78200000-...	222-375-021-111	Tachometer Indicator

Manufacturer	Manufacturer's P/N	Vendor's P/N	Designation
Litton Special Devices	90090002-02	407-375-003-107	Torque Indicator
Litton Special Devices	90090003-01	407-375-002-103	Tachometer Indicator NG
Litton Special Devices	90090007-01	407-375-004-101	Temp.-Press.-Indicator
Litton Special Devices	9813-25-07	212-070-160-007	Torquemeter Indicator Dual
Litton/Aeronetics	520-8014-003	RCG-801E	Vertical Gyro
Logic/Italy	RBE10-01/A	204-074-001-1	RPM WARNING UNIT
LUCAS Aerospace	51538-005A	105-90139	D.C.Generator Control Unit
LUCAS Aerospace	51539-002N		D.C.Generator Control Unit
LUCAS Aerospace	51565-000R		D.C.Generator Control Unit
LUCAS Aerospace/Lear Siegler	51509-002R		D.C.Generator Control Unit
Ludolph	FK16		Magnetic Compass
Ludolph	FK16S.t.D.m.B.	Vers.Nr.6605-12-144-2276	Magnetic Compass
Ludolph	FK16STDMBF1		Magnetic Compass
Mac Leod Instr. Corp.	950-935-09-1810	269A4250-11	Manifold Press Indicator
Mac Leod Instr. Corp.	210-09-1510		Airspeed Indicator
MACLEOD Instr. Corp.	230-210-09-1510		Airspeed Indicator
MACLEOD Instr. Corp.	230-218091210		Airspeed Indicator
MACLEOD Instr. Corp.	230-218-09-1210		Airspeed Indicator
Marathon Power Technologies	39563-001	81755/C8715-2, Type 18-S104	Emergency Power Supply
Marathon Power Technologies	DTSP-400L	31879-001	Emergency Power Supply
Marathon Power Technologies	Model BP-9	DC0800CA	Battery Pack Clock/IIDS
Marathon Power Technologies	PC-500-1B/500177	412-375-079-101	Inverter-Static
Marotta Scientific Controls Inc.	800853-3	Model MV524	Solenoid Valve

Manufacturer	Manufacturer's P/N	Vendor's P/N	Designation
Mid Continent	4200-...		Attitude Gyro
Mid Continent	4300-...		Attitude Gyro
Mid Continent Instr.	4300-311(15°)		Attitude Gyro
Mid Continent Instr.	4300-311(5°)		Attitude Gyro
Midland-Ross Corp.	2800-		Turn and Slip Indicator
Midland-Ross Corp.	4530N1		Turn and Slip Indicator
Midland-Ross Corp.	5550-7485N1L		Turn and Slip Indicator
Mitchel Aircraft Products Inc.	599-175A1	D1-112-5023	Tachometer Indicator
Mitchel Aircraft Products Inc.	D1-112-...		Tachometer Indicator
Mitchel Aircraft Products Inc.	D1-312-5038	Model 99500-ELT	Clock
Mitsubishi Electric Corp.	AU-10-01	117-94061-01	RPM WARNING UNIT
Mors SA Division/Brion Leroux/Sextant	2306-556-00-10		Fuel Quantity Indicator
Mors SA Division/Brion Leroux/Sextant	2306-557-00-10		Fuel Quantity Indicator
Mors SA Division/Brion Leroux/Sextant	2309-362-00-10		Ampere-Meter
Mors SA Division/Brion Leroux/Sextant	4619-777-00-10		Sling Load
Mors SA Division/Brion Leroux/Sextant	5306160-00-11		Press Indicator Oil
Mors SA Division/Brion Leroux/Sextant	5306-255-00-11		Temp. Indicator
Mors SA Division/Brion Leroux/Sextant	5306-265-00-10		Temp. Indicator
Mors SA Division/Brion Leroux/Sextant	5633-619-00-10		Tachometer Indicator N1
Mors SA Division/Brion Leroux/Sextant	5633-707-80-...		Tachometer Indicator NG

Manufacturer	Manufacturer's P/N	Vendor's P/N	Designation
Mors SA Division/Brion Leroux/Sextant	5633-713-20-10		Tachometer Indicator N1
Mors SA Division/Brion Leroux/Sextant	5637-551-00-12		Temp. Indicator
Mors SA Division/Brion Leroux/Sextant	5637-553-00-10		Temp. Indicator
Mors SA Division/Brion Leroux/Sextant	5637-560-00-10	704A47-632-065	Temp. Indicator
Mors SA Division/Brion Leroux/Sextant	5677-752-00-10		Torque Indicator
Mors SA Division/Brion Leroux/Sextant	5876-703-00-...		Tachometer Indicator
Mors SA Division/Brion Leroux/Sextant	7813-177-00-...		Tachometer Indicator
NORTHORP GRUMMAN Comp. Technologies	1K426-90090002-02	407-375-003-107	Torque Indicator
Oeco/Precision Electronics Inc.	22070	209-075-228-001	Voltage Regulator
Oeco/Precision Electronics Inc.	20087B	209-075-228-001	Voltage Regulator
PHAOSTRON INSTR.& ELEC.	000-20382	209-070-262-111	Temp.-Press.-Indicator
R.C. Allen	A1620	206-070-274-005	Turn and Slip Indicator
R.C. Allen	A5930-02	206-070-274-005	Turn and Slip Indicator
R.C. Allen	RCA26BK-...		Attitude Gyro
R.C. Allen	RCA85-1		Turn and Slip Indicator
R.C.Allen	10736-A	29-2000	Temp.Dual Carb.
R.C.Allen	A1600	MS28024-3	Turn and Slip Indicator
R.C.Allen	A1605	MS28041-1A	Turn and Slip Indicator

Manufacturer	Manufacturer's P/N	Vendor's P/N	Designation
R.C.Allen	RCA10-J-3985-02		Directional Gyro
R.C.Allen	RCA11A-...		Directional Gyro
R.C.Allen	RCA15 BK-2	102-0064-01	Directional Gyro
R.C.Allen	RCA15AK-...		Directional Gyro
R.C.Allen	RCA15BK-...	206-075-606-103/103-0022-01	Directional Gyro
R.C.Allen	RCA21-1	0661001-0503	Attitude Gyro
R.C.Allen	RCA22-...		Attitude Gyro
R.C.Allen	RCA26AK-...		Attitude Gyro
R.C.Allen	RCA26BK-...		Attitude Gyro
R.C.Allen	RCA82A-11	C661003-0507	Turn Coordinator
Revue Thommen AG	3A41.32.20F.28.4EP		Altimeter
Revue Thommen AG	3A43.22.20F.05.1AL		Altimeter
Revue Thommen AG	3A43.32.20F.28.4.CG		Altimeter
Revue Thommen AG	3A43.32.20F.28.4.EE		Altimeter
Revue Thommen AG	3A51.22.20F.05.1.F		Altimeter
Revue Thommen AG	3A51.32.35F.00.0.F	3A51-32-35F0Z02	Altimeter
Revue Thommen AG	3A55.32.35F.00.0.E	3A553235F000E	Encoding Altimeter
Revue Thommen AG	3A61.22.20F.28.1.DA		Altimeter
Revue Thommen AG	3A67.32.20F.05.1.KR		Encoding Altimeter
Revue Thommen AG	4A16...		Vertical Speed Indicator
Revue Thommen AG	5A.16.22.20K.05.1.AU	117-940471	Airspeed Indicator
Revue Thommen AG	5A16.22.20K.05.1.AU	117-9405221	Airspeed Indicator
Revue Thommen AG	5A58.32.18K.28.4BH		Airspeed Indicator
Revue Thommen AG	5A58.32.18K.28.4CN		Airspeed Indicator
Revue Thommen AG	5C16.42.35K.05.1D		Airspeed Indicator
Revue Thommen AG	95-21016		Fuel Flowmeter
Revue Thommen AG	95-21017		Fuel Flowmeter
Revue Thommen AG	B13-941.22.05.2	ABU-11/A	Clock

Manufacturer	Manufacturer's P/N	Vendor's P/N	Designation
Revue Thommen AG	B13-941.22.05.2.A	ABU-11A	Clock
Revue Thommen AG	B13-941.23.00.0.A	A-134-1	Clock
Revue Thommen AG	B13-944.22.00.0		Clock
Revue Thommen AG	B17-941.27.00.0.A		Clock
Revue Thommen AG	B18-945.22.00.0.A.	7050A4312004	Clock
Revue Thommen AG	B18-945.22.28.2.A	212-075-514-001	Clock
Revue Thommen AG	B18-945.22.28.2.A.	704A47320011	Clock
Revue Thommen AG	B18-945.22.28.4.DN	704A47320042	Clock
Revue Thommen AG	B18-945-22-28-2A		Clock
Revue Thommen AG	Q18-945.22.00.0BB		Clock
Rochester	6246-00514	369D24135-3	Temp Indicator Oil
Rochester	6247-00071	369D296305-021	Instrumet Cluster
Rogerson Kratos	50579	214-076-016-1	Transmitter Pressure Hydraulik
Rogerson Kratos	115.015	212-070-241-001	Temp.Indicator
Rogerson Kratos	124.013	209-070-262-003	Temp.-Press.-Indicator
Rogerson Kratos	124.013	209-070-262-103	Temp.-Press.-Indicator
Rogerson Kratos	124.014	212-070-124-043	Temp.-Press.-Indicator
Rogerson Kratos	124.039	209-070-264-003	Amperemeter Dual
Rogerson Kratos	124.040	209-070-263-003	Voltmeter Dual
Rogerson Kratos	124.041	212-070-116-007	Temp.Press Indicator XMSN Oil
Rogerson Kratos	124.043		Temp.-Press.-Indicator
Rogerson Kratos	124.044		Fuel Press Indicator
Rogerson Kratos	124.045	212-070-116-009	Temp.Press Indicator XMSN Oil
Rogerson Kratos	124.067	212-075-067-105	Temp. Indicator
Rogerson Kratos	124.115	209-070-262-009	Temp.-Press.-Indicator
Rogerson Kratos	124115	209-070-262-109, 122Y025	Temp.-Press.-Indicator
Rogerson Kratos	124.329	212-8300-16-1	Temp.-Press.-Indicator
Rogerson Kratos	124.331	212-8300-18-1	Temp. Indicator
Rogerson Kratos	124.380	109-0729-23-1	Fuel Quantity Indicator

Manufacturer	Manufacturer's P/N	Vendor's P/N	Designation
Rogerson Kratos	124.403	109-0729-28-3	Fuel Pressure & Load Indicator
Rogerson Kratos	124.419	109-0729-29-3	Press Ind. Hydraulik
Rogerson Kratos	124.439	206-075-188-005	Temp.-Press.-Indicator
Rogerson Kratos	124.439	206-075-706-001	Temp.-Press.-Indicator
Rogerson Kratos	124.440	206-063-633-101	Fuel Quantity Indicator
Rogerson Kratos	124.440	206-063-633-103	Fuel Quantity Indicator
Rogerson Kratos	124.440	206-075-707-001	Fuel Quantity Indicator
Rogerson Kratos	124.443	206-075-710-001	Ampere-Meter
Rogerson Kratos	124.444	206-075-190-001	Temp. Indicator
Rogerson Kratos	124.444	206-075-680-107	Temp. Indicator
Rogerson Kratos	124.480	212-075-067-105	Temp. Indicator
Rogerson Kratos	124.480	212-075-420-003	Temp. Indicator
Rogerson Kratos	124.486	109-0729-32-7	Temp. Indicator
Rogerson Kratos	124.487	109-0729-38-1	Voltmeter Dual
Rogerson Kratos	124.488	109-0729-38-3	Voltmeter
Rogerson Kratos	124.489	109-0729-39-1	Amperemeter Dual
Rogerson Kratos	124.545	222-375-024-101	Fuel Quantity Indicator
Rogerson Kratos	124.546	222-375-016-101	Temp.-Press.-Indicator
Rogerson Kratos	124.549	222-375-017-101	Temp.Press Indicator XMSN Oil
Rogerson Kratos	124.550	222-375-018-101	Temp.-Press.-Indicator
Rogerson Kratos	126.310	109-0900-13-101	Tachometer Indicator
Rogerson Kratos	124.1013	206-075-677-101	Temp.-Press.-Indicator
Rogerson Kratos	124.1014	206-075-676-101	Fuel Pressure & Load Indicator
Rogerson Kratos	124.1014	206-075-676-103	Fuel Pressure & Load Indicator
Rogerson Kratos	115.201-3		Press Ind. Hydraulik
Rogerson Kratos	115.201-4		Signal Conditioner
Rogerson Kratos	122Y026	212-075-036-107	Temp.Press Indicator XMSN Oil
Rogerson Kratos	124.039-3	209-070-264-003	Amperemeter Dual
Rogerson Kratos	124.040-1	209-070-263-003	Voltmeter Dual

Manufacturer	Manufacturer's P/N	Vendor's P/N	Designation
Rogerson Kratos	124.041-1	212-075-036-101	Temp.Press Indicator XMSN Oil
Rogerson Kratos	124.043-1		Temp.-Press.-Indicator
Rogerson Kratos	124.044-2	209-070-069-???	Fuel Press Indicator
Rogerson Kratos	124.067-2	212-075-420-003	Temp. Indicator
Rogerson Kratos	124.1012-1	206-075-678-101	Temp.Press Indicator XMSN Oil
Rogerson Kratos	124.1012-3	206-075-678-103	Temp.-Press.-Indicator
Rogerson Kratos	124.1012-5	206-075-678-107	Press Indicator XMSN Oil
Rogerson Kratos	124.1012-7	206-075-678-105	Temp.Press Indicator XMSN Oil
Rogerson Kratos	124.1013-1	206-075-677-103	Temp.-Press.-Indicator
Rogerson Kratos	124.1013-2	206-075-677-105	Temp.-Press.-Indicator
Rogerson Kratos	124.1014-1	206-075-676-105	Fuel Pressure & Load Indicator
Rogerson Kratos	124.1014-2	206-075-676-107	Fuel Pressure & Load Indicator
Rogerson Kratos	124.1014-3	206-075-676-109	Fuel Pressure & Load Indicator
Rogerson Kratos	124.1014-4	206-075-676-111	Fuel Pressure & Load Indicator
Rogerson Kratos	124.1128-1	222-375-025-107	Voltmeter
Rogerson Kratos	124.115-1	209-070-262-009	Temp.-Press.-Indicator
Rogerson Kratos	124.115-3	209-070-262-101	Temp.-Press.-Indicator
Rogerson Kratos	124.331-3	212-8300-18-3	Temp. Indicator
Rogerson Kratos	124.444.12		Temp. Indicator
Rogerson Kratos	124.444-10	206-075-680-101	Temp. Indicator
Rogerson Kratos	124.444-2		Temp. Indicator
Rogerson Kratos	124.444-20		Temp. Indicator
Rogerson Kratos	124.444-6		Temp. Indicator
Rogerson Kratos	124.480-1	212-075-067-109	Temp. Indicator
Rogerson Kratos	124.480-3	212-075-562-003	Temp. Indicator
Rogerson Kratos	124.498-3	117-94036-05	Press Indicator XMSN Oil
Rogerson Kratos	124.498-5	117-94058-07	Temp.-Press.-Indicator
Rogerson Kratos	124.498-6	117-94058-07	Temp.-Press.-Indicator
Rogerson Kratos	124.499-04	117-94051-05	Temp. Indicator

Manufacturer	Manufacturer's P/N	Vendor's P/N	Designation
Rogerson Kratos	124.499-05	117-94051-07	Temp. Indicator
Rogerson Kratos	124.499-4	117-94051-05	Temp. Indicator
Rogerson Kratos	124.499-5	117-94051-07	Temp. Indicator
Rogerson Kratos	124.500-3	117-94035-05	Temp. Indicator
Rogerson Kratos	124.501-2	117-94055-01	Voltmeter Dual
Rogerson Kratos	124.503-3	117-94036-05	Press Indicator XMSN Oil Dual
Rogerson Kratos	124.507-4/5		Ampere-Meter
Rogerson Kratos	124.550-1	222-375-018-103	Temp.Indicator
Rogerson Kratos	124.933A	209-070-264-1	Amperemeter Dual
Rogerson Kratos	124.972A	212-070-116-007/009	Temp.Press Indicator XMSN Oil
Rogerson Kratos	124.972A	212-075-036-101	Temp.Press Indicator XMSN Oil
Rogerson Kratos	124L039-6	209-070-264-105	Amperemeter Dual
Rogerson Kratos	124L507-6	117-902061	Amperemeter Dual
Rogerson Kratos	124Q1348	206-075-740-113	Fuel Quantity Indicator
Rogerson Kratos	124T499-7	117-902031	Temp. Indicator
Rogerson Kratos	124Y498-7	117-902041	Pressure Indicator
Rogerson Kratos	126.037-5		Fuel Quantity Indicator
Rogerson Kratos	126.178-1		Tach Indicator Propeller Speed
Rogerson Kratos	126.182-30		Torque Indicator
Rogerson Kratos	126.307-5	214-175-257-105	Fuel Quantity Indicator
Rogerson Kratos	50579-3		Transmitter Pressure Hydraulik
S.F.I.M.	58057-...		Gyroscope Compass
SAFE FLIGHT Instrument Corp.	C-80505		Speed Control Indicator
Sandia Aerospace	SAE5-35	305154-00	Blind Encoder/Altitude Sensor
Sangamo Weston	S476.3.264		Press Indicator Oil
Sangamo Weston Instruments Inc.	S128-5-139		Tachomter Indicator Dual
Saturn Electronics Corp.	1704-1001-2	205-075-388-013	RPM WARNING UNIT

Manufacturer	Manufacturer's P/N	Vendor's P/N	Designation
Saturn/Northrop Corp.	2260-1001-1	209-075-326-001	RPM WARNING UNIT
Sextant Avionics SA	39951213	704A47612120	Tachometer Indicator
Sextant Avionics SA	2579-116-1	704A-711-004	Voltmeter
Sextant Avionics SA	64818-...		Press Indicator XMSN Oil
SFENA	803...		Attitude Gyro
SFENA	703BD	6610-14-268-1619	Attitude Gyro
SFENA	903BD	6610-14-268-1620	Attitude Gyro
SFENA	903BD-V2		Attitude Gyro
SFENA	H140...		Attitude Gyro
SFENA	H321...		Attitude Gyro
SFENA / Bodenseewerk Gerätetechnik GmbH	903BD-...	6610-12-153-8926	Attitude Gyro
SFENA/Sextant	H140BHM2		Attitude Gyro
SFENA/Sextant	H221ARM		Attitude Gyro
SFENASextant	H321ABM1		Attitude Gyro
SFIM	461.00272.101	Typ 130 / 58.057-42	Gyroscope Compass
SFIM	454-00162-000		Gyroscope Compass
SFIM/ Badin Crouzet	418-00475-600	46340-30	Module Anemo-Barometrique
Shadin	8800T		Blind Encoder/Altitude Sensor
Sigma Tek/Edo Aire	5000E-...	IU149-006-0, Model 52D66M	Attitude Gyro (Autopilot)
Sigma Tek/Edo Aire	22-111-02		Torque Indicator
Sigma Tek/Edo Aire	23-501-017	5000F-6	Attitude Gyro
Sigma Tek/Edo Aire	23-501-06-04		Attitude Gyro
Sigma Tek/Edo Aire	23-501-031-1	5000B-38	Attitude Gyro
Sigma Tek/Edo Aire	4000B-...		Directional Gyro
Sigma Tek/Edo Aire	4000C-...		Directional Gyro (Autopilot)
Sigma Tek/Edo Aire	4000D-...		Directional Gyro (Autopilot)
Sigma Tek/Edo Aire	4000HR-...		Directional Gyro

Manufacturer	Manufacturer's P/N	Vendor's P/N	Designation
Sigma Tek/Edo Aire	5000B-...		Attitude Gyro
Sigma Tek/Edo Aire	5000E	52D66/23-501-04	Attitude Gyro (Autopilot)
Sigma Tek/Edo Aire	5000F-...	23-501-017/C661076-0101	Attitude Gyro
Sigma Tek/Edo Aire	5000F-6	23-501-017	Attitude Gyro
Sigma Tek/Edo Aire	52054M	IU262-004-15, Model 4000C-1	Directional Gyro (Autopilot)
Sigma Tek/Edo Aire	52D137-1332	IG-832A/44690-0000	Slaved Navigation Situation Display
Sigma Tek/Edo Aire	52D266	IU367-201-1	Attitude Gyro (Autopilot)
Sigma Tek/Edo Aire	52D67/23-501-05	5000E-1	Attitude Gyro (Autopilot)
Sigma Tek/Edo Aire	IU262-001-7	4000B-6	Directional Gyro
Sigma Tek/Edo Aire	IU262-005-20		Directional Gyro
Simmonds Precision	391046		Transmitter Fuel Probe
Simmonds Precision	393004-...		Fuel Quantity Indicator
Simmonds Precision	393008-...		Fuel Quantity Indicator
Sinn	J30BZ-1		Clock
Sinn	Nabo17	6645-12-146-1628	Clock
Sinn	Nabo17ES		Clock
Smiths Aircraft Instruments Ltd.	01-200-102		Altimeter
Smiths Aircraft Instruments Ltd.	115AS bis 157AS		Airspeed Indicator
Smiths Aircraft Instruments Ltd.	5RC/PC bis 31RC/PC		Vertical Speed Indicator
Smiths Aircraft Instruments Ltd.	LUO138AS1	138AS	Airspeed Indicator
Smiths Aircraft Instruments Ltd.	RD146AS/PC		Airspeed Indicator

Manufacturer	Manufacturer's P/N	Vendor's P/N	Designation
Smiths Aircraft Instruments Ltd.	WL1403AM/MS/1		Encoding Altimeter
Smiths Aircraft Instruments Ltd.	WL506CUF/MS/1		Altitude Alerter
SOFRANCE	9550001800	JA03501C	Switch Fuel pressure
SOFRANCE	9550172050	JA00008B	Switch Fuel pressure
Sperry	2592920-444	RD-444	Deviation Indicator
Sperry	4030182-901	AC-702	Altitude Sensor
Sperry	RD-444	2592920-444	Deviation Indicator
Sperry/Honeywell	7000300-901	Model AS-702	Airspeed Sensor
Sperry/Honeywell	7002353-901	Model AZ-649	Air Data Sensor
Swearingen Aviation Corp.	61104-03	27-19149-3	Temp. Indicator
T.C.I.Trans-Cal Industries Inc.	SSD120-30		Blind Encoder/Altitude Sensor
Tempo Aerospace Company	07031-94123-7	206-075-447-007	Voltage Regulator
Terra Corporation	EPU 28-24 RM	0900-1840-22	Emergency Power Supply
Thomas A. Edison Industries	217-09261		Torque Indicator
Thommson-CSF/Jäger	61015-007-1	704A47-621-089	Torquemeter Indicator Dual
Thomson-CSF/Jäger	64111-049-1		Altimeter
TMP Electronics/Bell	PS304-1		Inverter-Static
Trans-Cal Industries	D120-P2-T		Blind Encoder/Altitude Sensor
Trans-Cal Industries Inc.	SSD120-30A		Blind Encoder/Altitude Sensor
U.S. Gauge	AW1842AR04	369H4526-7	Torque Indicator
U.S.Gauge	AW1842BA03	206-075-739-107	Torque Indicator
United Instruments Inc.	6111		Manifold Press Indicator
United Instruments Inc.	6121		Manifold Press Indicator
United Instruments Inc.	7000...		Vertical Speed Indicator
United Instruments Inc.	7030...	AHC-SP-034-01	Vertical Speed Indicator
United Instruments Inc.	8000...		Airspeed Indicator
United Instruments Inc.	159300		Airspeed Indicator

Manufacturer	Manufacturer's P/N	Vendor's P/N	Designation
United Instruments Inc.	11-1001K		Airspeed Indicator
United Instruments Inc.	5035P2	066-306401	Encoding Altimeter
United Instruments Inc.	5035P2-P...		Encoding Altimeter
United Instruments Inc.	5035P-P23		Encoding Altimeter
United Instruments Inc.	5035P-P40P.40		Encoding Altimeter
United Instruments Inc.	5932-BH5	206-070-263-005	Altimeter
United Instruments Inc.	5932BH5 Model LA-4		Altimeter
United Instruments Inc.	5934 Code A.91	206-070-263-7	Altimeter
United Instruments Inc.	5934-1	Code A67	Altimeter
United Instruments Inc.	5934D-1Code A.159	206-070-263-101	Altimeter
United Instruments Inc.	5934D-3 Code A.159		Altimeter
United Instruments Inc.	5934D-3Code A.159	206-070-263-101	Altimeter
United Instruments Inc.	5934M-1	206-070-263-007	Altimeter
United Instruments Inc.	5934M-3 Code A.193		Altimeter
United Instruments Inc.	5934P-1/Code A.91		Altimeter
United Instruments Inc.	5934P-1/Code A56	C661071-0101	Altimeter
United Instruments Inc.	5934PAD-1 Code A.132		Altimeter dual scale
United Instruments Inc.	5934PAD-3		Altimeter
United Instruments Inc.	5934PAD-3 Code A.135		Altimeter
United Instruments Inc.	5934PAD-3 CodeA.132		Altimeter
United Instruments Inc.	5934PD-1	369D24174	Altimeter
United Instruments Inc.	5934PD-1 / Code A.130	369D24174	Altimeter
United Instruments Inc.	5934PD-1/Code A.130		Altimeter dual scale
United Instruments Inc.	5934PD-3 Code A.167	369D24174	Altimeter
United Instruments Inc.	5934PD-3 Code A.624	350A760108-01	Altimeter
United Instruments Inc.	5934PD3A250		Altimeter
United Instruments Inc.	5934PM-1		Altimeter
United Instruments Inc.	5934PM-1/Code A.316		Altimeter
United Instruments Inc.	5934PM-1/Code A.56		Altimeter

Manufacturer	Manufacturer's P/N	Vendor's P/N	Designation
United Instruments Inc.	5934PM-1/Code A57	C661071-0102	Altimeter
United Instruments Inc.	5934PM-1/Code A84	LA-72-11A	Altimeter
United Instruments Inc.	5934PM-3		Altimeter
United Instruments Inc.	5934PM-3/Code A.199	206-070-263-101	Altimeter
United Instruments Inc.	5934PM-3/Code A84		Altimeter
United Instruments Inc.	5934PM-3A.199		Altimeter
United Instruments Inc.	5934PM-3A.203		Altimeter
United Instruments Inc.	5940DCode A.623	206-070-263-103	Altimeter
United Instruments Inc.	5940DCode A.625	350A76010802	Altimeter
United Instruments Inc.	5943PM-1	Code A.199	Altimeter
United Instruments Inc.	6111 Code D.25		Manifold Press Indicator
United Instruments Inc.	6111Code D.25	269A4250-11	Manifold Press Indicator
United Instruments Inc.	7000Code C.26		Vertical Speed Indicator
United Instruments Inc.	7030 Code C.189	350A760107-01	Vertical Speed Indicator
United Instruments Inc.	7030 Code C.27	350A76103600	Vertical Speed Indicator
United Instruments Inc.	7040C.28		Vertical Speed Indicator
United Instruments Inc.	7130 Code C.41		Vertical Speed Indicator
United Instruments INC.	7160 C.130		Vertical Speed Indicator
United Instruments INC.	7160 C.134		Vertical Speed Indicator
United Instruments Inc.	7160C43C		Vertical Speed Indicator
United Instruments Inc.	7201-3	Code C.148	Vertical Speed Indicator
United Instruments Inc.	8000...	369D24506-3	Airspeed Indicator
United Instruments Inc.	-8000-	369D24506-7	Airspeed Indicator
United Instruments Inc.	8000 Code B.751	206-075-725-003	Airspeed Indicator
United Instruments Inc.	8000 Code B.758		Airspeed Indicator
United Instruments Inc.	8000 Code B.827	350A760106-01	Airspeed Indicator
United Instruments Inc.	8000-BH5		Airspeed Indicator
United Instruments Inc.	8000Code B.11		Airspeed Indicator
United Instruments Inc.	8000Code B.111	206-070-264-007	Airspeed Indicator

Manufacturer	Manufacturer's P/N	Vendor's P/N	Designation
United Instruments Inc.	8000Code B.216	269A4600-13	Airspeed Indicator
United Instruments Inc.	8000Code B.336	206-075-725-001	Airspeed Indicator
United Instruments Inc.	8000Code B.402	369D24506	Airspeed Indicator
United Instruments Inc.	8000Code B.709	L341M10C1001	Airspeed Indicator
United Instruments Inc.	8000Code B.751	206-075-725-103	Airspeed Indicator
United Instruments Inc.	8000Code B.827	350A76010601	Airspeed Indicator
United Instruments Inc.	8000TCode B.111 / SA-40-1RB	206-070-264-007	Airspeed Indicator
United Instruments Inc.	8000TCode B.12/SA-40-01	206-070-264-005	Airspeed Indicator
United Instruments Inc.	8025...		Airspeed Indicator
United Instruments Inc.	8025Code B.845	7050A4341042	Airspeed Indicator
United Instruments Inc.	8030Code B.448		Airspeed Indicator
United Instruments Inc.	8040CodeB.567		Airspeed Indicator
United Instruments Inc.	8125 Code B.784	PS 50049-661	Airspeed Indicator
United Instruments Inc.	9501 Code N.521		Turn and Slip Indicator
United Instruments Inc.	9550A Code N.503	206-070-274-101	Turn and Slip Indicator
United Instruments Inc.	9550A Code N.589	206-070-274-101	Turn and Slip Indicator
United Instruments Inc.	9551 Code N.506		Turn and Slip Indicator
United Instruments Inc.	9551B		Turn and Slip Indicator
United Instruments Inc.	9551B CodeN.541		Turn and Slip Indicator
United Instruments Inc.	9552 Code N.511		Turn and Slip Indicator
United Instruments Inc.	9552A		Turn and Slip Indicator
United Instruments Inc.	KEA-129	5035P2-P44	Encoding Altimeter
VDO	BE412		Voltmeter
VDO	BE413		Ampere-Meter
VDO	BE413-...		Ampere-Meter
VDO	BE418-3		Ampere-Meter
VDO	DK012		Transmitter Pressure

Manufacturer	Manufacturer's P/N	Vendor's P/N	Designation
VDO	DK013		Transmitter Pressure
VDO	DK014		Transmitter Pressure
VDO	DK014-...		Transmitter Pressure
VDO	DK040		Transmitter Pressure
VDO	DK042 Mod 01		Transmitter Pressure
VDO	DK044-1	6685-12-188-3070	Transmitter Pressure
VDO	DK404 / 404A		Press Indicator XMSN Oil
VDO	DK404/A		Press Indicator XMSN Oil
VDO	DK405		Press Indicator XMSN Oil
VDO	DK405/A		Press Indicator XMSN Oil
VDO	DK433		Fuel Press.-Indicator Dual
VDO	DK433-...		Fuel Press Indicator
VDO	DK449-...		Pressure Indicator
VDO	DK483-1		Torque Indicator
VDO	DK504-...		Torquemeter Indicator Dual
VDO	DL401-...		Tachometer Indicator N1
VDO	DL404/4		Tachometer Indicator Triple
VDO	DL404-...		Tachometer Indicator Triple
VDO	DL405		Tachometer Indicator N1
VDO	DL412		Tachometer Indicator N1
VDO	DL412-...	105-90948	Tachometer Indicator N1
VDO	DL436-...		Tachometer Indicator Triple
VDO	DL439-003-003	407-375-008-101	Tachomter Indicator Dual
VDO	DL445-...		Tachometer Indicator N1
VDO	DL446-...		Tachometer Indicator N1
VDO	DL448	6620-12-310-4747	Tachometer Indicator N1
VDO	DL450		Tachomter Indicator Dual
VDO	DL456	222-375-022-111	Tachometer Indicator N1
VDO	DL457-021	407-375-008-101	Tachomter Indicator Dual

Manufacturer	Manufacturer's P/N	Vendor's P/N	Designation
VDO	DT409-...		Torquemeter Indicator Dual
VDO	DT410-...		Torque Indicator
VDO	DT501-6	117-69005-03	Torquemeter Indicator Dual
VDO	FM504	LUO 138 AS 2	Airspeed Indicator
VDO	FM504-...		Airspeed Indicator
VDO	HM509-3 / -3A		Encoding Altimeter
VDO	HM547	Baugleich mit KAA1803LU0-3	Altimeter
VDO	HM565	KAA1803LU/0/3	Altimeter
VDO	HM565-...		Altimeter
VDO	SL249 / 249A		Temp Indicator XMSN Oil
VDO	SL249EM5		Temp Indicator XMSN Oil
VDO	TM410		Temp. Indicator Triple
VDO	TM410-...		Temp. Indicator Triple
VDO	TM420-...		Temp. Indicator
VDO	TM469	6685-12-309-1919	Temp. Indicator
VDO	VT108		Fuel Low Level Warning Switch
VDO	VT405 / 405A	6680-12-144-1909	Fuel Quantity Indicator
VDO	VT405A	6680-12-309-1918	Fuel Quantity Indicator
VDO	VT422-1		Fuel Quantity Indicator
VDO	VT426		Fuel Quantity Indicator
VDO	VT426-...		Fuel Quantity Indicator
VDO	VT476-...		Fuel Quantity Indicator
VDO/Smiths	KCA0101W		Magnetic Compass
VDO/Smiths	KCA0104W		Magnetic Compass
VDO/Smiths	KCA0105W		Magnetic Compass
VDO/Smiths	KCA0113W	KCA0113W	Magnetic Compass
VDO/Smiths	KAA1803LU/0/3	6610-12-151-0526	Altimeter
VDO/Smiths	KAA1803LUO-1		Altimeter

Manufacturer	Manufacturer's P/N	Vendor's P/N	Designation
Voltron Products	124.934A	209-070-263-001	Voltmeter Dual
Walter Kidde Aerospace	892121-0350	209-075-395-001	Fire Control unit
Waltham Clock Comp.	400163		Clock
Waltham Clock Comp.	400216	Type ABU-9/A	Clock
Waltham Clock Comp.	400240	ABU-11A	Clock
Waltham Clock Comp.	400270	212-075-514-101	Clock
Weston Instruments Inc.	157800		Temp.Indicator
Weston Instruments Inc.	253608	369A4521	Temp. Indicator
Weston Instruments Inc.	520751	Model 1122 Type 69-51711	Temp. Indicator
Weston Instruments Inc.	520752		Temp.Indicator
Weston Instruments Inc.	521992	Model 1822, Type 191	Temp. Indicator
Weston Instruments Inc.	522157	Model 1822 Type 263	Temp. Indicator
Weston Instruments Inc.	522298	369A4521-7	Temp. Indicator
Weston Instruments Inc.	22-697-08-2	Model 697	Airspeed Indicator
Weston Instruments Inc.	369A4521-9	369A4521-9	Temp. Indicator
Weston Instruments Inc.	S128-5-150		Tachometer Indicator N1
Weston Instruments Inc.	S219-3-298		Fuel Quantity Indicator
Weston Instruments Inc.	S476.1.394		Temp. Indicator
Weston Instruments Inc.	S476.3.263		Temp Indicator Oil

EASA Part-145 Approved Maintenance Organization (Line & Base Maintenance)
Approval No. DE.145.0082

FAA approved Repair Station
Approval No. DE5Y802M

TCCA Approved Maintenance Organization
Approval No. 813-23

Rating	Non-Destructive Testing	Limitation
D1	Non-Destructive Testing	Liquid Penetrant Inspection (PT) Magnetic Particle Inspection (MT) Eddy Current Inspection (ET)